

Z Axis Assembly




Created by:
Joshua Vasquez

last edited:
6/16/2021

SCALE: 1:4

SHEET 1 OF 23

Make 3 assemblies.






Compress the Delrin anti-backlash nut fully before installing it. Twist it down about 1/3 down the length of the leadscrew.



ITEM NO.	DESCRIPTION	QTY.
1	8mm T8x2 Trapezoidal Lead Screw	3
2	8mm T8x2 Small Delrin Anti-Backlash Nut	3

Lead Screw Nut Installation			
	Created by: Joshua Vasquez	last edited: 6/16/2021	
	SCALE: 1:3	SHEET 2 OF 23	

Press-Fit all pins with an arbor press..



Use the printed fixture to hold both pieces upright while installing the pins with the arbor press.

ITEM NO.	DESCRIPTION	QTY.
1	Left Bed Coupler with Insert	1
2	Right Bed Coupler with Insert	1
3	M4 Dowel Pin, 20mm long	4
4	Spring Pin Insertion Fixture	1
5	Coupling Pin Insertion Fixture	1


Front Coupling Plate Assemblies




Created by:
Joshua Vasquez
last edited:
6/16/2021

SCALE: 2:3 SHEET 3 OF 23

Press-Fit the M4 dowel pins with an arbor press



Exploded View



Assembled View

ITEM NO.	DESCRIPTION	
1	M4 Dowel Pin, 20mm long	2
2	Back Bed Coupler with Insert	1


Back Z Lift Assembly



Created by:
Joshua Vasquez
last edited:
6/16/2021


SCALE: 1:1 SHEET 4 OF 23

Make three Assemblies



Keep these T-Nuts Loose; only two full turns.
They will be tightened into the frame later.

Exploded View



Assembled View

ITEM NO.	DESCRIPTION	
1	M3 Buttonhead Screw, 8mm long	5
2	MGN12C Carriage Block	1
3	400mm (or 395mm) long MGN12 Rail	1
4	M3 Stamped Slide-In T Nuts	5


Linear Rail Assembly




Created by:
Joshua Vasquez
last edited:
6/16/2021

SCALE: 1:2 SHEET 5 OF 23


Make three assemblies using each leadscrew retainer from the prior step.



Ensure that the rail is centered. Then fully tighten all M3 screws. Centering this rail "by eye" is sufficient.



Some rails (HIWIN) are actually 395mm, not 400mm, so make sure that the **top** of the rail is 400mm from the bottom of the extrusion.



Make three Assemblies.


ITEM NO.	DESCRIPTION	QTY.
3	400mm long MGN12 rail with Carriage, screws, and nuts	3
4	430mm 2020 TSlot Extrusion	3

Front Z Tower Assembly




Created by:
Joshua Vasquez
last edited:
6/16/2021

SCALE: 1:3 SHEET 6 OF 23



Exploded View


Keep this nut loose.



Assembled View


Make three Assemblies.

ITEM NO.	DESCRIPTION	QTY.
3	M5 Buttonhead Screw, 10mm long	3
4	M5 Stamped Slide-In T Nut	3
5	Z Leadscrew Retainer	3
6	Backing Spring	3



Add a **Backing Spring** first. Then fully tighten into each rail.

These parts act as hard limits for the Z axis, so the 400mm length is crucial.




Make three Assemblies.

Leadscrew Retainer Assembly





Created by:
Joshua Vasquez
last edited:
6/16/2021

SCALE: 1:1 SHEET 7 OF 23



These holes are for tightening the screws with a hex key in the next step.



Install four M3, 8mm long screws into each hole first on both the front left and right bed coupling lifts.

Installing them here first will make them easier to attach to the carriage in the next step.


ITEM NO.	DESCRIPTION	QTY.
1	Left Bed Coupler with Pins and Insert	1
2	Right Bed Coupler with Pins and Insert	1
3	Back Bed Coupler with Pins and Insert	1
5	M3 Buttonhead Screw, 8mm long	12

Screw Preloading



Created by:
Joshua Vasquez
last edited:
6/16/2021

SCALE: 1:1 SHEET 8 OF 23




ITEM NO.	DESCRIPTION	QTY.
1	Left Bed Coupler with Inserts	1
2	8mm T8x2 Small Delrin Anti-Backlash Nut	1
3	8mm T8x2 Trapezoidal Lead Screw	1
4	M3 Buttonhead Screw, 8mm long	4

Exploded View

Assembled View

ITEM NO.	DESCRIPTION	QTY.
1	Right Bed Coupler with Inserts	1
2	8mm T8x2 Small Delrin Anti-Backlash Nut	1
3	8mm T8x2 Trapezoidal Lead Screw	1
4	M3 Buttonhead Screw, 8mm long	4

Exploded View



Assembled View


Front Z Lift Assemblies




Created by:
Joshua Vasquez
last edited:
6/16/2021

SCALE: 1:2 SHEET 9 OF 23


Left Assembly



Right Assembly



Fully tighten the coupler assembly into the rail carriage.



DETAIL A
SCALE 1 : 1

ITEM NO.	DESCRIPTION	QTY.
4	M3 Buttonhead Screw, 8mm long	8
5	Left Coupler Assembly with Leadscrew	1
6	Right Coupler Assembly with Leadscrew	1
7	Extrusion Assembly with Rail	2
11	Z Leadscrew Retainer	1
12	M5 Buttonhead Screw, 10mm long	1

Front Z Tower Assemblies




Created by:
Joshua Vasquez


last edited:
6/16/2021

SCALE: 1:3

SHEET 10 OF 23



Exploded View



Assembled View


ITEM NO.	DESCRIPTION	QTY.
1	Z Leadscrew with Installed Nut	1
2	Back Bed Coupler with Pins and Inserts	1
3	M3 Buttonhead Screw, 8mm long	4

Back Z Lift Assembly



Created by:
Joshua Vasquez
last edited:
6/16/2021

SCALE: 1:2 SHEET 11 OF 23




ITEM NO.	DESCRIPTION	
1	Z Leadscrew with Installed Nut	1
2	Back Coupling Plate with Inserts	1
5	M3 Buttonhead Screw, 8mm long	8
6	430mm 2020 TSlot Extrusion	1
9	Z Leadscrew Retainer	1
10	M5 Buttonhead Screw, 10mm long Back Z Tower Assembly	1



Created by:
Joshua Vasquez last edited:
6/16/2021

SCALE: 1:3 SHEET 12 OF 23



Set this aside for now.

ITEM NO.	DESCRIPTION	QTY.
1	409mm TSlot Extrusion	1
2	Interior Inside Corner Bracket	4

Ooze Control Assembly




Created by:
Joshua Vasquez

last edited:
6/16/2021

SCALE: 1:2

SHEET 13 OF 23





ITEM NO.	DESCRIPTION	QTY.
1	PSU Socket Holder	1
2	M5 Buttonhead Screw, 8mm long	2

Power Socket Holder 1/2



Created by:
Joshua Vasquez
last edited:
6/16/2021

SCALE: 1:1 SHEET 14 OF 23




Set this aside for now.


ITEM NO.	DESCRIPTION	QTY.
1	IEC320 C14 120V Power Socket	1
2	M3 Flathead Screw, 10mm long	2

Power Socket Holder 2/2			
CC BY	Created by: Joshua Vasquez	last edited: 6/16/2021	
	SCALE: 1:1	SHEET 15 OF 23	


Slide Each Z Axis Assembly into its corresponding set of brackets.




Exploded View



Extrusions should be fully seated such that there is no noticeable gap between the extrusions. Then, tighten the screws on these brackets.



Assembled View



Slide each leadscrew into the coupler about 7 to 9mm deep and tighten the coupler screw. **Do not go deeper than 9mm**, or the couplers may not function properly. If you are using the default T8x2 leadscrews, install 4 grooves deep.

ITEM NO.	DESCRIPTION	QTY.
1	Lower Frame Assembly	1
3	Back Z Lift Assembly	1
4	Left Z Lift Assembly	1
5	Right Z Lift Assembly	1
6	430mm 2020 TSlot Extrusion	4

Z Axis Extrusions






Created by:
Joshua Vasquez
last edited:
6/16/2021


SCALE: 1:6

SHEET 16 OF 23

You must use **Backing Springs** on all these T Nuts or it will be very tricky to do the next steps.



Slide **2** Stamped **M5** T Nuts into each extrusion in the orientations shown. Exact locations don't matter.




ITEM NO.	DESCRIPTION	QTY.
8	M5 Stamped Slide-In T Nuts	6
9	M5 T Nut Backing Spring	6

Z Axis Extrusion T Nuts




Created by:
Joshua Vasquez
last edited:
6/16/2021

SCALE: 1:6 SHEET 17 OF 23



Exploded View

Assembled View



Extrusions should be fully seated such that there is no noticeable gap between the extrusions. Then tighten the screws on these brackets.

ITEM NO.	DESCRIPTION	QTY.
6	430mm 2020 TSlot Extrusion	4

Corner Vertical Extrusions



Created by:
Joshua Vasquez
last edited:
6/16/2021

SCALE: 1:6 SHEET 18 OF 23

You must use **Backing Springs** on all these T Nuts or it will be very tricky to do the next steps.



Slide in:

- **2 Stamped M5 T Nuts on the left**
- **4 in the back**





Slide in:

- **2 Stamped M5 T Nuts on the left**





Slide in:

- **2 Stamped M5 T Nuts on the right**
- **3 in the back**



Slide in:

- **2 Stamped M5 T Nuts on the right**



ITEM NO.	DESCRIPTION	QTY.
6	M5 Stamped Slide-In T Nuts	23
7	M5 T Nut Backing Spring	16

Corner Extrusion T Nuts




Created by:
Joshua Vasquez


last edited:
6/16/2021



SCALE: 1:6
SHEET 19 OF 23



Gently lower the CoreXY frame onto the rest of the frame.



See next page for more details.

CoreXY Installation 1/2




Created by:
Joshua Vasquez

last edited:
6/16/2021

SCALE: 1:6

SHEET 20 OF 23



CoreXY Installation 2/2





Created by:
Joshua Vasquez

last edited:
6/16/2021

SCALE: 1:6

SHEET 21 OF 23



PSU Installation





Created by:
Joshua Vasquez

last edited:
6/16/2021

SCALE: 1:6

SHEET 22 OF 23

Install the bed plate assembly by seating it into the coupling. It should slide into the proper position.



Loop each dangling terminal lugs into an M3, 6mm screw and install as shown above.

Bed Plate Installation



Created by:
Joshua Vasquez

last edited:
6/16/2021

SCALE: 1:5

SHEET 23 OF 23