

MITSUBISHI MOTORS Trouble Shooting Guide for Multimedia models: AU600034 & AU600035

NOTE

- Have you checked for a firmware update?
- Have you tested the customers phone and cable to confirm the fault?
- Have you tested the customers phone on a different head unit? (must be same brand as the customers)

Problem	Symptom / Cause	New	Original GUI	New GUI	Correction
Unit will not power on	Unit does not Turn On		✓	✓	Use multi meter or voltage tester to check power to the pins in the harness into the AVN. Check Vehicle`s BATT & ACC Fuse. Check 15A FUSE on rear of AVN.  Check the radio harness for damaged. Check for dislodged pins in harness plug during install. 
	Unit Frozen		✓	✓	Press the reset button "RES" located below the back icon on the front passenger side face of the unit (using a pen tip/paper clip) 
	Unit Not Starting/Responding to Ignition Cycle	✓	✓	✓	Disconnect battery terminal for 10 minutes
Issues after updating software.	AVN stuck on logo, rebooting or black screen after firmware update		✓		Follow instructions “Recovery from Boot Loop” available on the Mitsubishi portal Knowledge Base. NEW - Recovery from boot loop/black screen issue : Mitsubishi Support (directed.support)
Touch Screen	No Display / No touch functions		✓	✓	Check ignition is in the on position. Touch the PWR button, hold for several seconds.  Check system brightness in Settings Menu. Check to make sure screen protector has been removed (new protectors are fitted to refurbished unit).
	Glare		✓	✓	Check to make sure the screen protector has been removed.
No Sound	Wiring		✓	✓	Speakers or Vehicles wiring may be damaged or shorted to ground - disconnecting or testing speakers one at a time.
	Settings		✓	✓	Check the Volume, Mute, Fader/Balance is set correctly. Carryout a full factory RESET via Settings/Factory menu. 
	No sound from Radio after hanging up Bluetooth phone call		✓	✓	This occurs if the AM or FM station being listened to has not saved - i.e., stored in one of the preset locations. tune station (refer to AVN manual) or perform Auto store to store all available stations.
Radio Stations changing randomly	Inadvertent Function Activation		✓		Station scan activated. (This is the magnifying glass icon, and it scans each stored station for 10 seconds)
Reception AM/FM	Poor or no Reception		✓	✓	Move vehicle outdoors or to a good radio signal area when Auto Storing stations. Ensure antenna has clear sight of the sky. Ensure Antenna is connected at the rear of the unit and installed on vehicle.
	FM Stations Fade in/out		✓		If "AF" is displayed on the screen near the "DX" & "ST" icons, turn the AF function off by selecting the "RDS" icon on the bottom-left side of the tuner screen the touch "AF"
DAB+ (GLX+ & above only)	No Reception		✓	✓	Coverage is limited only to major city regions. Visit the following site for details. Home - Digital Radio Plus
	Reception cuts out at times		✓	✓	
	Stations jump when tuning up/down		✓		Download and install latest Firmware version from Mitsubishi
Mi-DISPLAY Not Working when Smartphone is connected	USB Cable		✓	✓	Ensure the cable supplied with the unit or genuine USB cables are used. This is important for Apple phones, and it is advisable to have your own "reference" cable on hand to confirm that the customer's cable is in fact genuine if not the model supplied with the unit. Consider purchasing a USB cable tester.
	Correct USB Outlet		✓	✓	Ensure the USB cable is connected to the correct USB port in the vehicle. GLX+ & above, use port 2 only  GLX only 
	Android phones		✓	✓	Ensure the Android Auto App installed on the phone and that the latest version of the Android operating system is installed.

Mi-DISPLAY Cuts out	Dirty phone connector		✓	✓	Clean inside the phone and vehicle ports. Use compressed air or a soft tool like a wooden toothpick to clean out lint and dirt.
Product does not pair with Blue Tooth	USB cable being used		✓	✓	When device is connected with USB cable, pairing will not occur, disconnect device. When the device is used for Android Auto, pairing is not allowed, disconnect device from USB cable.
Mi-DISPLAY function does not work.	Mi-DISPLAY function does not work when connecting Smartphone.		✓	✓	Ensure you only use genuine or certified USB cables. (shorter cables are better) Ensure the USB cable is connected to the right USB port in the vehicle denoted with the smartphone icon. (see - Mi-DISPLAY Not Working when Smartphone is connected) Ensure USB plug into the car socket is firm to push in. Test customers phone with known good cable from workshop. Test customers phone on same model AVN in a different vehicle. Ensure Android Auto installed on the customers phone and the latest version of the Android operating system is installed.
Phone charges slowly	Phone charges slowly when connected to Mi-DISPLAY		✓	✓	The Mi-DISPLAY USB connection not only provides an on-screen interface for your phone but will also charge it. Please note that available charge rate is 1A depending on the number of functions being performed by the phone, for example Navigation and Audio Streaming, the charge rate will be reduced compared to charging while not operating Mi-DISPLAY.
CarPlay	Mi-DISPLAY does not work when iPhone is locked.		✓	✓	Go to settings > General > Carplay >  Your Car >  and select  "Allow CarPlay While Locked"
	Stops working after 1 hour		✓	✓	Ensure "USB Accessories" setting is set to on in: Settings/Face ID & Passcode – second bottom selection.
	Crashes when you start playing music		✓	✓	This is an issue in some Firmware versions and can be associated to Apple Music's EQ settings. Go to Settings/Music/EQ and turning off "Late Night" if selected, the disconnect and re-connect the phone.
	Echo during calls (Apple and Android)			✓	Upgrade to firmware Version 2.9 which addresses the echo issue during phone calls. (Service Campaign 020200 software files have been updated from V2.8 to V2.9)
	Not working/Intermittent Operation		✓	✓	Turn off/disable any VPN/DNS apps that are installed on the phone.
			✓	✓	This may occur if the phone is "Jailbroken". Full functionality of the i-Link interface cannot be guaranteed with phones that are jailbroken or using unauthorised software/firmware.
			✓	✓	Delete all CarPlay devices currently stored on the iPhone then re-add them. Go to Settings/General/CarPlay, select each device one by one and then select "Forget this car". When the unit is reconnected after this, you will need to "Allow" Carplay again.
Echo/Whine/Scratchy sound in Android phone Calls	Android Voice Assistant		✓	✓	Certain voice assistant functions may cause echo, so it is recommended to turn off voice assistant functionality when using Mi-DISPLAY. Consult the phone manufacturer's instructions for assistance in doing this. Upgrade to firmware in AVN unit to V2.9
Navigation Lagging, Not Showing Correct Location When Using Mi-DISPLAY	Smartphone GPS Reception		✓	✓	Locate the smartphone in a higher position in the car, ideally not within pockets or consoles but in the line of site of the windows which will provide better GPS coverage.
Phone Charging	Phone Charges Slowly when connected to Mi-DISPLAY / Appears to "Drain Battery"		✓	✓	The Mi-DISPLAY USB connection not only provides an on-screen phone interface but will also charge it. Please note that the available charge rate is 1A so depending on the number of functions being performed by the phone, for example Navigation and Audio Streaming, the charge rate will be reduced compared to charging while not operating Mi-DISPLAY (in other words charge at a lesser rate than the phone is using current). This is because the connection is a data link and is not fast charge. This an issue with most Apple and Android systems. Suggested improvements include closing non-essential apps, utilising low power mode and re-positioning the phone (maybe out of a pocket or bag) to allow better cellular coverage which in turn will reduce battery usage.
	iPhone does not charge over 80% when connected to the unit		✓	✓	There is a factory setting called "Optimised Battery Charging" that can be found in: Settings/Battery/Battery Health (see https://support.apple.com/en-au/HT210512). This setting restricts when the phone can charge over 80%. By turning this function off, the phone can charge over 80%
Bluetooth	Not Pairing		✓	✓	Turn your mobile completely off and restart it. Open Bluetooth settings on your phone and leave the settings menu open when trying to connect and make sure Bluetooth is turned on.
Spotify Not Auto Playing	Software		✓	✓	This is a known issue with Spotify and is not related to the head unit. There is no current fix.

ANDRIOD Auto Mi-DISPLAY Specific Issues

Problem	Symptom / Cause	New	Original GUI	New GUI	Correction
Android Auto not Working/Connecting	Latest Software/Firmware		✓	✓	Make sure Android Auto is installed on the phone and the latest version is installed. 1. Open the Google Play Store. 2. Search for Android Auto. 3. Tap on the Android Auto app page. 4. Hit the Uninstall button and confirm the action by tapping on Uninstall again. Let the process finish. 5. Tap on Update. 6. Try using Android Auto again.
	Memory/Data		✓	✓	Clear the Android Auto app cache and storage: 1. Open the Settings app. 2. Go into Apps. 3. Tap on See all apps. 4. Find and select Android Auto. In some devices, the app is moved to the system and might appear as com.google.android.projection.gearhead. 5. Go into Storage & cache. 6. Tap on Clear storage and Clear cache
	Check the Android Auto settings are correct:		✓	✓	1. Open the Settings app. 2. Go into Connected devices. 3. Tap on Connection preferences. 4. Hit Android Auto. 5. Select Start Android automatically and pick Always. 6. Toggle on Start Android Auto while locked. 7. Tap on Previously connected cars at the top of the settings and ensure your vehicle isn't accidentally on the Rejected cars list. 8. Enable Add new cars to Android Auto. However, in some cases, if you plan to use the same car every time, users say that disabling this setting helps fix connection problems.
	Accepted/Rejected Cars in Android Auto App		✓	✓	Find Advanced Settings/Android Auto and "forget" all cars in the app then try reconnecting or check to see if the phone is listed in the Rejected cars header.
Spotify / Music Player volume lower compared to radio	Android Auto Settings (which vary from handset brand to brand).		✓	✓	Turn off "Normalise Volume" in Spotify app settings.
			✓	✓	If the phone's audio settings have EQ settings applied, please remove them (i.e., set to default)
			✓	✓	Make sure handset volume is full once the Bluetooth connection starts
			✓	✓	Depending on handset brand, turn off "Adapt Sound"
Random Screen "Freezes" / Black Screen	Android Auto Operating System Please google the phone model for specific help - please see some suggestions here		✓	✓	Try unlocking/locking the phone
			✓	✓	Set Android Auto services to high performance mode
			✓	✓	Disable battery optimizations for all Android Auto services
Screen Resolution Lower Than Home Screen when Android Phone Connected	Android Auto Specific		✓	✓	1. Open the Settings app. 2. Go into Connected devices. 3. Tap on Connection preferences. 4. Hit Android Auto. 5. Scroll to the bottom and tap on the Version section to display the Version and permission info. 6. Tap on this section multiple times continuously. 7. You'll be asked if you want to allow development settings. Hit OK. 8. Tap on the three-dot menu icon in the top-right corner. 9. Open Developer settings. 10. Go to Video resolution. 11. Set the resolution to the highest option available.

V2.2