MITSUBISHI MOTORS

WARRANTY INFORMATION BULLETIN

WIB 2013-10 19/04/2013

This Bulletin forms part of the Warranty Procedure Manual.

ATT: SERVICE MANAGERS/WARRANTY ADMINISTRATORS

Master Warranty Descriptions

This Warranty Bulletin is to advise dealers that a description has been added to the vehicle master warranty codes.

Previously when a vehicle check was performed, the vehicle master warranties would show the master warranty code in the "Warranty Type Text" column and would only show the same code again in the "Description Master Warranty" column.

Now the master warranty code will appear in the "Warranty Type Text" column and the "Description Master Warranty" column will show the master warranty code and a description of what that code represents.

Below is an example of how this now looks in the dealer portal and there is also a table of all the possible master warranty codes with their description.

Master Warranty Details

Warranty Type	Warranty Type Text	Description Master Warranty
A	C1-60-99	C1-60-99 Perforation Wty
B	E1-60-130	E1-60-130 Emission System Wty
C	D1-60-130	D1-60-130 Electronics System Wty
D	01-60-130	01-60-130 Basic Wty
E	S3-60-130	S3-60-130 Safety System Wty
F	P1-120-160	P1-120-160 Power Train Wty 10/5
G	E2-120-160	E2-120-160 Emission Power Train Wty 10/5
H	02-12-20	02-12-20 Limited Life Wty
I	AX-36-130	AX-36-130 Accessories Wty

To contact Warranty Payments Administration:
Warranty Telephone: (08) 8275 2367
e-mail: warrantyadmin@mmal.com.au
mmal_warranty_admin@mmal.com.au
Address: 1284 South Road Clovelly Park SA 5042
PO Box 8 Melrose Park SA 5039

Description	
Old	New
C1-60-99	C1-60-99 Perforation Wty
E1-60-130	E1-60-130 Emission System Wty
D1-60-130	D1-60-130 Electronics System Wty
01-60-130	01-60-130 Basic Wty
S3-60-130	S3-60-130 Safety System Wty
P1-120-160	P1-120-160 Power Train Wty 10/5
E2-120-160	E2-120-160 Emission Power Train Wty 10/5
02-12-20	02-12-20 Limited Life Wty
AX-36-130	AX-36-130 Accessories Wty
C1-0-0	C1-0-0 Perforation Wty (restricted)
E1-0-0	E1-0-0 Emissions System Wty (Restricted)
D1-0-0	D1-0-0 Electronics Sys Wty (Restricted)
D1-0-0	D1-0-0 Electronics Sys Wty (Restricted)
01-0-0	01-0-0 Basic Wty (Restricted)
S3-0-0	S3-0-0 Safety System Wty (Restricted)
P1-0-0	P1-0-0 Power Train Wty (Restricted)
E2-0-0	E2-0-0 Emission Pwr Trn Wty (Restricted)
02-0-0	02-0-0 Limited Life Wty (Restricted)
AX-0-0	AX-0-0 Accessory Wty (Restricted)
C1-72-130	C1-72-130 Perforation (Extended)
E1-72-130	E1-72-130 Emission Sys Wty (Extended)
01-72-130	01-72-130 Basic Wty (Extended)
S3-72-130	S3-72-130 Safety Sys Wty (Extended)
E1-60-100	E1-60-100 Emission Sys Wty (EV)
D1-60-100	D1-60-100 Electronics Sys Wty (EV)
S3-60-100	S3-60-100 Safety Sys Wty (EV)
P1-120-100	P1-120-100 Power Train Wty (EV)
GW-99-999	GW-99-999 Goodwill
01-60-100	01-60-100 Basic Wty (EV)
S3-60-100	S3-60-100 Safety Sys Wty (EV)
P1-60-130	P1-60-130 Power Train Wty 5/5
E2-60-130	E2-60-130 Emission Power Train Wty 5/5
D1-72-130	D1-72-130 Electronics Sys Wty (Extended)
E2-60-130	E2-60-130 Emission Power Train Wty (EV)
AX-36-100	AX-36-100 Accessory Wty (EV)

Neale Clarke
Manager, Warranty
Corporate Quality

To contact Warranty Payments Administration:
Telephone Warranty Hot Line: (08) 8275 2367
Fax: (08) 8275 2496
E-mail: mmal_warranty_admin@mmal.com.au
Address: 1284 South Road Clovelly Park SA 5042
PO Box 8 Melrose Park SA 5039