

EMM - Procedure

2008. 11. 05

Yong Hak, Jung / Onnet Technologies

Tel:016-500-8582

E-Mail: jyhpan@ont.co.kr





- Acronyms
- EMM Specific Procedure
 - Attach
 - Detach
 - Tracking Area Updating
- EMM connection management Procedure
 - Service request
 - Paging
- EMM STATUS message
- Q&A

Acronyms




- EPC : Evolved Packet Core Network
- EPS : Evolved Packet System
- EMM : EPS Mobility Management
- GUTI : Globally Unique Temporary Identity
- IMSI : International Mobile Subscriber Identity
- KSI : Key Set Identifier
- MME : Mobility Management Entity
- NAS : Non Access Stratum
- PDN GW : Packet Data Network Gateway
- S-TMSI : S-Temporary Mobile Subscriber Identity
- TAC : Tracking Area Code
- TAI : Tracking Area Identity
- TIN: Temporary Identity used in Next Update
- TMSI : Temporary Mobile Subscriber Identity




- Attach
 - 목적 : packet service 위해 EPC 에 Attach
 - _결과
 - Context in MME
 - Default bearer
 - Always on IP connectivity
 - IPv4, IPv6 Address
 - UE에서 먼저 시작함












- Abnormal cases in the UE
 - Access barred
 - Lower layer failure
 - **T3410 timeout**
 - ATTACH REJECT
 - Cause code 에 따른 Action
 - Change of cell
 - Mobile originated detach
 - Detach procedure collision
 - PDU Transmission failure
- Attach attempt counter
 - Counter < 5
 - T3411 Start, EMM-DEREGISTERED.ATTEMPTING-TO-ATTACH, expired Attach restart
 - Counter == 5
 - Delete GUTI, TAI list, TAI, PLMN list
 - T3402 Start






- Abnormal cases on the network side
 - Lower layer failure
 - Protocol error
 - **T3450 timeout**
 - ATTACH REQUEST duplicated
 - ATTACH REQUEST in EMM-REGISTERED
 - TAU received before ATTACH COMPLETE




- Detach
 - _ 목적
 - EPS Service detach
 - Disconnect PDN connected
 - Network 가 UE에게 더 이상 필요 없는 EPS 라고 알리기 위해
 - _ 발생시기
 - UE Switch off
 - USIM removed
 - EPS capability Disable
 - 연결 되었던 Context
 - Deactivated without Peer to Peer PDU
 - 양쪽 모두 시작할 수 있음













- Tracking Area Updating
 - S1 mode only
 - _ 발생목적
 - Normal : 실제 Tracking Area 를 등록하기 위해서
 - Periodic : UE 의 Availability 를 Network 에 알리기 위해서
 - Intersystem change: lu mode / A Gb mode / S101 mode -> S1 mode
 - MME load balancing
 - UE에서 먼저 시작함
 - UE 가 EMM-IDLE 모드인 경우 radio and \$1 bearer 재요청
 - _ 발생시기
 - UE가 알려지지 않은 Tracking Area 에 진입시
 - T3412 expired
 - RRC가 "load balancing TAU required" 보낼 경우












- Abnormal cases in the UE
 - Access barred
 - Lower layer failure
 - **T3430 timeout**
 - TAU REJECT
 - Cause code 에 따른 Action
 - Change of cell
 - TAU and detach procedure collision
 - GUTI reallocation procedure collision
 - PDU Transmission failure
- Tracking Area Updating attempt counter
 - Counter < 5
 - T3411 Start, expired TAU restart, 상태 변경
 - Counter == 5
 - T3402 start, delete equivalent PLMN list





- Abnormal cases on the network side
 - Lower layer failure
 - Protocol error
 - **T3450 timeout**
 - TRACKING AREA UPDATE REQUEST duplicated


EMM Connection Management Procedure

- Service Request




- Service Request
 - _ 목적
 - EMM-IDLE 모드를 EMM-CONNECTED 모드로 변환시키기 위해 사용
 - Establish Radio and S1 Bearers
 - _ 발생조건
 - Network 가 Downlink signal pending 상태일 때
 - UE 가 Uplink signal pending 상태일 때
 - UE 가 IDLE MODE 이고 Data pending 상태일 때
 - UE 가 IDLE MODE 이고 Paging Request 를 받을 경우
 - _ UE 에서 시작











- Abnormal cases in the UE
 - Access barred
 - Lower layer failure
 - **T3417 timeout**
 - SERVICE REJECT
 - Cause code 에 따른 Action
 - TAU procedure triggered
 - Power off
 - Procedure collision
 - Dedicated / Default Bearer set up failure
 - PDU Transmission failure



- Abnormal cases on the network side
 - Lower layer failure
 - Protocol error
 - SERVICE REQUEST duplicated
 - ATTACH REQUEST received
 - TAU REQUEST received

EMM Connection Management Procedure


- Paging



- Paging
 - _ 목적
 - UE에게 NAS signalling connection 설립을 요청하기 위해 사용
 - Init mobile terminating CS fallback procedure
 - Network 에서 시작
 - _ 종류
 - Using S-TMSI: NAS signalling connection
 - Using IMSI: abnormal procedure for error recovery
- NAS Signalling connection
 - S1 mode 에서 UE와 MME 사이의 Peer to Peer Connection
 - LTEuu 인터페이스 + S1AP Connection


EMM Connection Management Procedure - Paging





EMM Connection Management Procedure - Paging





EMM STATUS message



- EMM STATUS message
 - _ 목적
 - EMM Protocol Data 수신 시 검출되는 error conditions 을 Report 하기 위해서 사용
 - UE 또는 Network 에서 시작
 - Implementation dependent





Question & Answer