

Network & Connectivity

Simple troubleshooting guide for customers — no technical knowledge needed

1. Signal Loss / Weak Coverage

What this means: Your phone shows no bars or very few bars and calls or internet are not working properly.

Step 1: Turn your phone OFF, wait 30 seconds, then turn it back ON.

Step 2: Check that Airplane Mode is OFF — go to Settings and look for Airplane Mode.

Step 3: Move to an open area like a balcony, terrace, or near a window. Thick walls and basements block signal.

Step 4: Remove your SIM card, wipe it gently with a dry cloth, and put it back in firmly.

Step 5: Go to Settings → Mobile Network → Network Selection → select 'Automatic'.

Step 6: If you are indoors often, ask us about Wi-Fi calling — it uses your home Wi-Fi so signal does not matter.

Step 7: If the problem continues for more than 2 hours in the same location, raise a ticket or call us.

■ ■ Weak signal is usually caused by your location, not your phone or SIM. Moving just a few metres can make a big difference.

2. Internet Feels Slow / Laggy / Unstable

What this means: Pages load slowly, videos keep buffering, or apps take a long time to respond.

Step 1: Check your data balance first — dial *123# or open the app. If your balance is zero, recharge and the speed will return.

Step 2: Switch mobile data OFF, wait 10 seconds, then switch it back ON.

Step 3: Restart your phone — this refreshes the connection.

Step 4: Close apps that are running in the background — they silently use your data.

Step 5: Avoid using internet in crowded places like stadiums or malls during peak hours — many people sharing the network slows it down.

Step 6: Try moving to an open outdoor area to see if speed improves.

Step 7: If speed is consistently slow at home for more than a day, contact us and we will check your area.

■ ■ Slowness is often due to low data balance or too many apps running. These are easy to fix yourself in under 2 minutes.

3. Fiber Cut / Internet Line Broken

What this means: Your home broadband or fiber internet has completely stopped working, often after bad weather or construction nearby.

Step 1: Check if the lights on your router/modem are normal. If the internet light is red or off, there is a line issue.

Step 2: Restart your router — switch it off, wait 1 minute, switch it back on.

Step 3: Check if your neighbours also have no internet — if yes, it is likely a line issue in your area.

Step 4: Do NOT try to fix or touch any wires or cables outside your home — this is dangerous.

Step 5: Raise a ticket or call us. A technician will be sent to your area. Average fix time: 4–8 hours.

Step 6: Use your mobile data as a backup until the fiber is restored.

■■ Fiber cuts are usually caused by external factors like digging or storms. Our field team will repair it as fast as possible.

4. Website / App Not Opening (DNS Issue)

What this means: Your internet connection works but specific websites or apps are not loading — you may see 'This site can't be reached'.

Step 1: Restart your phone or router first.

Step 2: Try opening a different website or app to check if it is just one website or all of them.

Step 3: Turn Airplane Mode ON for 10 seconds, then turn it OFF — this resets your internet connection.

Step 4: If you are on Wi-Fi, forget the Wi-Fi network and reconnect to it.

Step 5: Try using a different network (switch from Wi-Fi to mobile data) to see if the issue is with your connection or the website.

Step 6: If a specific app is not opening, delete it and reinstall from the Play Store or App Store.

Step 7: If many websites are not opening, contact us — our team can reset your internet settings remotely.

■■ If only one website is not opening, the issue is with that website's server — not your connection. Try again after some time.

5. Calls / Routing Not Working Correctly

What this means: Your calls are going to the wrong number, getting cut off immediately, or not connecting at all.

Step 1: Restart your phone and try the call again.

Step 2: Check that you are dialling the correct number including the area code for landlines.

Step 3: Make sure Call Forwarding is NOT accidentally turned on — Settings → Phone → Call Forwarding → check it is off.

Step 4: Check your call balance if you are on a prepaid plan.

Step 5: Try calling from a different location — sometimes routing issues are area-specific.

Step 6: If calls are going to a wrong number automatically, raise an urgent ticket — this needs immediate attention from our network team.

■■ Routing issues that happen automatically (calls going to wrong numbers without your input) should be reported immediately.