

Drawing Standard Drawing Sheet

EGD-ME101-18


Swarn Singh

Drawing Sheet: Standard size


- Trimmed paper of a size A0 ~ A4.
- Standard sheet size (JIS)

A4 210 x 297 A3 297 x 420 A2 420 x 594 A1 594 x 841 A0 841 x 1189

(Dimensions in millimeters)




Drawing Sheet: Orientation & Margin




Sheet size	c (min)	d (min)
A4	10	25
A3	10	25
A2	10	25
A1	20	25
Α0	20	25


2. Type Y (A4 only)




TITLE BLOCK FOR STUDENTS



TITLE BLOCK FOR STUDENTS




TITLE BLOCK FOR FIRM



Drawing Scales: Definition

Length, size

Scale is a ratio between the linear dimension of a drawn representation of an object and the actual object.



Drawing Actual

Drawing Scales: Designation

Designation of a scale consists of the word "SCALE" followed by the indication of its ratio, as follows

SCALE 1:1 for full size

SCALE X:1 (X > 1) for an enlargement scales

SCALE 1:X (X > 1) for a *reduction* scales

Drawing scale is commonly found in a title block.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:	CAD GENERATED DRA DO NOT MANUALLY U		INTERBRIDGE	
FRACTIONS DECIMALS ANGLES	APPROVALS	DATE	DDOODEOON/E DIE	
XXX±0.02"	DRAWN		PROGRESSIVE DIE	
± 1/32"			FOR P/N	
	CHECKED		TORFIN	
MATERIAL				
	RESP ENG		4 0 0 V D D 4 V // N / O 0	
FINISH			」 ASSY DRAWINGS	
	REVISION		SIZE DWG, NO. REV.	
	QUAL ENG		D	
DO NOT SCALE DRAWING	QUAL ENG		SCALE 1:1 CADFILE: Sheet_02_03_04 SHEET 1 OF 3	

Drawing Scales: Notes

Dimension numbers shown in the drawing represent the "true size" of an object and they are independent of the drawing scale used.

Drawing Scales: Standard scale

Standard reducing scales are 1:2, 1:5, 1:10, 1:20, 1:50, 1:100

Standard enlarging scales are

2:1, 5:1, 10:1, 20:1, 50:1, 100:1

LETTERING

Writing text on a drawing (e.g. titles, dimensions, scales) using letters which can be alphabets, numerals, symbols or punctuation marks to convey detailed information.

Features of Lettering

- Legibility, uniformity, ease, rapidity of execution and reproducibility
- 2. No ornamental or artistic and cursive style of letter
- Letters should be distinguishable from each other in order to avoid any confusion even in case of slight mutilations

Standard followed

IS 9609 (Part 0): 2001 & SP46: 2003 (lettering for technical drawings). This BIS standard is based on ISO 3098-0: 1997

Types of Lettering


- Single stroke Thickness of the line of the letter should be such as is obtained in one stroke of the pencil.
 - Does not mean that the letter should be made in one
- **Double stroke** When more thickness is given to single stroke letters, it is known as double stroke or gothic letters.

Both types can be Vertical or Inclined at 75° to the horizontal

- BIS (SP46:2003) Gives dimensions for lettering & types
 - Type A Height of capital letter is divided into 14 parts
 - Type B Height of capital letter is divided into 10 parts


Line Width of Type A < Type B

Examples



BIS (SP 46: 2003) has recommended the heights of letters as: 1.8, 2.5, 3.5, 5, 7, 10, 14 & 20 mm

Total height of lowercase letters equals that of capital letters.



The height-to-width ratio for letters varies between 7:4 or 7:6

Height and width of letters

Sr. no	Items on a drawing	Size (mm)
1	Name of the company	10, 14, 20
2	Drawing numbers, letters denoting section planes	10,14
3	Title of the drawing	7, 10
4	Sub- titles & Headings	5, 7
5	Dimensioning, notes, schedules & material lists	3.5, 7
6	Alteration entries and tolerances	3.5

Recommendation

Text's style on the drawing **Examples** must have the following 2 properties

Legibility

- Shape
- Space between letters
- Space between words

Uniformity

- Size (or text height)
- line thickness

ESTIMATE GOOD

EstiMaTe

Not uniform in style.

ESTIMATE ESTIMATE

Not uniform in height.

EST/MATE ESTIMATE

Not uniformly

ESTIMATE ESTIMATE


Not uniform in thickness of stroke.


ESTIMATE Inappropriate space between letters

Style

- Gothic vertical style.
- Begin the sentence, phrase or word with a capital letter.
- Text height 2~3mm.
- Space between lines of text is about of text height.
- Height of the lower-case letter is about 2/3 of that of a capital letter.

Basic Strokes








Upper-case Letters & Numerals


Straight line Curved line letters & **Numerals**


Lower-case Letters






































VERTICAL GOTHIC LETTERS




Fig. 4.8. Single stroke vertical Gothic (thick) letters and Numerals Ratio 7: 4 (SP: 46-1988)

INCLINED GOTHIC LETTERS






Fig. 4.9. Single stroke inclined Gothic (thick) letters and numerals Ratio 7:4 (SP: 46-1988)

DOUBLE STROKE LETTERS




DOUBLE STROKE NUMERICS




Word Composition

Space between the letters depends on the adjacent contour of the letters.




Word having non-uniform spacing is more readable.

Word Composition



- Contour can be denoted as "straight", "slant" and "curve".
- Adjacent contour can be
 - 1. straight-straight : II, IN, IM, IP etc.
 - 2. straight-curve (or curve-straight): IO, QR etc.
 - 3. straight-slant (or slant-straight) : IV, IW etc.
 - 4. curve-curve : OO, OG etc.
 - 5. slant-curve (or curve-slant) : VO, WG, VC etc.
 - 6. slant-slant : VW, VX etc.



Sentence Composition


Leave the space between words equal to the space requires for writing a letter "O".

Example

ALLODIMENSIONSOAREOIN
MILLIMETERSOUNLESS
OTHERWISEOSPECIFIED.





Inclined Capital Letters At 75°



The height of index is half of height of a base letter

Fraction & Indices lettering






- Height of numerator and denominator = 3/4th of height of non-fractioned number
- division bar and numerator or denominator should be such that the total height of fraction will be twice of that of non-fractioned number

Few Tips

If you put the central horizontal strokes of the letters B, E, F, and H at midheight, they will appear to be below center. To overcome this optical illusion, draw the strokes B, E, F, and H slightly above the center as you letter, keeping letters uniform, as in the second example of fig(right below).





Use extremely light horizontal guidelines to keep letter height uniform as shown in Figure (left above). Do not use vertical guidelines to space the distance from one letter to the next within a word or sentence. This should he done by eye while lettering.

Some combinations, such as LT and VA, may have to be slightly closer than other letters to look correctly spaced. In some cases the width of a letter may be decreased slightly. In typesetting, pairs of letters that need to be spaced more closely to appear correctly are called kerned pairs.