

Remove and Install Footpegs - Stark VARG MX 1.2 / EX

Video link: <https://www.youtube.com/watch?v=3jf77p82xLY>

Source video: Remove and Install Footpegs - Stark VARG MX 1.2 by Stark Future Official

Applicable models: MX 1.2 / EX

Scope

This guide converts the official Stark Future tutorial video into a step-by-step workshop procedure. It documents each action shown in the video in sequence and pairs every step with a dedicated screenshot.

Preparation

- Place the bike on a stable stand or work area before starting the procedure.
- Prepare the correct tools for the fasteners, clips, brackets, and components shown in the video.
- Keep removed hardware organized in sequence so reassembly follows the same order as the video.
- Have a torque wrench ready for any tightening steps that specify a torque value.

Removal Procedure

1. Unscrew the right foot peg pin

Unscrew the right foot peg pin.



2. Remove the foot peg from the side plate

Remove the foot peg from the side plate.



3. Unscrew the left foot peg pin

Unscrew the left foot peg pin.



4. Remove the foot peg from the side plate

Remove the foot peg from the side plate.



Installation Procedure

5. Position the right foot peg into the right side plate

Position the right foot peg into the right side plate.



6. Tighten the foot peg pin to 20 Nm

Tighten the foot peg pin to **20 Nm**.



7. Position the left foot peg into the left side plate

Position the left foot peg into the left side plate.



8. Tighten the foot peg pin to 20 Nm

Tighten the foot peg pin to **20 Nm**.



Torque Summary

Component	Torque
Tighten the foot peg pin	20 Nm

Video-sourced torque items:

- Tighten the foot peg pin: **20 Nm** from the official Stark tutorial video.

Critical Checks Before Riding

- Confirm the serviced component is fully seated and all fasteners are tightened in the correct order.
- Recheck all torque-critical hardware before riding.
- Make sure all routed cables, clips, brackets, and surrounding parts are returned to their original positions.
- Inspect the bike visually for any missing hardware before returning it to service.