

How to remove and install the Horn on your Stark VARG EX

Video link: https://www.youtube.com/watch?v=9P_dmj_X0LQ

Source video: How to remove and install the Horn on your Stark VARG EX by Stark Future Official

Applicable models: EX

Scope

This guide follows the same step-by-step workshop structure as the MX tutorials, but it is derived as a visual sequence from the official Stark Future ASMR video. Because the EX video does not provide usable captions or narration, the procedure is documented through curated screenshots and concise action guidance.

Preparation

- Place the bike on a stable stand or work area before starting the procedure.
- Prepare the correct tools for the fasteners, clips, brackets, and components shown in the video.
- Keep removed hardware organized in sequence so reassembly follows the same order as the video.
- Have a torque wrench ready for any tightening steps that specify a torque value.

Removal Procedure

1. Remove the fasteners or panels that block access to the Horn

Remove the front-mask or side-access hardware needed to expose the horn bracket and horn wiring behind the left fork area.

Keep the removed hardware organized in sequence so the same covers and brackets can be returned during assembly.



2. Release the clips and routing points for the Horn

Remove the upper front-mask fastener that opens access to the horn bracket area.

Document the original routing so the same path and slack are restored during installation.



3. Disconnect the Horn

Remove the side fastener that frees the front-mask access area so the horn lead and bracket can be reached.

Release the connector lock first and avoid pulling on the wire itself.



4. Remove the retaining hardware for the Horn

Remove the horn mounting fastener from the bracket while supporting the horn body.

Support the component as the last fastener is removed so it does not drop or hang on the wiring.



5. Remove the Horn from the bike

Remove the horn from the bike once the lead and mounting fastener are free.

Keep any washers, spacers, sleeves, or rubber mounts with the removed component for reassembly.



Installation Procedure

6. Position the Horn for installation

Position the horn back onto its bracket in the same orientation used before removal.

Confirm that no cable is trapped behind the component before the fasteners are started.



7. Reconnect the Horn and route the wiring correctly

Reconnect the horn lead and return it to the original clips and guides behind the front assembly.

Check that the wiring has enough slack for steering, suspension, and normal component movement.



8. Install the retaining hardware for the Horn

Install the horn mounting fastener and then refit any front-mask or access hardware removed for access.

Reinstall any removed clips, covers, or brackets after the main hardware is secure.



9. Verify the operation of the Horn

Verify the horn is secure on its bracket and operates correctly.

Inspect the surrounding routing and hardware one more time before returning the bike to service.



Critical Checks Before Riding

- Confirm the serviced component is fully seated and all fasteners are tightened in the correct order.
- Recheck all torque-critical hardware before riding.
- Make sure all routed cables, clips, brackets, and surrounding parts are returned to their original positions.
- Inspect the bike visually for any missing hardware before returning it to service.