

How to remove and install the Steering Locker Barrel on your Stark VARG EX

Video link: <https://www.youtube.com/watch?v=FmNoajqid1w>

Source video: How to remove and install the Steering Locker Barrel on your Stark VARG EX by Stark Future Official

Applicable models: EX

Scope

This guide follows the same step-by-step workshop structure as the MX tutorials, but it is derived as a visual sequence from the official Stark Future ASMR video. Because the EX video does not provide usable captions or narration, the procedure is documented through curated screenshots and concise action guidance.

Preparation

- Place the bike on a stable stand or work area before starting the procedure.
- Prepare the correct tools for the fasteners, clips, brackets, and components shown in the video.
- Keep removed hardware organized in sequence so reassembly follows the same order as the video.
- Have a torque wrench ready for any tightening steps that specify a torque value.

Removal Procedure

1. Prepare access to the Steering Locker Barrel

Open the surrounding panel area so the Steering Locker Barrel mounting points and wiring path are fully accessible.

Keep the removed fasteners organized in sequence so reassembly matches the video.



2. Remove the visible retaining hardware for the Steering Locker Barrel

Remove the visible Steering Locker Barrel fasteners and support the part so it does not hang on the wiring.

Support the component as the last fastener is removed.



3. Release any bracket, clip, or coupling attached to the Steering Locker Barrel

Free any bracket, clip, spacer, linkage, or connector that still ties the Steering Locker Barrel to the bike.

Note the orientation of these supporting pieces before setting them aside.



4. Remove the Steering Locker Barrel from the bike

Remove the Steering Locker Barrel from the bike once the connector, routing clips, and mounting hardware are free.

Inspect the removed part and the mounting points before reassembly.



Installation Procedure

5. Position the Steering Locker Barrel for installation

Return the Steering Locker Barrel to its mounting position and align the holes, tabs, or locating surfaces.

Hold the component in place until the first retaining hardware is started.



6. Reconnect or refit the support pieces for the Steering Locker Barrel

Reinstall any bracket, clip, spacer, linkage, or coupling associated with the Steering Locker Barrel.

Make sure each supporting piece is seated correctly before final tightening.



7. Install the retaining hardware for the Steering Locker Barrel

Install the Steering Locker Barrel mounting hardware by hand first and seat the part evenly against its bracket or panel.

Check that the component remains aligned while the hardware is brought fully home.



8. Verify the completed installation of the Steering Locker Barrel

Inspect the final position of the Steering Locker Barrel and confirm that all hardware, clips, and surrounding parts are back in place.

Check the component for correct fit and movement before returning the bike to service.



Critical Checks Before Riding

- Confirm the serviced component is fully seated and all fasteners are tightened in the correct order.
- Recheck all torque-critical hardware before riding.
- Make sure all routed cables, clips, brackets, and surrounding parts are returned to their original positions.
- Inspect the bike visually for any missing hardware before returning it to service.