

Remove and Install Front Brake Assembly - Stark VARG

Video link: <https://www.youtube.com/watch?v=HPDYJlpExLc>

Source video: Remove and Install Front Brake Assembly - Stark VARG by Stark Future Official

Applicable models: MX

Scope

This guide follows the same step-by-step workshop structure as the MX tutorials, but it is derived as a visual sequence from the official Stark Future ASMR video. Because the source video does not provide usable captions or narration, the procedure is documented through curated screenshots and concise action guidance.

Preparation

- Place the bike on a stable stand or work area before starting the procedure.
- Prepare the correct tools for the fasteners, clips, brackets, and components shown in the video.
- Keep removed hardware organized in sequence so reassembly follows the same order as the video.
- Have a torque wrench ready for any tightening steps that specify a torque value.

Removal Procedure

1. Prepare access to the Front Brake Assembly

Remove the surrounding parts needed to expose the Front Brake Assembly and its routing or mounting points.

Keep the removed fasteners organized in sequence so reassembly matches the video.



2. Remove the visible retaining hardware for the Front Brake Assembly

Remove the visible Front Brake Assembly fasteners while supporting the brake component as the hardware comes free.

Support the component as the last fastener is removed.



3. Release any bracket, clip, or coupling attached to the Front Brake Assembly

Free any bracket, clip, spacer, linkage, or connector that still ties the Front Brake Assembly to the bike.

Note the orientation of these supporting pieces before setting them aside.



4. Remove the Front Brake Assembly from the bike

Remove the Front Brake Assembly from the bike once the last fastener and any routed support pieces are released.

Inspect the removed part and the mounting points before reassembly.



Installation Procedure

5. Position the Front Brake Assembly for installation

Return the front brake master cylinder and front brake caliper to their mounting positions.

Hold the master cylinder in place and tighten the clamp bolts to **6 Nm**.



6. Reconnect or refit the support pieces for the Front Brake Assembly

Slide the front brake caliper onto the brake disc and start the caliper bolts by hand.

Tighten the front brake caliper bolts to **25 Nm**.



7. Install the retaining hardware for the Front Brake Assembly

Align the front brake line bracket so the hose is not twisted or crushed, then install the bracket screws.

Tighten the fork brake line bracket screws to **3 Nm**.



8. Verify the completed installation of the Front Brake Assembly

Refit the front number plate and make sure the brake line is routed back into the number plate guides.

Inspect the full front brake assembly for correct fit, routing, and lever feel before returning the bike to service.



Torque Summary

Component	Torque
Tighten the hand brake master cylinder clamp bolts	6 Nm
Tighten the front brake caliper bolts	25 Nm
Tighten the fork brake line bracket screws	3 Nm

Verified torque items:

- Tighten the hand brake master cylinder clamp bolts: **6 Nm** from Stark technical manual 02.009.01 Remove and install hand brake master cylinder.
- Tighten the front brake caliper bolts: **25 Nm** from Stark technical manual 02.005.01 Remove and install front brake caliper.
- Tighten the fork brake line bracket screws: **3 Nm** from Stark technical manual 02.011.01 Remove and install front brake line bracket.

Critical Checks Before Riding

- Confirm the serviced component is fully seated and all fasteners are tightened in the correct order.
- Recheck all torque-critical hardware before riding.
- Make sure all routed cables, clips, brackets, and surrounding parts are returned to their original positions.
- Inspect the bike visually for any missing hardware before returning it to service.