

Remove and Install Throttle - Stark VARG

Video link: <https://www.youtube.com/watch?v=zP623x53H-I>

Source video: Remove and Install Throttle - Stark VARG by Stark Future Official

Applicable models: MX

Scope

This guide follows the same step-by-step workshop structure as the MX tutorials, but it is derived as a visual sequence from the official Stark Future ASMR video. Because the source video does not provide usable captions or narration, the procedure is documented through curated screenshots and concise action guidance.

Preparation

- Place the bike on a stable stand or work area before starting the procedure.
- Prepare the correct tools for the fasteners, clips, brackets, and components shown in the video.
- Keep removed hardware organized in sequence so reassembly follows the same order as the video.
- Have a torque wrench ready for any tightening steps that specify a torque value.

Removal Procedure

1. Prepare access to the Throttle

Open the surrounding panel area so the Throttle mounting points and wiring path are fully accessible.

Keep the removed fasteners organized in sequence so reassembly matches the video.



Remove number plate up and outward

2. Remove the visible retaining hardware for the Throttle

Remove the visible Throttle fasteners and support the part so it does not hang on the wiring.

Support the component as the last fastener is removed.



3. Release any bracket, clip, or coupling attached to the Throttle

Free any bracket, clip, spacer, linkage, or connector that still ties the Throttle to the bike.

Note the orientation of these supporting pieces before setting them aside.



4. Remove the Throttle from the bike

Remove the Throttle from the bike once the connector, routing clips, and mounting hardware are free. Inspect the removed part and the mounting points before reassembly.



Installation Procedure

5. Position the Throttle for installation

Return the Throttle to its mounting position and align the holes, tabs, or locating surfaces.

Hold the component in place until the first retaining hardware is started.



6. Reconnect or refit the support pieces for the Throttle

Reinstall any bracket, clip, spacer, linkage, or coupling associated with the Throttle.

Make sure each supporting piece is seated correctly before final tightening.



7. Install the retaining hardware for the Throttle

Install the Throttle mounting hardware by hand first and seat the part evenly against its bracket or panel.

Check that the component remains aligned while the hardware is brought fully home.

Tighten the throttle bolt to **3 Nm**.



8. Verify the completed installation of the Throttle

Inspect the final position of the Throttle and confirm that all hardware, clips, and surrounding parts are back in place.

Check the component for correct fit and movement before returning the bike to service.



Torque Summary

Component	Torque
Tighten the throttle bolt	3 Nm

Verified torque items:

- Tighten the throttle bolt: **3 Nm** from the official Stark VARG owner manual torque table.

Critical Checks Before Riding

- Confirm the serviced component is fully seated and all fasteners are tightened in the correct order.
- Recheck all torque-critical hardware before riding.
- Make sure all routed cables, clips, brackets, and surrounding parts are returned to their original positions.
- Inspect the bike visually for any missing hardware before returning it to service.