

# Remove and Install Pull Rod - Stark VARG

Video link: <https://www.youtube.com/watch?v=yNa4CXP0EMk>

Source video: Remove and Install Pull Rod - Stark VARG by Stark Future Official

Applicable models: MX

## Scope

This guide follows the same step-by-step workshop structure as the MX tutorials, but it is derived as a visual sequence from the official Stark Future ASMR video. Because the source video does not provide usable captions or narration, the procedure is documented through curated screenshots and concise action guidance.

## Preparation

- Place the bike on a stable stand or work area before starting the procedure.
- Prepare the correct tools for the fasteners, clips, brackets, and components shown in the video.
- Keep removed hardware organized in sequence so reassembly follows the same order as the video.
- Have a torque wrench ready for any tightening steps that specify a torque value.

## Removal Procedure

### 1. Prepare access to the Pull Rod

Remove or move aside the surrounding part, cover, or hardware needed to reach the Pull Rod.

Keep the removed fasteners organized in sequence so reassembly matches the video.



## 2. Remove the visible retaining hardware for the Pull Rod

Remove the bolts, screws, nuts, or clips that directly secure the Pull Rod.

Support the component as the last fastener is removed.



## 3. Release any bracket, clip, or coupling attached to the Pull Rod

Free any bracket, clip, spacer, linkage, or connector that still ties the Pull Rod to the bike.

Note the orientation of these supporting pieces before setting them aside.



#### 4. Remove the Pull Rod from the bike

Lift, slide, or guide the Pull Rod out of its mounting position once the retaining hardware is removed. Inspect the removed part and the mounting points before reassembly.



### Installation Procedure

#### 5. Position the Pull Rod for installation

Return the Pull Rod to its mounting position and align the holes, tabs, or locating surfaces.

Hold the component in place until the first retaining hardware is started.



## 6. Reconnect or refit the support pieces for the Pull Rod

Reinstall any bracket, clip, spacer, linkage, or coupling associated with the Pull Rod.

Make sure each supporting piece is seated correctly before final tightening.



## 7. Install the retaining hardware for the Pull Rod

Install the main retaining hardware for the Pull Rod by hand first, then tighten it evenly.

Check that the component remains aligned while the hardware is brought fully home.

Tighten the pull rod nuts to **60 Nm**.



## 8. Verify the completed installation of the Pull Rod

Inspect the final position of the Pull Rod and confirm that all hardware, clips, and surrounding parts are back in place.

Check the component for correct fit and movement before returning the bike to service.



## Torque Summary

| Component                 | Torque |
|---------------------------|--------|
| Tighten the pull rod nuts | 60 Nm  |

Verified torque items:

- Tighten the pull rod nuts: **60 Nm** from the official Stark VARG owner manual torque table.

## Critical Checks Before Riding

- Confirm the serviced component is fully seated and all fasteners are tightened in the correct order.
- Recheck all torque-critical hardware before riding.
- Make sure all routed cables, clips, brackets, and surrounding parts are returned to their original positions.
- Inspect the bike visually for any missing hardware before returning it to service.