Single Cycle Processor

Madiba Hudson-Quansah

CONTENTS

CHAITERI	INSTRUCTIONS	F AGE 2	
1.1	R-Type Instructions Structure of R-Type Instructions — 2	2	
1.2	I-Type Instructions	3	
1.3	J-Type Instructions	3	
CHAPTER 2	Processor Design	Page 4	
2.1	Register Transfer Level (RTL)	4	
2.2	Data Path Components and Clocking Methodology	5	
	Data Path Components - 5 2.2.1.1 Pipelining 2.2.1.2 Out-of-order Execution 2.2.1.3 Speculative Execution Clocking Methodology - 6 2.2.2.1 Clock Skew	6	
Chapter 3	Instruction Type Data Paths	Page 7	
3.1	Control Signals	7	
3.2	R-Type Instructions	7	
3.3	I-Type Instructions	8	
3.4	J-Type Instructions	8	
CHAPTER 4	Limitations of Single Cycle Processors	PAGE 9	
4.1	Overcoming Limitations	10	
4.2	Multi-Cycle vs Pipelining	10	
4.3	Multi-Cycle Implementation	10	

Instructions

Each instruction in MIPS is the same size (32 bits). There are three types of instructions in MIPS:

- R-Type: Register, example add \$t0, \$t1, \$t2
- I-Type: Immediate, example addi \$t0, \$t1, 100
- J-Type: Jump, example j 1000

MIPS supports various addressing modes, including:

Immediate - Operand is a constant value embedded in the instruction itself. Example: addi \$t0, \$t1, 100

Register - Operand is stored in a register. Example: add \$t0, \$t1, \$t2

Base - Operand is stored in memory, and the address is calculated using a base register and an offset. Example: lw \$t0, 100(\$t1)

PC-Relative - Operand is stored in memory, and the address is calculated using the program counter (PC) and an offset. Example: beq \$t0, \$t1, 100

Pseudo-Direct - Operand is stored in memory, and the address is calculated using a pseudo-direct addressing mode. Example: j 1000

1.1 R-Type Instructions

Register operations. Arithmetic and logical operations directly on registers. MIPS defines 32 general purpose register each 32 bits wide. The registers are numbered from 0 to 31, with register 0 always being 0.

1.1.1 Structure of R-Type Instructions

opcode	rs	rt	rd	shamt	funct
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

For R-type instructions, the **opcode** field is always 0, i.e. 000000 as the **funct** determines the operation type. This is only for R-type instructions. Where:

opcode The operation code. Used to specify the operation.

- **rs** The source register. Used to store the first operand.
- rt The target register. Used to store the second operand.
- **rd** The destination register. Used to store the result of the operation.

shamt The shift amount. Used to specify the number of bits to shift.

funct The function code. Used to specify the operation, example **add**, **sub**, **and**, **or**, etc.

1.2 I-Type Instructions

Memory access and immediate values.

opcode	rs	rt	immediate
6 bits	5 bits	5 bits	16 bits

Where:

opcode The operation code. Used to specify the operation.

rs The source register. Used to store the register operand

rt The target register. The desination register.

immediate The immediate value. Used to store the immediate value operand

1.3 J-Type Instructions

Branching and jumping.

opcode	address
6 bits	26 bits

Where:

opcode The operation code. Used to specify the operation.

address The address. Target address of the jump.

Processor Design

In designing a processor for an ISA one goes through the following steps

Analyse the Instruction Set - To determine data path requirements and control signals

Select Data path components and clocking methodology - Based on the instruction set

Assemble the datapath meeting the requirements

Analyse the implementation of each instruction - To determine the needed control signals

Assemble the control logic - To generate the control signals

Taking into account only a subset of the MIPS instructions:

ALU Instructions (R-Type) - add, sub, and, or, slt

Immediate Instructions (I-Type) - addi, lw, sw, beq

Load and Store (I-Type) - lw, sw

Branch (I-Type) - beq, bne

Jump (J-Type) - j

2.1 Register Transfer Level (RTL)

Definition 2.1.1: Register Transfer Level (RTL)

A description of data flow between registers in a processor. It is a way of describing the implementation of a processors instructions at the register level.

Instructions are first fetched from memory using the **Program Counter (PC)** to get the address. The instruction is then decoded to determine the operation type and then executed using accordingly.

ADD - Reg (rd)
$$\leftarrow$$
 Reg (rs) + Reg (rt); $PC \leftarrow PC + 4$

In terms of processor design a hybrid Von-Nuemann Harvard architecture is used, where instruction memory is separate from data memory. In terms of MIPS there are 31 general purpose registers each 32-bit wide with R0 always being 0. The program counter is stored in the PC registers and an adder is used to increment the PC.

2.2 Data Path Components and Clocking Methodology

2.2.1 Data Path Components

Definition 2.2.1: Data Path

The part of the processor that is responsible for executing instructions by performing arithmetic operations, data movement and logical operations.

The data path is made up of the following components:

Registers - Small fast memory within the processor. Used to store data temporarily during execution. Registers can include

General Purpose Registers - Used to hold data and intermediate results during execution

Special-Purpose Registers - Used for specific purposes such as keeping track of the program counter (PC), instruction register (IR), stack pointer (SP), status flags, etc.

Arithmetic Logic Unit (ALU) - Performs arithmetic and logical operations on data. Arithmetic operations include addition, subtraction, multiplication and logical operations include AND, OR, NOT, XOR, etc.

Data Paths - The connections between registers, the ALU and other functional units of the processor.

Memory Interface - Enables communication between the processor and system memory (RAM). Includes components such as the memory address register (MAR) for storing memory addresses, and memory data register (MDR) for storing data read from or written to memory.

Multiplexers and Demultiplexers - For selecting between multiple data paths between different components such as registers and ALUs based on control signals generated by the control unit

Buses - Communication pathways that transfer data and control signals between different components of the CPU and system memory. Buses include the data bus, address bus, and control bus.

Instruction Fetch and Decode Logic - The instruction fetch unit retrieves instructions from memory based on the program counter (PC) and send them to the instruction decode unit which decodes the instruction to determine appropriate operation to execute.

Pipeline Stages - The data path can also be divided in to pipeline stages to improve throughput and performance. Each pipeline stage performs a specific task such as instruction fetch, decode, execute, and write-back.

Cache Interface - For storing frequently accessed data and instruction closer to the CPU cores for faster access.

Control Signals - Generated by the control unit to coordinate the operation of different components within the data path. Control signals determine which operations are performed by the ALU, which data paths are selected and when data is transferred between registers and memory.

The design of the Data path is critical to processor design as it determines how fast the processor can execute instructions and how efficiently it can perform computations. It must be optimized to ensure that instructions are executed correctly and efficiently while minimizing latency and maximizing throughput. Modern processors employ complex data paths with some of the following features:

- Pipelining
- · Out-of-order execution
- Speculative execution

2.2.1.1 Pipelining

Definition 2.2.2: Pipelining

The execution of an instruction is broken down into multiple stages, i.e. fetch, decode, etc, then stages of instruction execution are executed in an overlapping manner allowing multiple instructions to executed simultaneously.

2.2.1.2 Out-of-order Execution

Definition 2.2.3: Out-of-order Execution

Instructions are executed in an order different from the order they appear in the program, based on data dependencies and resource availability. This allows the processor to execute instructions more efficiently by avoiding stalls and keeping the execution units busy.

2.2.1.3 Speculative Execution

Definition 2.2.4: Speculative Execution

The processor executes instructions under an execution branch before the result of the branch is known, i.e. if the branch is taken or not. This potentially allows the processor to be more performant by executing instructions that are likely to be executed.

2.2.2 Clocking Methodology

Definition 2.2.5: Clocking Methodology

The method used to synchronize the operations of the different components of the processor. This defines when data can be written to and read from.

We assume edge-triggered clocking where all state changes happen on the same clock edge. Data must be valid and stable before the clock edge and the output must be valid after the clock edge. Edge-trigged clocking allows data to be read and written during the same clock cycle, for example data could be read during the rising edge and written during the falling edge.

With edge-triggered clocking the clock cycle must be long enough to allow all operations to complete, therefore the clock cycle speed is determined by the time taken by slowest instruction. This shown by the equation:

$$T_{\text{cycle}} \geqslant T_{\text{clk-q}} + T_{\text{max comb}} + T_{s}$$

Where:

 T_{cycle} - The clock cycle time

 $T_{
m clk}\,$ - The clock to output delay through register, i.e time taken for data to be read from a register

 $T_{\text{max_comb}}$ - The longest delay through combinatorial logic, i.e. the longest time taken for data to be processed (instruction execution)

 T_s - Setup time, the time data must be stable before the clock edge

 T_h - Hold time, the time data must be stable after the clock edge, normally satisfied since $T_{clk-q} > T_h$

2.2.2.1 Clock Skew

Definition 2.2.6: Clock Skew

The absolute difference in time between when two storage elements see a clock edge.

Clock skew arises from the fact that the clock signal uses different paths each with differing delays to reach state elements, like flip-flops. This has to be accounted for to ensure that the cycle time can accommodate all read and write operation irrespective of the time the registers they are clocked. This results in the new equation:

$$T_{\text{cycle}} \ge T_{\text{clk-q}} + T_{\text{max comb}} + T_s + T_{\text{skew}}$$

This skew amount can however be minimized by balancing the clock delays to all storage elements.

Instruction Type Data Paths

3.1 Control Signals

The MIPS ISA defines the following control signals:

IsJAL - Used when the instruction is a Jump and Link instruction, which saves the return address in the link register.

IsShamt - Determines if the instruction is a shift operation which requires the shamt field to be used.

ALUSrc - Chooses whether the second operand for the ALU comes from a register (rt) or an immediate value.

IsSyscall - Determines whether the instruction is a system call.

ExtOp - Determines whether the immediate value should be zero-extended or sign-extended.

MemRead - Controls whether memory should be read to.

Jump - Determines whether the instruction is a jump instruction.

Branch - Determines whether the instruction is a branch instruction.

RegDst - Determines whether the destination register comes from rt (I-type) or rd (R-type).

IsJR - Determines whether the instruction is a jump register instruction, which jumps to the address in a register.

ReadRS/ReadRT - Determines whether the instruction should read from the source register (rs) or target register (rt).

 $\label{eq:allower} \textbf{ALUOp} \ \ \textbf{-} \ \textbf{Determines} \ \ \textbf{the operation to be performed by the ALU, such as addition, subtraction, logical AND, etc.}$

RegWR - Determines whether the instruction should write to a register.

3.2 R-Type Instructions

For R-type instructions the datapath is as follows:

- **IF** The instruction is fetched from instruction memory (ROM) using the program counter and stored in the instruction register (IR).
- **ID** The instruction is decoded by the control unit to determine the operation type and the destination (rd) and operand registers (rs and rt). At this stage these are the control signals activated:
 - **ALUOp** As opcode is 0, the ALUOp is determined by the funct field of the instruction.
 - **ALUSrc** The second operand for the ALU comes from the register file (rt)
 - **RegDst** The destination register comes from the *rd* field of the instruction.
 - RegWR Enables writing of the ALU result.
- **EX** The ALU performs the operation specified by the ALUOp.

WB - The result of the ALU operation is written back to the destination register (rd) in the register file.

3.3 I-Type Instructions

For I-type instructions the datapath is as follows:

- **IF** The instruction is fetched from instruction memory (ROM) using the program counter and stored in the instruction register (IR).
- **ID** The instruction is decoded by the control unit to determine the operation type op, and the destination (rt), operand register (rs) and immediate value. At this stage these are the control signals activated:
 - **ALUOp** The ALUOp is determined by the opcode field of the instruction.
 - ALUSrc The second operand for the ALU comes from the immediate value.
 - **RegDst** The destination register comes from the rt field of the instruction.
 - **RegWR** Enables writing of the ALU result.
 - **ExtOp** Determines whether the immediate value should be zero-extended or sign-extended as the 16-bit immediate value needs to be extended to 32 bits for ALU operations.
- **EX** The ALU performs the operation specified by the ALUOp using the immediate value and the value in the rs register.
- MEM Activated depending on the type of instruction, i.e. load/store instructions
 - **Load** The memory address is computed by adding the immediate value to the value in the rs register. The data is then read from memory and stored in the rt register.
 - **Store** The memory address is computed by adding the immediate value to the value in the rs register. The data from the rt register is then written to memory.
 - **Branch** The branch target address is computed by adding the immediate value to the program counter (PC). The branch is taken if the condition is met.
- **WB** The result of the ALU operation is written back to the destination register (rt) in the register file.

3.4 J-Type Instructions

For J-type instructions the datapath is as follows:

- **IF** The instruction is fetched from instruction memory (ROM) using the program counter and stored in the instruction register (IR).
- ID The instruction is decoded by the control unit to determine the operation type op, and the target address. At this stage these are the control signals activated:
 - **Jump** The jump target address is computed by shifting the 26-bit address left by 2 bits and then concatenating with the upper 4 bits of PC + 4
 - **IsJAL** Determines whether the instruction is a jump and link instruction, which saves the return address in the link register.
- **EX** The new program counter (PC) is computed by adding the jump target address to the current program counter (PC), depending on the type of jump instruction.

Limitations of Single Cycle Processors

Each instruction execution can be categorized into the following categories based on their common stages:

		ALU Inst	ruction Fetch	Decode / R	Register Re	ead ALU	Register W	Vrite	
Load	Instruc	tion Fetch	Decode / Ro	egister Read	Compute	e Address	Memory Re	ead Registe	er Write
	Store	Instruction	n Fetch De	code / Registe	er Read	Compute .	Address Me	emory Write	
	Branc	ch Instruc	ction Fetch	Register read	/ Branch	Target	Compare and	Update PC	
			Jump In	struction Fetc	h Deco	de / Updat	e PC		

With the Load instruction category being the slowest, meaning the cycle time must be long enough to accommodate the load instruction. This has several implications:

- **Clock Speed Constraint** The clock cycle time must be long enough to accommodate the longest instruction, i.e. the load instruction. This means that shorter instructions waste time waiting for the longer ones to complete and in the case where a shorter one completes before the cycle is over, the processor is idle for the rest of the cycle.
- **Resource Utilization** All resources such as ALUs, memory and registers are only used once per cycle. This means that the processor is not fully utilising its resources most of the time.
- **Complexity in Control** The control unit must manage all the operations in a single cycle increasing the complexity of design.
- **Power Consumption** Due to the need to complete all operations in a single cycle, the processor will need to consume more power drive all the functional units simultaneously.
- **Scalabity** As more instructions are added to the ISA, the cycle time will need to be adjusted to accommodate the longest instruction, placing a limit on the ability to scale the processor for better performance.
- **Peformance** Since the clock cycle time is constrained by the slowest instruction, the processor is not able to achieve the best performance by executing multiple instructions simultaneously.

4.1 Overcoming Limitations

To overcome the limitations of the single cycle processor, the following techniques can be employed:

Pipelining 2.2.1.1

Multi-Cycle Design - Breaks down an instruction execution into multiple stages, with each stage taking one cycle to execute. This allows the clock cycle time to be reduced as it is no longer constrained by the slowest instruction rather the slowest stage.

Superscalar Architecture - Involves the use of multiple execution units, i.e. multiple ALUs, allowing multiple instructions to be executed simultaneously. By fetching and dispatching multiple instructions per cycle, superscalar processors increase instruction throughput.

Out-of-order Execution 2.2.1.2

Branch Prediction and Speculative Execution - Predicts the outcome of a branch instruction before it is executed, allowing the processor to speculatively execute 2.2.1.3

Instruction Level Parallelism - Techniques such as loop unrolling, software pipelining, vectorization and instruction reordering can allow for more parallelism in instruction execution.

Caching - Improves performance by storing frequently accessed data and instructions closer to the processor cores reducing the latency of memory access.

Register Renaming - Dynamically allocates physical registers to logical registers, i.e. dynamically mapping concurrently used logical registers to avoid what is the hardware equivalent of a race condition, to avoid hazards and dependencies between instructions.

4.2 Multi-Cycle vs Pipelining

Feature	Multi-Cycle Processor Design	Pipelined Processor Design	
Execution Phases	Instructions are executed over several	Instructions are divided into stage	
	cycles in the form of stages	that overlap execution	
Hardware Utilization	Resources are reused across different	More hardware resources are needed	
	cycles for different stages	to execute multiple stages simultane-	
		ously	
Control Complexity	Complex control unit normally im-	Complex control logic needed to	
	plemented as a finite state machine	manage simultaneous execution of	
	(FSM)	multiple stages	
Cycle Time	Clock cycle time is determined by the	Clock cycle time is determined by the	
	slowest stage	longest stage	
Performance	Instructions are completed in several	Instruction throughput can approach	
	cycles, but each cycle is faster than in	one instruction per cycle due to stage	
	a single-cycle processor	overlapping	

4.3 Multi-Cycle Implementation

First break each instruction into five stages:

- Instruction Fetch (IF)
- Instruction Decode / Register Read or Target Address for jump/branch. (ID)
- Execution / Memory address computation or branch outcome. (EX)
- Memory Access / ALU instruction completion (MEM)
- Load instruction completion (WB)

Each stage takes one clock cycle to complete, i.e. the categories of instructions break down into the following cycle counts

- **ALU** 4
- Load 5
- Store -4
- Branch 3
- **Jump** 2

Example 4.3.1

Question 1

Assuming the following operation times for components:

- Access time for instruction and data memories is 200 ps
- Delay in ALU and adders is 180 ps
- Delay in decode and register file access (read or write) is 150 ps
- Ignore all other delays in PC, mux, extender, and wires

Which of the following designs would be faster and by how much?

- 1. Single cycle processor
- 2. Multi-cycle processor

Assume the following instruction mix: 40% ALU, 20% Load, 10% Store, 20% Branch, 10% Jump

Solution:

ALU -200 + 150 + 180 + 150 = 680ps

Load -200 + 150 + 180 + 200 + 150 = 880ps

Store -200 + 150 + 180 + 150 = 680ps

Branch -200 + 150 + 180 = 530ps

Jump -200 + 180 = 280ps

- 1. Each single cycle processor cycle has to be as long as the longest instruction, i.e. 880ps
- 2. Each multi cycle processor cycle has to be as long as the longest stage i.e. 200ps.

$$CPI = 0.4 \times 4 + 0.2 \times 5 + 0.1 \times 4 + 0.2 \times 3 + 0.1 \times 2$$

= 3.8

$$\therefore$$
 Clock Period = $3.8 \times 200 = 760$

$$\frac{880}{760} = 1.16$$

∴ the multi-cycle design is faster by about 16 %