

TABLE OF CONTENTS

1.	INS	ALLATION GU	JIDE	pg. 1
2.	LOG	pg. 2		
	2.1			
	2.2			
3.	MA	N MODULE_	pg. 3	
4.	USE	pg. 4		
	4.1	Creating Nev		
	4.2			
	4.3			
5.	SYS	pg. 4		
	5.1	General Sett		
		5.1.1 Tran	saction Type	
		5.1.2 Syste	em Unit Weight	
		5.1.3 Enak	ole Pricing	
		5.1.4 Enak	ole Ticket Printout	
		5.1.5 Indic	cator Type	
	5.2	Serial/Comn		
	5.3			
	5.4			
	5.5	Company Pr	ofile	
	5.6	Backup Data		
6.	DAT	ABASE MAIN	pg. 7	
	6.1			
	6.2			
	6.3			
7.	WEI	pg. 8		
	7.1	Creating Tra	nsaction	
	7.2	Reprinting o	f Weighing Ticket	
	7.3	Deleting Tra	nsaction	
8.	TRA	NSACTION M	ANAGEMENT	pg. 10
	8.1	EDITING TRA	INSACTION	
	8.2	DELETING TE	RANSACTION	
	8.3	REPRINTING	TRANSACTION	
9.	REP	pg. 12		
	9.1	Generating 9	Summary Reports	
	9.2	Setting the D	Date Range	
	9.3	Filter Panel		
	9.4	Printing and	Viewing Reports	

1. INSTALLATION GUIDE

STEP 1: Install Microsoft Office Application (2003 or higher version)


STEP 2: Install dotNetFx40_Full_x86_x64.exe

STEP 3: Install CRRuntime_32bit_13_0_8 .exe for 32 bit OS

STEP 4: Install Weighing System v1.1 Setup Just Click Next.

STEP9 (Optional): Install DTECH USB2SERIAL Driver if your machine doesn't have a built-in Communication Port.

STEP10: To Setup Weighng System Port Connection, follow the instruction below Device Manager Window



2. LOGIN FORM


2.1 LOG-IN TAB

Every user must enter the user name and password to access Weighing System. For fresh installed, user name is *admin* and password is *1*.




2.2 DATABASE CONNECTION TAB

In this Section, you can choose the database file (MDB file) that you want to use. Just Click edit and click to browse to the location of the DB File, type in database password then press.



3. MAIN MODULE


For Successful login and server connection, main module will appear.



Just Click Log out your account

4. USER CONTROL

Fig. 4a



4.1 CREATING NEW USER

Go to *MAIN MODULE-> ADMINISTRATION->User Accounts*. Just Click and enter your display name (Name that you want to appear on your weighing ticket), User name and password for your login account, Check the desired permission to the user then click save.

4.2 MODIFYING USER


To modify user, click and set your desired info and features then click

System will prompt you to logout the system to refresh changes made to your accont

4.3 REMOVING USER

To remove or delete user, highlight the row/s or user that you want to delete then click and click yes for confirmation. *Note: You cannot delete user that is currently logged-in.*

5. SYSTEM SETTINGS



5.1 GENERAL SETTINGS

5.1.1 TRANSACTION TYPE

- Single Weighing Enable this option if you want to use the software as a Single Weigh transaction.
- **In/Out Weighing** Enable this option if you want to use the software as a standard weigh-in and out transaction.

5.1.2 SYSTEM UNIT WEIGHT

- **Kg** Converts Weight Device Signal to Kilogram
- Tons Converts Weight Device Signal to Tons
- **5.1.3 ENABLE PRICING** To Enable Pricing, Just click Edit Button and check
 - **▼** Enable Pricing then click Save.
 - Unit Per Price

Per Kilogram - Computes Total Amount in Per Price per Kilo. **Per Tons** - Computes Total Amount in Per Price per Kilo.


5.1.4 ENABLE /DISABLE TICKET PRINTOUT - Enables/Disables Ticket Printout during Transaction.

- **Print In and Out Separatly** 2 printings will occur for every transaction. Inbound details will be printed separately to outbound details.
- **Print All details at Weigh-Out** Prints all details during Outbound only.
- **5.1.5 Indicator Type** Selection for Indicator that you are currently using. (GSE or Rinstrum Brand.)

5.2 SERIAL/COMM PORTS

- 5.3 DATABASE SETTINGS Same as section 2.2
- **5.4 REFERENCE SETTINGS** Lets you set your desired transaction reference no. To edit reference no. just click edit button, Type the desired reference from the textbox provided and click save.
- **5.5 COMPANY PROFILE** Lets you store a brief Information about your company such as Name and address with corresponding Photo.
- **5.6 BACKUP DATA** Creates a copy of your database(access file) for backup purposes.
 - To create a backup, just click BACKUP DATABASE, browse to the location where you want your database to be backuped then click save.

6. DATABASE/FILE MAINTENANCE



6.1 ADDING NEW DATA

- STEP 1: Under the Main Menu Window, Click

 Database/File Maintenance
- **STEP 2**: Click from the button where you want to add/modify/delete data.
- **STEP 3:** Just Scroll down to the empty row and type in the data that you want to add then press enter.

6.2 MODIFYING/EDITING DATA

REPEAT STEP 1 & 2

STEP 3: Just Scroll to the row of the data that you want to modify, just type in the changes then press enter.

6.3 DELETING/REMOVING DATA

REPEAT STEP 1 & 2

STEP 3: Just Scroll to the row of the data that you want to delete then press Delete button on your keyboard then press yes for message box confirmation that appeared.

7. WEIGHING TRANSACTIONS

Fig 7.1a





Fig 7.1b



7.1 CREATING TRANSACTION

STEP 1: Go to **TRANSACTION** -> **TRANSACTION**->**WEIGH-IN** (see Fig 7.1a).

STEP 2: Enter the Required field and wait for the Device weight to get stable then click SAVE or Click CANCEL to void transaction. A printout will occur if the In and Out printing is enabled in the system settings. Status window (see fig. 7.1b) will appear if saving is successful.

STEP 4: If an entry is ready for outbound then, select the entry from queue list to the left and click **WEIGH-OUT**

STEP 5: Wait again for the signal to get stable and click SAVE or CANCEL. You can edit your transaction data during outbound operation. . Status window will appear again if saving is successful. You can reprint again the Ticket by pressing Re-Print in the status window

NOTE:

- (A short cut button is provided to easily add or register Customer/Supplier or Commodity to your database.)
- If Weight Signal Panel turns Red, then the weight device connection is not successful or committed an error while connecting. An error message will appear below the buttons.

7.2 REPRINTING OF WEIGHING TICKET

Option 1:

Under the Status Window, Click re-print button and click yes to confirm re-printing of ticket. (For Inbound Only.)

Option 2:

STEP 1: Go to MAIN MENU->TRANSACTION-> MANAGEMENT.

STEP 2: Press Inbound if the needed record is a pending transaction and Outbound if it is a completed transaction. (You can Set date range to filter easily filter the record that you want to list.

STEP 3: Select the desired transaction record then click Re-Print button

7.3 DELETING TRANSACTION

Option 1:

Under the transaction window, select from the queue list, Press delete button and click yes to continue removing of transaction. (For Inbound Only.)

Option 2:

STEP 1: Go to MAIN MENU->TRANSACTION-> MANAGEMENT.

STEP 2: Press Inbound if the needed record is a pending transaction and Outbound if it is a completed transaction. (You can Set date range to filter easily filter the record that you want to list.

STEP 3: Select the desired transaction record and press delete button.

8. TRANSACTION MANAGEMENT

Fig 8a TRANSACTION MANAGENT MENU





Fig 8b TRANSACTION DETAILS



8.1 EDITING TRANSACTION

- **STEP 1:** To edit Inbound/Outbound transaction, go to *MAIN MODULE-> TRANSACTION-> MANAGEMENT (See fig. 7a)*
- **STEP 2:** Press Inbound if the needed record is a pending transaction and Outbound if it is a completed transaction. (You can Set date range to filter easily filter the record that you want to list.
- **STEP 3**: Select the desired transaction record then press VIEW DATA Button. A new window will Appear. See *Fig 8b*
- STEP 4: Press Edit Button to enable editing
- **STEP 5:** Change the desired changes then click save.

8.2 DELETING TRANSACTION

- **STEP 1:** To Delete Inbound/Outbound transaction, go to *MAIN MODULE-> TRANSACTION-> MANAGEMENT (See fig. 7a)*
- **STEP 2**: Press Inbound if the needed record is a pending transaction and Outbound if it is a completed transaction. (You can Set date range to filter easily filter the record that you want to list.
- **STEP 3:** Select the desired transaction record and press delete button.


8.3 REPRINTING TRANSACTION

(Make sure Print-out is enabled in the system settings)

- **STEP 1**: To reprint Inbound/Outbound transaction, go to *MAIN MODULE-> TRANSACTION-> MANAGEMENT (See fig. 7a)*
- **STEP 2:** Press Inbound if the needed record is a pending transaction and Outbound if it is a completed transaction. (You can Set date range to filter easily filter the record that you want to list.
- **STEP 3:** Select the desired transaction record then press Re-print button.

9. REPORTING

Fig. 9.1a



9.1 GENERATING SUMMARY REPORTS

To generate or make a summary reports, go to **MAIN MODULE-> REPORTING-> SUMMARY REPORTS.**

9.2 SETTING THE DATE RANGE

- 9.2.1 DATE RANGE Transaction date can be generated by Date In(Inbound date) or Date Out(outbound date) depending on your needs and can be sorted by the following fields
- **9.2.2 SORT BY** (*Date In, Date Out, Final Net, Reference No.*) Lets you select the fields where you want your report to be arranged.
- **9.2.3 ORDER BY** Report can be ordered in ascending, descending or original position.

9.3 FILTER PANEL

To enable filtering of reports, just check \square None and check also the desired filter category.

9.3.1 Transaction Type (*Not applicable to Single Weighing Transaction*)

O Inbound	Outbound	
INBOUI	ID – selecting this option will generate only pending transacti	on
ОИТВО	JND – selecting this option will generate only completed tran	saction
ALL – al	transaction type will be generated.	

9.3.2 Plate Number - just check By Plate # and type in the plate number that you want to filter.

- **9.3.3** Client to filter client, just check \square By Client , Selecting the \square Customer will list the registered customer in the dropdown box below same with selecting \square Supplier . After the listing, just select the desired client
- **9.3.4** Commodity to include commodity in the filter, just check and select the desired commodity name.
- **9.3.5 Driver** To also filter driver, just check \square By Driver and type in the driver name.

9.4 PRINTING AND VIEWING REPORTS

After settings the date range and the filter, just click to make the report appear or refresh in the preview panel. Just click if you are ready to print your report.

WEIGH SLIP FORMAT



REPORT FORMAT W/ PRICING

GENERAL LISTING REPORT TERRINNEL SCALES INCORPORATED 8388 DR. A SANTGS AVENUE PARAMAQUE CITY From: 06-05-2014 To: 06-05-2014 Becoipt No. Date Time In: Date Time Out: PlateNo Client Commodity DR No. Gross Tare Net Ded. Final Net Unit Price Total Arm. Weigher-Out: 50000178 060574 1151 060574 1151 AEC 412 TS: MW 12604721 230274 KG 1227 KG 1280 KG 550 7626550 MCN4ES, A FANICA TOTAL: 37.137 KG 15.396 MG 21,741 KG 21,741 KG 21,741 KG 21,741 KG 21,741 KG TOTAL: 37.137 KG 15.396 MG 21,741 KG 21,741 KG 21,741 KG MICHAEL A FANICA Prepared by:

NO PRICING

GENERAL LISTING REPORT TERRINIEL SCALES INCORPORATED 8368 DR. A SANTOS AVENUE, PARANAQUE CITY													
rom: 0 6-	05-2014 To:	06-05-2014											
eceipt No.	Date Time In	Date Time Out	PlateNo	Client		Commodity	DR No.	Gross	Tare	Net	Ded.	Final Net	Weigher-Out
		06/05/14 11:53	ABC 412	TSI		MW	124004721	23,074 KG	10,273 KG	12,801 KG	0.00%	12,801 KG	MICHAEL A. FAINZA
0000178	06/05/14 11:51							44.053.85	E 400 KG	0.040.05			
000178	06/05/14 11:51 06/05/14 13:08	06/05/14 13:08	ABC 412	KERBING		METAL SCRAP	12419123	14,063 KG	5,123 KG	8,940 KG	0.00%	8,940 KG	MICHAEL A. FAINZA

MICHAEL A. FAINZA