

TABLE OF CONTENTS

1.	INSTALLATION GUIDE	pg. 1
2.	LOG-IN FORM	pg. 2
	2.1 Login Tab	
	2.2 Server Connection Tab	
3.		
4.		pg. 4
	4.1 Creating New User	
	4.2 Modifying User	
	4.3 Removing User	
5.	SYSTEM SETTINGS pg. 4	
	5.1 General Settings	
	5.1.1 Transaction Type	
	5.1.2 System Unit Weight	
	5.1.3 Enable Pricing	
	5.1.4 Enable Ticket Printout	
	5.1.5 Indicator Type	
	5.2 Serial/Comm Ports	
	5.3 Database Settings	
	5.4 Reference Settings	
	5.5 Company Profile	
	5.6 Backup Data	
6.	DATABASE MAINTENANCE pg. 7	
	6.1 Adding New Data	
	6.2 Modifying/Editing Data	
	6.3 Deleting/Removing Data	
7.	WEIGHING TRANSACTIONS pg. 8	
	7.1 Creating Transaction	
	7.2 Reprinting of Weighing Ticket	
	7.3 Deleting Transaction	
8.	TRANSACTION MANAGEMENT pg. 10	
	8.1 EDITING TRANSACTION	
	8.2 DELETING TRANSACTION	
	8.3 REPRINTING TRANSACTION	
9.	REPORTING pg. 12	

- 9.1 Generating Summary Reports
- 9.2 Setting the Date Range
- 9.3 Filter Panel
- 9.4 Printing and Viewing Reports

1. INSTALLATION GUIDE

STEP 1: Install Microsoft Office Application (2003 or higher version)


STEP 2: Install dotNetFx40_Full_x86_x64.exe

STEP 3: Install CRRuntime_32bit_13_0_8 .exe for 32 bit OS STEP

4: Install Weighing System v1.1 Setup Just Click Next.

STEP9 (Optional): Install DTECH USB2SERIAL Driver if your machine doesn't have a built-in Communication Port.

STEP10: To Setup Weighng System Port Connection, follow the instruction below Device Manager Window



2. LOGIN FORM

2.1 LOG-IN TAB

Every user must enter the user name and password to access Weighing System. For fresh installed, user name is *admin* and password is *1*.



2.2 DATABASE CONNECTION TAB

In this Section, you can choose the database file (MDB file) that you want to use. Just Click


to edit and click
File, type press.

browse to the location of the DB in database password then



3. MAIN MODULE


For Successful login and server connection, main module will appear.



Just Click Log out your account

4. USER CONTROL

Fig. 4a



4.1 CREATING NEW USER

Go to *MAIN MODULE-> ADMINISTRATION->User Accounts*. Just Click and enter your display name (Name that you want to appear on your weighing ticket), User name and password for your login account, Check the desired permission to the user then click

4.2 MODIFYING USER


To modify user, click and set your desired info and features then click

System will prompt you to logout the system to refresh changes made to your accont

4.3 REMOVING USER

To remove or delete user, highlight the row/s or user that you want to delete then click and click yes for confirmation. *Note: You cannot delete user that is currently logged-in.*

5. SYSTEM SETTINGS



5.1 GENERAL SETTINGS

5.1.1 TRANSACTION TYPE

- **Single Weighing** Enable this option if you want to use the software as a Single Weigh transaction.
- In/Out Weighing Enable this option if you want to use the software as a standard weigh-in and out transaction.


5.1.2 SYSTEM UNIT WEIGHT

- Kg Converts Weight Device Signal to Kilogram
- Tons Converts Weight Device Signal to Tons
- **5.1.3 ENABLE PRICING** To Enable Pricing, Just click Edit Button and check
 - Enable Pricing then click Save.
 - Unit Per Price

Per Kilogram - Computes Total Amount in Per Price per Kilo. **Per Tons** - Computes Total Amount in Per Price per Kilo.

- **5.1.4 ENABLE /DISABLE TICKET PRINTOUT** Enables/Disables Ticket Printout during Transaction.
 - **Print In and Out Separatly** 2 printings will occur for every transaction. Inbound details will be printed separately to outbound details.
 - Print All details at Weigh-Out Prints all details during Outbound only.
- **5.1.5 Indicator Type** Selection for Indicator that you are currently using. (GSE or Rinstrum Brand.)
- **5.2 SERIAL/COMM PORTS**
- **5.3 DATABASE SETTINGS** Same as section **2.2**
- **5.4 REFERENCE SETTINGS** Lets you set your desired transaction reference no. To edit reference no. just click edit button, Type the desired reference from the textbox provided and click save.
- **5.5 COMPANY PROFILE** Lets you store a brief Information about your company such as Name and address with corresponding Photo.
- **5.6 BACKUP DATA** Creates a copy of your database(access file) for backup purposes.
 - To create a backup, just click BACKUP DATABASE, browse to the location where you want your database to be backuped then click save.

6. DATABASE/FILE MAINTENANCE



6.1 ADDING NEW DATA

STEP 1: Under the Main Menu Window, Click



- **STEP 2**: Click from the button where you want to add/modify/delete data.
- **STEP 3:** Just Scroll down to the empty row and type in the data that you want to add then press enter.

6.2 MODIFYING/EDITING DATA

REPEAT STEP 1 & 2

STEP 3: Just Scroll to the row of the data that you want to modify, just type in the changes then press enter.

6.3 DELETING/REMOVING DATA

REPEAT STEP 1 & 2

STEP 3: Just Scroll to the row of the data that you want to delete then press Delete button on your keyboard then press yes for message box confirmation that appeared.

7. WEIGHING TRANSACTIONS

Fig 7.1a





Fig 7.1b



7.1 CREATING TRANSACTION

STEP 1: Go to **TRANSACTION** -> **TRANSACTION**->**WEIGH-IN** (see Fig 7.1a).

STEP 2: Enter the Required field and wait for the Device weight to get stable then click SAVE or Click CANCEL to void transaction. A printout will occur if the In and Out printing is enabled in the system settings. Status window (see fig. 7.1b) will appear if saving is successful.

STEP 4: If an entry is ready for outbound then, select the entry from queue list to the left and click **WEIGH-OUT**

STEP 5: Wait again for the signal to get stable and click SAVE or CANCEL. You can edit your transaction data during outbound operation. . Status window will appear again if saving is successful. You can reprint again the Ticket by pressing Re-Print in the status window

NOTE:

- (A short cut button is provided to easily add or register Customer/Supplier or Commodity to your database.)
- If Weight Signal Panel turns Red, then the weight device connection is not successful or committed an error while connecting. An error message will appear below the buttons.

7.2 REPRINTING OF WEIGHING TICKET

Option 1:

Under the Status Window, Click re-print button and click yes to confirm re-printing of ticket. (For Inbound Only.)

Option 2:

STEP 1: Go to MAIN MENU->TRANSACTION-> MANAGEMENT.

STEP 2: Press Inbound if the needed record is a pending transaction and Outbound if it is a completed transaction. (You can Set date range to filter easily filter the record that you want to list.

STEP 3: Select the desired transaction record then click Re-Print button

7.3 DELETING TRANSACTION

Option 1:

Under the transaction window, select from the queue list, Press delete button and click yes to continue removing of transaction. (For Inbound Only.)

Option 2:

STEP 1: Go to MAIN MENU->TRANSACTION-> MANAGEMENT.

STEP 2: Press Inbound if the needed record is a pending transaction and

Outbound if it is a completed transaction. (You can Set date range to filter easily filter the record that you want to list.

STEP 3: Select the desired transaction record and press delete button.

8. TRANSACTION MANAGEMENT

Fig 8a TRANSACTION MANAGENT MENU





Fig 8b TRANSACTION DETAILS



8.1 EDITING TRANSACTION

- **STEP 1:** To edit Inbound/Outbound transaction, go to *MAIN MODULE-> TRANSACTION-> MANAGEMENT (See fig. 7a)*
- **STEP 2:** Press Inbound if the needed record is a pending transaction and Outbound if it is a completed transaction. (You can Set date range to filter easily filter the record that you want to list.
- **STEP 3**: Select the desired transaction record then press VIEW DATA Button. A new window will Appear. See *Fig 8b*
- STEP 4: Press Edit Button to enable editing
- **STEP 5:** Change the desired changes then click save.

8.2 DELETING TRANSACTION

- **STEP 1:** To Delete Inbound/Outbound transaction, go to *MAIN MODULE-> TRANSACTION-> MANAGEMENT (See fig. 7a)*
- **STEP 2**: Press Inbound if the needed record is a pending transaction and Outbound if it is a completed transaction. (You can Set date range to filter easily filter the record that you want to list.
- **STEP 3:** Select the desired transaction record and press delete button.


8.3 REPRINTING TRANSACTION

(Make sure Print-out is enabled in the system settings)

- **STEP 1**: To reprint Inbound/Outbound transaction, go to *MAIN MODULE-> TRANSACTION-> MANAGEMENT (See fig. 7a)*
- STEP 2: Press Inbound if the needed record is a pending transaction and Outbound if it is a completed transaction. (You can Set date range to filter easily filter the record that you want to list.
- **STEP 3:** Select the desired transaction record then press Re-print button.

9. REPORTING

Fig. 9.1a



9.1 GENERATING SUMMARY REPORTS

To generate or make a summary reports, go to **MAIN MODULE-> REPORTING-> SUMMARY REPORTS.**

9.2 SETTING THE DATE RANGE

- 9.2.1 DATE RANGE Transaction date can be generated by Date In(Inbound date) or Date Out(outbound date) depending on your needs and can be sorted by the following fields
- **9.2.2 SORT BY** (*Date In, Date Out, Final Net, Reference No.*) Lets you select the fields where you want your report to be arranged.
- **9.2.3 ORDER BY** Report can be ordered in ascending, descending or original position.

9.3 FILTER PANEL

To enable filtering of reports, just check have and check also the desired filter category.

9.3.1 Transaction Type (Not applicable to Single Weighing Transaction)

	-			
() Inbound		Outbound	()	ΔII

INBOUND – selecting this option will generate only pending transaction
 OUTBOUND – selecting this option will generate only completed transaction
 ALL – all transaction type will be generated.

9.3.2	Plate Number - just check By Plate and type in the plate number that you want to filter.
9.3.3	Client - to filter client, just check ☐ By Client, Selecting ☐ Customer will list the
	the registered customer in the dropdown box below
	same with selecting .
	After the listing, just select the desired client
9.3.4	$ \begin{tabular}{ll} \textbf{Commodity} - to include commodity in the filter, just check & \square & By & $Commodity and select the desired commodity name. \\ \end{tabular} $
9.3.5	Driver - To also filter driver, just check \square By Driver and type in the driver name.
9.4 PRINT	ING AND VIEWING REPORTS
After setting	gs the date range and the filter, just click to make the report
• •	or refresh in the preview panel. Just click if you are print your report.

WEIGH SLIP FORMAT

TRUCKSCALE TICKET

Print Time: Aug-20-2018 09:35:49AM TERRINIEL SCALES INC.

PARANAQUE

00000003

Client : 222 Address : 111 Commodity : DDD

Weigh-in

Date In : 05/10/17 09:46 AM

Plate # In : 3123

Inbound Wt.: 31,200 KG

Weigh-Out

Date Out : 07/11/18 10:24 AM

Gross Wt. : 31,200 KG

Tare Wt. : 1,000 KG

Net Wt. : 30,200 KG

DR# : 111 TKT # : Operator : WEIGHER 1

Driver Remarks

REPORT FORMAT W/ PRICING

GENERAL LISTING REPORT TERRINIEL SCALES INCORPORATED 8368 DR. A SANTOS AVENUE, PARANAQUE CITY From: 06-05-2014 To: 06-05-2014 Client Net Ded. Final Net Unit Price Total Amt. Weigher-Out Receipt No. Date Time In Date Time Out PlateNo DR No. 00000178 06/05/14 11:51 06/05/14 11:53 ABC 412 124004721 23,074 KG 10,273 KG 12,801 KG 0.00% 12,801 KG 5.50 70,405.50 MICHAEL A. FAINZA 00000179 06/05/14 13:08 06/05/14 13:08 ABC 412 KERBING METAL SCRAP 12419123 14,063 KG 5,123 KG 8,940 KG 0.00% 8,940 KG 5.23 46,756.20 MICHAEL A. FAINZA 37,137 KG 21,741 KG 117,161.70 Prepared by:

NO PRICING

GENERAL LISTING REPORT TERRINIEL SCALES INCORPORATED

8368 DR. A SANTOS AVENUE, PARANAQUE CITY

From: 06-05-2014 To: 06-05-2014

Receipt No.	Date Time In	Date Time Out	PlateNo	Client		Commodity	DR No.	Gross	Tare	Net	Ded.	Final Net Weigher-Out
00000178	06/05/14 11:51	06/05/14 11:53	ABC 412	TSI		MW	124004721	23,074 KG	10,273 KG	12,801 KG	0.00%	12,801 KG MICHAEL A. FAINZA
00000179	06/05/14 13:08	06/05/14 13:08	ABC 412	KERBING		METAL SCRAP	12419123	14,063 KG	5,123 KG	8,940 KG	0.00%	8.940 KG MICHAEL A. FAINZA
					TOTAL:			37,137 KG	15,396 KG	21,741 KG		21,741 KG

MICHAEL A. FAINZA
Prepared by: