Maintenance Procedure No. P134

Page 1 of 1

TASK DESCRIPTION

CLEAN RADIATOR CORE AIR PASSAGES - MAIN AND HEP ENGINE

BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS

GM Locomotive F- 59H Service Manual

SPECIAL TOOLS REQUIRED:

Air hose equipped with pressure reduction, a pipe nozzle and a flexible rubber tip extension.

RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.

SAFETY PRECAUTIONS:

CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.

PREPARATION:

- 1) Secure locomotive from movement
- 2) Shut main engine down and apply "DO NOT START" tag.

PROCEDURE

- 1 Main engine to be shut down and "DO NOT START" tag applied.
- 2 Spray a solution of a mixture of mild alkaline solution and water through the fan blades and guards of the cooling fans onto the main and HEP engine radiators until foreign material is removed.
- 3 Rinse with water.

Note: Do not use a high-pressure machine.

Ensure all access manhole covers are securely in place.

4 Report all work completed and notify supervisor of any discrepancies.

DATE OF FIRST ISSUE	May 1997	AUTHORIZED BY:
REVISION 1	September 2006	TITLE: Manager, Rail Equipment