TASK DESCRIPTION

COMPANION ALTERNATOR CABLES AND TERMINAL BOARDS INPECTION

BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS

MPI LOCOMOTIVE MAINTENANCE MANUAL, SECTION 8

SPECIAL TOOLS REQUIRED:

RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.


SAFETY PRECAUTIONS:

CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.

PREPARATION:

PROCEDURE

- 1. Ensure tightness of all mechanical and electrical connections. Cable connections to the terminal board should be intact.
- 2. Use dry cloths to wipe away any accumulation of dirt.



DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 1	August 2009	TITLE: Manager, Rail Equipment