Maintenance Procedure No. MP1335

Page 1 of 1

TASK DESCRIPTION			
OBTAIN HEP COOLANT SAMPLE FOR LAB ANALYSIS.			
BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS			
MP40PH-3C Head End Power MAINTENANCE MANUAL, CATERPILLAR MAINTENANCE MANUAL C27			
SPECIAL TOOLS REQUIRED:			
RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.			
RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.			
RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.			
RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC. SAFETY PRECAUTIONS:			
SAFETY PRECAUTIONS:			

PROCEDURE

- 1. Ensure that the engine is warm and running.
- 2. Relieve pressure by slowly opening then closing manual vent valve.
- 3. Obtain coolant sample from petcock on bottom of expansion tank sight gauge.
- 4. Fill out entire label on sample bottle being careful to include engine hours, locomotive number, and engine serial number.

DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 2	November 16, 2009	TITLE: Manager, Rail Equipment