Maintenance Procedure No. MP1010

Page 1 of 1

| TASK DESCRIPTION | | | |
|---|--|--|--|
| CHECK NOSE | | | |
| BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS | | | |
| MPI LOCOMOTIVE MAINTENANCE MANUAL, SECTION 10 | | | |
| SPECIAL TOOLS REQUIRED: | | | |
| | | | |
| RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC. | | | |
| | | | |
| | | | |
| SAFETY PRECAUTIONS: | | | |
| SAFETY PRECAUTIONS: CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE. | | | |
| | | | |

PROCEDURE

- 1. Check bolts and nuts fastening the nose to the locomotive frame.
- 2. If loose, remove nuts and apply liquid Locktite No. 242 (blue).
- 3. Tighten loose bolts and nuts to 150 ft-lbs.

| DATE OF FIRST ISSUE | September 2007 | AUTHORIZED BY: |
|---------------------|----------------|--------------------------------|
| REVISION 1 | August 2009 | TITLE: Manager, Rail Equipment |