Maintenance Procedure No. MP565

Page 1 of 1

TASK DESCRIPTION		
CHECK SOAK BACK PUMP AND MOTOR OPERATION		
BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS		
MPI LOCOMOTIVE MAINTENANCE MANUAL, SECTION 5		
SPECIAL TOOLS REQUIRED:		
RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.		
SAFETY PRECAUTIONS:		
SAFETY PRECAUTIONS:		

PROCEDURE

- 1. With the engine shut down and the soak back pump motor running remove the left rear handhole cover.
- 2. Oil flow should be seen throughout gear train.
- 3. Observe camshaft bearings. Lube oil flowing from the camshaft bearings indicates a faulty turbocharger filter outlet check valve.

DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 1	August 2009	TITLE: Manager, Rail Equipment