Maintenance Procedure No. MP684

Page 1 of 1

TASK DESCRIPTION			
INSPECT AND TEST OPERATION OF SAND CONTROL VALVE			
BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS			
MPI LOCOMOTIVE MAINTENANCE MANUAL, SECTION 6			
SPECIAL TOOLS REQUIRED:			
RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.			
SAFETY PRECAUTIONS:			
CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.			
PREPARATION:			

PROCEDURE

- 1. Inspect the electrical connections for tightness.
- 2. Inspect the air connection for leaks.
- 3. Push in the plungers on each side of the clean-out jets to clean out the orifice. The plunger will automatically reset at the beginning of the next sanding cycle from the high-pressure clean-out blast of air.

DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 1	August 2009	TITLE: Manager, Rail Equipment