

# Faculty of Engineering & Technology Electrical & Computer Engineering Department

# **Communication Lab - ENEE4113**

# Experiment 1: Normal Amplitude Modulation and Demodulation Prelab #1

Student Name: Maha Maher Mali

**Student ID**: 1200746

Instructor: Dr. Ashraf Al Rimawi

Teacher Assistant: Eng. Mohammed Battat

Section: 4

**Date**: 2-8-2023

# Contents

Theoretical Prelab	3
Definition Normal Amplitude Modulation (AM)	3
Mathematical Representation of AM	3
Frequency Spectrum of AM signal	4
Demodulation of an AM Signal	4
Software Prelab	3
Message signal	3
Plot Message signal in Time Domine	3
Plot Message signal in Frequency Domine	3
Carrier signal	4
Plot Carrier signal in Time Domine	4
Plot Carrier signal in Frequency Domine	5
When (µ=1)	6
Calculate the value of ka	6
Mathematical Representation of AM Signal in Time Domain	6
Mathematical Representation of AM Signal in Frequency Domain	6
Build The Diagram When Modulation Index =1 ( $\mu$ =1) Step by Step	7
When (µ=0.5)	15
Calculate the value of ka	15
Mathematical Representation of AM Signal in Time Domain	15
Build The Diagram When Modulation Index =0.5 ( $\mu$ =0.5) Step by Step	15
When (µ=1.5)	21
Calculate the value of ka	21
Mathematical Representation of AM Signal in Time Domain	21
Build The Diagram When Modulation Index =0.5 ( $\mu$ =0.5) Step by Step	22
References	28

# **Table of Figures**

Figure 1: Message signal in time domain	3
Figure 2: spectrum of message signal	4
Figure 3 :carrier signal in time domain	4
Figure 4: carrier signal in frequency domain	5
Figure 5: General Modulation	7
Figure 6: Modulation Block Diagram for μ=1	7
Figure 7: properties of m(t)	8
Figure 8: properties of c(t)	8
Figure 9: s(t) in time domain	8
Figure 10: modulation block with spectrum analyzer	9
Figure 11: Spectrum for modulated signal (u=1)	9
Figure 12: General Coherent Demodulation.	10
Figure 13: Demodulation Block Diagram for μ=1	11
Figure 14: coherent demodulation output in time domain	11
Figure 15: coherent demodulation output in frequency domain	12
Figure 16: Envelope detector demodulation general formula	13
Figure 17: Envelope detector demodulation output in time domain	14
Figure 18: Envelope detector demodulation output in frequency domain	14
Figure 19: block diagram for case 2 (u=0.5)	16
Figure 20: s(t) in time domine	16
Figure 21: diagram to plot spectrum	17
Figure 22: Spectrum for modulated signal (u=0.5)	17
Figure 23: Coherent demodulation block diagram	18
Figure 24: Coherent demodulation in time domine	18
Figure 25: Coherent demodulation in frequency domine	19
Figure 26: Envelope detector demodulation block digram when (u=0.5)	
Figure 27: Envelope detector demodulation in time domine	20
Figure 28: Envelope detector demodulation in frequncy domine	20
Figure 29: Block diagram for μ=1.5	22
Figure 30:s(t) in time domine	23
Figure 31:s(f) in frequency domine	24
Figure 32: Coherent demodulation block digram	24
Figure 33: s(t) in time domine	25
Figure 34: s(F) in frequency domine	25
Figure 35: Envelope detector demodulation	26
Figure 36: s(t) in time domine	26
Figure 37: s(f) in frequency domine	27

# Theoretical Prelab Definition Normal Amplitude Modulation (AM)

Is the process of varying the amplitude of a sinusoidal carrier wave in synchronism with, and in direct proportion, to the amplitude of a modulating signal.[1]

## Mathematical Representation of AM

$$s(t) = A_c (1 + K_a m(t)) \cos(2\pi f_c t)$$

### Where:

• Ac: The amplitude of carrier signal

• fc: The frequency of carrier signal

• m(t): Message signal

• ka: The amplitude sensitivity

AM transmitters vary the amplitude of the carrier wave:

- The amplitude of the carrier wave is proportional to the amplitude of the signal being modulated.[2]
- If the modulation signal frequency increases, the amplitude of the carrier changes at a greater rate.[2]
- If the modulation signal frequency increases, the sidebands move further from the carrier. [2]

# Frequency Spectrum of AM signal

The frequency spectrum of an AM signal can be obtained using Fourier analysis, and it is given by:

$$s(f) = \frac{A_c k_a}{2} [M(f - f_c) + M(f + f_c)] + \frac{Ac}{2} [\delta(f - f_c) + \delta(f + f)]$$

Where:

- M(f) is the Fourier transform of the modulating signal.
- $\delta$  (f) is the delta function.

# Demodulation of an AM Signal

Demodulation is defined as extracting the original information-carrying signal from a modulated carrier wave. A demodulator is an electronic circuit that is mainly used to recover the information content from the modulated carrier wave. [3]

The demodulated signal can be expressed as:

$$m(t) = A_C s(t) \cos(2\Pi f_C t)$$

Which is the product of the received signal and a local oscillator at the carrier frequency. This signal is then passed through a low-pass filter to remove the carrier frequency and obtain the modulating signal.

# Software Prelab Message signal

 $m(t) = 0.85\cos(2\pi (1000) t)$ 

# Plot Message signal in Time Domine




Figure 1: Message signal in time domain

We notice from the graph that the amplitude of the Message signal is greater than 0.8, and this is very similar to the amplitude value in the Message signal equation.

# Plot Message signal in Frequency Domine




Figure 2: spectrum of message signal

From the graph for the spectrum of message signal we notice that there is two delta function one around -1khz, and another one around 1khz.

# Carrier signal

$$c(t) = 1\cos(2\pi (15000) t)$$

# Plot Carrier signal in Time Domine




Figure 3 :carrier signal in time domain

We notice from the graph that the amplitude of the carrier signal is 1, and this is very similar to the amplitude value in the carrier signal equation.

Plot Carrier signal in Frequency Domine




Figure 4: carrier signal in frequency domain

From the graph for the spectrum of carrier signal we notice that there is two delta function one around -15khz, and another one around 15khz.

# When $(\mu=1)$

Calculate the value of 
$$k_a$$
 
$$\mu=k_a\cdot A_m \quad \text{, given } m(t)=0.85\cos{(2\pi{(1000)}\ t)} \text{ so } A_m=0.85$$
 
$$\text{ka}=(\mu)\,/\,(\text{Am})$$
 
$$=(1)\,/\,(0.85)$$
 
$$=1.1765$$

# Mathematical Representation of AM Signal in Time Domain

### Given

- $m(t) = 0.85\cos(2\pi (1000) t)$
- $c(t) = 1\cos(2\pi (15000) t)$

•

$$s(t) = A_c (1 + K_a m(t)) \cos(2\Pi f_c t)$$

$$s(t) = (1)(1 + 1.1765 (0.85 \cos(2\Pi(1000)t))\cos(2\Pi(15000)t)$$

# Mathematical Representation of AM Signal in Frequency Domain

$$\begin{split} S(f) &= (Ac) \ /2 \ [ \ \delta \ (f-fc) + \delta \ (f+fc) ] + ((Ac) \ (\mu) \ /4) \ [ \ \delta \ (f-(fc+fm) + \delta \ (f+(fc+fm)) ] + \\ & ((Ac) \ (\mu) \ /4) \ [ \ \delta \ (f-(fc-fm) + \delta \ (f+(fc-fm)) ] \end{split}$$
 
$$= (1) \ /2 \ [ \ \delta \ (f-(fc-fm) + \delta \ (f+(fc-fm)) ] + ((1) \ (1) \ /4) \ [ \ \delta \ (f-(16000) + \delta \ (f+(16000)) ] + ((1) \ (1) \ /4) \ [ \ \delta \ (f-(14000) + \delta \ (f+(14000)) ] + ((1) \ (1) \ /4) \ [ \ \delta \ (f-(14000) + \delta \ (f+(14000)) ] + ((1) \ (1) \ /4) \ [ \ \delta \ (f-(14000) + \delta \ (f+(14000)) ] + ((1) \ (1) \ /4) \ [ \ \delta \ (f-(14000) + \delta \ (f+(14000)) ] + ((1) \ (1) \ /4) \ [ \ \delta \ (f-(14000) + \delta \ (f+(14000)) ] + ((1) \ (1) \ (1) \ /4) \ [ \ \delta \ (f-(14000) + \delta \ (f+(14000)) ] + ((1) \ ($$

# Build The Diagram When Modulation Index =1 ( $\mu$ =1) Step by Step Modulation

The figure below shows the general block diagram for AM modulation we can build it easily by using mathematical representation of AM signal in time domain

$$s(t) = A_c (1 + K_a m(t)) \cos(2\Pi f_c t)$$




Figure 5: General Modulation

The figure shows the modulation block diagram for  $\mu$ =1 by using MATLAB




Figure 6: Modulation Block Diagram for  $\mu=1$ 




Figure 8: properties of c(t)

Figure 7: properties of m(t)

To plot one cycle of s(t) we calculate the periodic time which is:

• Period time = 1/fm

$$= 8/1000 = 0.008 \text{ s}$$




Figure 9: s(t) in time domain

Because of u = 1 we notice that the type of modulation is normal.

To plot s(f) we add Zero-order hold and Spectrum analyzer




Figure 10: modulation block with spectrum analyzer




Figure 11: Spectrum for modulated signal (u=1)

From the graph of Spectrum, we got almost the same results based on this equation:

$$\begin{split} S(f) &= (Ac) \ /2 \ [ \ \delta \ (f-fc) + \delta \ (f+fc) ] + ((Ac) \ (\mu) \ /4) \ [ \ \delta \ (f-(fc+fm) + \delta \ (f+(fc+fm)) ] + \\ & ((Ac) \ (\mu) \ /4) \ [ \ \delta \ (f-(fc-fm) + \delta \ (f+(fc-fm)) ] \end{split}$$
 
$$= (1) \ /2 \ [ \ \delta \ (f-15k) + \delta \ (f+15k) ] + ((1) \ (1) \ /4) \ [ \ \delta \ (f-(16000) + \delta \ (f+(16000)) ] + \\ & ((1) \ (1) \ /4) \ [ \ \delta \ (f-(14000) + \delta \ (f+(14000)) ] \end{split}$$

### Demodulation

### Coherent demodulation

The figure below shows the general block diagram for AM Coherent demodulation we can build it easily by using this formula:

$$s(t)_{de} = c(t) * s(t)$$




Figure 12: General Coherent Demodulation

The figure 13 shows the build of modulation block diagram for  $\mu$ =1 by using MATLAB:




Figure 13: Demodulation Block Diagram for  $\mu$ =1

Due to the difficulty in controlling the gain value of the filter, the filter output was multiplied by a factor of 2.429 to obtain the signal amplitude that corresponds to the original amplitude of 0.85.




Figure 14: coherent demodulation output in time domain

As we see in the figure below, the output of the demodulation process is equal to the message signal. that's mean that we got the message signal after demodulation.

$$m(t) = 0.85 (2 pi (1000) t)$$




Figure 15: coherent demodulation output in frequency domain

# Envelope detector demodulation

The figure below shows the general block diagram for AM Envelope detector demodulation





Figure 16: Envelope detector demodulation general formula

now we should build the modulation block diagram for  $\mu$ =1 by using MATLAB:






Figure 17: Envelope detector demodulation output in time domain




Figure 18: Envelope detector demodulation output in frequency domain

# When $(\mu=0.5)$

Calculate the value of 
$$k_a$$
 
$$\mu=k_a\cdot A_m \quad \text{, given } m(t)=0.85\cos{(2\pi{(1000)}\ t)} \text{ so } A_m=0.85$$
 
$$\text{ka}=(\mu)\,/\,(\text{Am})$$
 
$$=(0.5)\,/\,(0.85)$$
 
$$=0.588$$

# Mathematical Representation of AM Signal in Time Domain

### Given

- $m(t) = 0.85\cos(2\pi (1000) t)$
- $c(t) = 1\cos(2\pi (15000) t)$

•

$$s(t) = A_c (1 + K_a m(t)) \cos(2\Pi f_c t)$$

$$s(t) = (1)(1 + 0.588 (0.85 \cos (2\Pi(1000)t)) \cos(2\Pi(15000)t)$$

# Build The Diagram When Modulation Index =0.5 ( $\mu$ =0.5) Step by Step Modulation

The figure shows the modulation block diagram for  $\mu$ =0.5 by using MATLAB




Figure 19: block diagram for case 2 (u=0.5)

To plot five cycle of s(t) we calculate the periodic time which is:

• Period time = 1/fm

= 5/1000




Figure 20: s(t) in time domine

Because of  $\mu$ =0.5we notice that the type of modulation is under modulation.

# To plot s(f) we add Zero-order hold and Spectrum analyzer




Figure 21: diagram to plot spectrum




Figure 22: Spectrum for modulated signal (u=0.5)

# Demodulation Coherent demodulation

The figure shows the build of modulation block diagram for  $\mu = 1$  by using MATLAB:




Figure 23: Coherent demodulation block diagram




Figure 24: Coherent demodulation in time domine




Figure 25: Coherent demodulation in frequency domine

# Envelope detector demodulation




Figure 26: Envelope detector demodulation block digram when (u=0.5)




Figure 27: Envelope detector demodulation in time domine




Figure 28: Envelope detector demodulation in frequncy domine

# When $(\mu=1.5)$

Calculate the value of 
$$k_a$$
 
$$\mu=k_a\cdot A_m \quad \text{, given } m(t)=0.85\cos{(2\pi{(1000)}\ t)} \text{ so } A_m=0.85$$
 
$$\text{ka}=(\mu)\,/\,(\text{Am})$$
 
$$=(1.5)\,/\,(0.85)$$
 
$$=1.765$$

# Mathematical Representation of AM Signal in Time Domain

Given

- $m(t) = 0.85\cos(2\pi (1000) t)$
- $c(t) = 1\cos(2\pi (15000) t)$

$$s(t) = A_c (1 + K_a m(t)) \cos(2\Pi f_c t)$$

$$s(t) = (1)(1 + 0.588(1.765\cos(2\Pi(1000)t))\cos(2\Pi(15000)t)$$

# Build The Diagram When Modulation Index =0.5 ( $\mu$ =0.5) Step by Step Modulation

The figure shows the modulation block diagram for  $\mu$ =1.5 by using MATLAB




Figure 29: Block diagram for  $\mu$ =1.5

To plot five cycle of s(t) we calculate the periodic time which is:

• Period time = 1/fm= 5/1000





Figure 30 :s(t) in time domine

Because of  $\mu$ =1.5we notice that the type of modulation is over modulation.

To plot s(f) we add Zero-order hold and Spectrum analyzer






Figure 31:s(f) in frequency domine

# Demodulation Coherent demodulation




Figure 32: Coherent demodulation block digram




Figure 33: s(t) in time domine




Figure 34: s(F) in frequency domine

# Envelope detector demodulation




Figure 35: Envelope detector demodulation




Figure 36: s(t) in time domine




Figure 37: s(f) in frequency domine

# References [1] https://uotechnology.edu.iq/dep/coe/lectures/Analog%20Communication%20%20Systems%20I-pdf/3.%20Amplitude%20Modulation%20Systems.pdf [2] https://reviseomatic.org/help/2-modulation/Amplitude%20Modulation.php [3] https://byjus.com/physics/modulation-and-demodulation/