


# Ice Machine Parts List for Series QM45 Models

QM45AE QM45AE


QM45 – 1 Updated: 5/12

# QM45 CONTROL BOX



DESCRIPTION		
1 Control Board (for use with all voltages)		
2 10 Amp Fuse – Mounted on Control Board	2511493	
3 Toggle Switch Only		
a. Toggle Switch Wiring Harness Only	2032483	
4 Relay		
a. 115V/60 Hz/1 Ph	8505533	
b. 230V/50-60 Hz/1 Ph	8505543	
5 Wiring Harness		
a. Air-Cooled (Not shown)	2008303	
6 Power Cord		
a. 125V/60 Hz (Not shown)	040001218	
b. 230V/50 Hz (Not shown)	2033023	
Miscellaneous - Brackets, Screws, etc.		
7 Control Board Mounting Supports	4302253	
8 Screw, #10-24 x .50 Ground		
9 Bushing		
10 Bushing		

#### **QM45 EVAPORATOR ASSEMBLY**




DESCRIPTION PAR		
1	Evaporator Assembly	
	a. Dice Cube	† 7629463
2	Water Pump	
	a. 115V/60 Hz	† 7623063
	b. 230V/50 Hz - Up to Serial Number 310145261	† 7626013
	c. 230V/50 Hz - After Serial Number 310145261	040000946
3	Float Valve (Complete Assembly) - Up to Serial Number 031100000	† 7602133
4	Float Valve (Complete Assembly) - After Serial Number 031100000	8369049
	a. Float Valve Screen	† 8369069
	b. Float Valve Plunger	† 8369089
	c. Float Valve Compression Nut	† 5650729
	d. Bracket	7621403
5	Ice Thickness Control Probe	† 7601603
6	Magnetic Bin Switch (Mounted to Evaporator)	
7	Ice Damper	
	a. Ice Damper Magnet and Cap	7629093
8	Water Distribution Tube	000007163
9	Water Trough	040001233
10	Water Inlet Tubing (Not shown)	4420291
11	Siphon Cap	4302223
Miscellaneous – Brackets, Screws, etc.		
12	Drain Tube	† 7600863
13	Tubing (Water Pump Out)	040001234
14	Screw, #8-32 x 0.625 Nylon Water Distribution Tube Mounting	040001217
15	Screw, #10-24 x 0.750 Used to Mount Evaporator (Not shown)	† 5202189
16	Screw, #10-24 x 0.50	
17	Thumbscrew, #8-32 x 0.625	
18	Bushing (Ice Thickness Probe Wire)	•
19	Water Pump Lead (Not Shown)	
20	Water Pump Cover	000006754

QM45 - 3


Updated: 5/12

### QM45 REFRIGERATION COMPARTMENT - COMMON PARTS



DE	SCRIPTION	PART NO.
1	Compressor	
	a. 115V/60 Hz/1 Ph	† 7629183
	b. Overload for Compressor	† 8505683
	c. Starting Device	8505703
	d. 230V/50 Hz/1 Ph	† 7629193
	e. Overload for Compressor	† 8505503
	f. Starting Device	8505693
2	Hot Gas Valve	
	a. Hot Gas Valve Including 115V 60 Hz Electrical Coil (Danfoss)	† 7630001
	b. Hot Gas Valve 115V Coil Only Danfoss	000005156
	c. Hot Gas Valve 115V Coil Only Alco	2404363
	d. Hot Gas Valve Including 208/230V 50/60 Hz Electrical Coil (Danfoss)	† 7630061
	e. Hot Gas Valve 230V/50 Hz Coil Only Danfoss	000005157
	f. Hot Gas Valve 230V/50 Hz Coil Only Alco	† 2404483
3	Expansion Valve	† 7629503
4	Expansion Valve Body Insulation Boot	4007213
5	Expansion Valve Bulb Insulation Boot	4007203
Miscellaneous – Brackets, Screws, etc.		
6	Bracket (Water/Electrical Inlet)	6035151
7	Water Inlet Female Wing Adapter	† 8706093
8	Male Connector 1/4" OD x 1/8" NTPF	1360961
9	Bin Drain Tubing (Molded)	4421443
10	Bin Drain Hose Clamp (Not shown)	† 5650649
11	Water Inlet Tubing 0.375 ID	4420291
12	Clamp, Expansion Valve Bulb	† 5650529
13	Screw, #10-24 x 0.50	† 5202069
14	Compressor Mounting Retainer	† 5648269
15	Compressor Mounting Washer	† 5573179
16	Compressor Clevis Pin 1/4" x 1"	† 3712109
17	Compressor Hairpin Clip	† 5648289


#### QM45 REFRIGERATION COMPARTMENT - AIR-COOLED



DESCRIPTION		
1	Compressor (Refer to COMMON PARTS Page)	Page 4
2	Air Condenser	8851353
3	Fan Motor	
	a. 115V	
	b. 230V/50 Hz	
4	Fan Blade	
5	Fan Cycling Control	2355453
6	Drier	†8930259
Miscellaneous – Brackets, Screws, etc.		
7	Fan Shroud	6061749
8	Fan Motor Mounting Bracket	6029401

Updated: 5/12

## **QM45 PANELS**



DESCRIPTION		PART NO.
1	Front Panel Assembly	7629213
2	Air Filter	7629223
3	Door Frame Assembly	040000627
4	Bin Door	040002220
	a. Door Pin Gasket and Door Pin Assembly	7629233
	b. Door Pin Thumbscrews	5012353
5	Back Panel, Upper	
6	Back Panel, Lower	6029461
Miscellaneous – Brackets, Screws, etc.		
7	Front Cover Screw	† 5202239
8	Screw, #10-24 x 0.50	† 5121539
9	Ice Scoop (Not shown)	3302583