Rep	Designazione	Designation	Description	Descripcion	Code
01		Plaque Inférieure Lisse TPO/PD	Lower Smooth Plate Tpo/Pd	Placa Inferior Lisa TPO/PD	0SI364
02DX	Piastra Sup. Rigata Dx Pd	Plaque Supérieure Lisse Droite Dx Pd	1		0SI372
02SX		Plaque Supérieure Lisse Gauche Dx Pd	Upper Left Smooth Plate Dx Pd	Placa Superior Lisa Izqda Dx Pd	0SI374
03	Basamento Inox Pgd Electrolux	Structure inox PGD Electrolux	Stainless steel structure PGD Electrolux	Estructura inoxidable PGD Electrolux	0SI353
04	1	Couvercle inférieur zingué TPO-PD R/L/M	Lower galvanised cover TPO-PD R/L/M	Tapa inferior galvanizada TPO-PD R/L/M	0US364
05		Couvercle postérieur Inox PD R/L/M	Rear stainless steel cover PD R/L/M	Tapa posterior inoxidable PD R/L/M	0US362
06	1	Tiroir de récolte inox TPO-PD R/L/M	Stainless steel collection tray TPO-PD R/L/M	Cajón de recogida inoxidable TP0-PD R/L/M	0SI136
07DX		Couvercle supérieur droit PD R/L/M	Upper right cover PD R/L/M	Tapa superior derecha PD R/L/M	0SI163
07SX		Couvercle supérieur gauche PD/LEI	Upper left cover PD/LEI	Tapa superior izquierda PD/LEI	0SI196
08		Résistance supérieure gauche/droite 220 PD/LEI	Upper right/left heating element 220 PD/LEI	Resistencia superior izquierda/derecha 220 PD/LEI	0US373
08A	Resist.Sup.Sx/Dx 110v. Pd/Lei	Résistance supérieure gauche/droite 110V. PD/LEI	Upper left/right heating element 110V. PD/LEI	Resistencia superior izquierda/derecha 110V. PD/LEI	0US375
09	Resist.Inf.Sx/Dx 220 Pd/Tpo/El	Résistance inférieure gauche/droite 220 PD/TPO/EL		Resistencia inferior izquierda/derecha 220 PD/TPO/EL	0SI187
09A	Resist.Inf.Sx/Dx 110	Résistance inférieure gauche/droite 110 PD/TPO/LEI	Lower right/left heating element 110 PD/TPO/LEI	Resistencia inferior izquierda/derecha 110 PD/TPO/LEI	0US377
10		Thermostat 110/220V-50/60HZ pour plaques	Thermostat 110/220V- 50/60HZ FOR PLATES	Termostato 110/220V- 50/60HZ PARA PLACAS	0US460
11		Lampe temoin PG1/2/D Electrolux	Pilot lamp PG1/2/D Electrolux	Lampara temoin PG1/2/D Electrolux	0SI307
12		Panneau isolant K120 PD/TPO/LEI	Insulation panel K120 PD/TPO/LEI	Panel aislante K120 PD/TPO/LEI	0SI265
12		Panneau Isolant 110 ZK PD/LEI	INSULATION PANEL 110 ZK PD/LEI	Panel Aislante 110 ZK PD/LEI	0SI267
13		Protection de panneau isolant TPO-PD R/L/M		Protección de panel aislante TPO-PD R/L/M	<b>0SI140</b>
14DX		Barrette de soulèvement droite DAL. 99 PD-CRT-LEI	Right lifting bar DAL. 99 PD-CRT-LEI	Barra de elevación derecha DAL. 99 PD-CRT-LEI	0SI000
14SX	Asta Soll.Sx Dal. 99 Pd-	Barrette de soulèvement gauche DAL. 99 PD-CRT- LEI	PD-CRT-LEI	Barra de elevación izquierda DAL. 99 PD-CRT-LEI	0SI001
15	Freno Ottone Pd-Crt-Lei	Frein en cuivre PD-CRT-LEI	Copper brake PD-CRT- LEI	Freno de cobre PD-CRT-LEI	0SI165
16		Axe de soulèvement d.12 PD/ELIO	Raising spindle d.12 PD/ELIO	Eje de elevación d.12 PD/ELIO	0SI003
17	Perno Bilanciamento	Axe de rotation PD/LEI	Rotation spindle PD/LEI	Eje de rotación PD/LEI	0SI002
18	Perno Impugnatura Pd/Lei			Eje del asa PD/LEI	<b>0SI057</b>
19DX		Ressort De Soulèvement Droit DAL 99 PD-LEI	Right Raising Spring Dal 99 PD-LEI	Muelle De Elevación Derecho DAL 99 PD-LEI	<b>0SI073</b>
19SX	Molla Soll. Sx Dal 99 Pd-	Ressort De Soulèvement Gauche DAL 99 PD-LEI	Left Raising Spring Dal 99 PD-LEI	Muelle De Elevación Izquierdo DAL 99 PD-LEI	0PR054
20	Impugn. Soll. Pg1/D/Usa	Poignée De Soulèvement PG1/D/ USA Electrolux	Raising Handle PG1/D/ USA Electrolux	Asa De Elevación Pg1/D/USA Electrolux	0SI269
21	Pomel.Casset.Pg1/2/D/Usa	Bouton De Tiroir PG1/2/D/ USA Electrolux	Drawer Handle PG1/2/D/	Botón De Cajón PG1/2/D/USA Electrolux	0SI271

23	Manop.Termos.Pg1/2/D	Bouton Thermostatique	Thermostat Knob	Botón Termostático PG1/2/D/	
		PG1/2/D Electrolux		Electrolux	<b>0SI356</b>
	Electrolux	I G1/2/D Electrolux	I G1/2/D/ Electrolux	Electrolux	
24	Piedino Pd-Crt-Lei-Tpo	Pieds PD-CRT-LEI-TPO	Feet PD-CRT-LEI-TPO	Patas PD-CRT-LEI-TPO	<b>0US372</b>
30DX		Dispositif de fixation droite		Dispositivo de fijación	
	Ast. Anti Ribalt. Dx Pd	PD	Right fixing device PD	derecho PD	<b>0US365</b>
30SX		Dispositif de fixation gauche		Dispositivo de fijación	
	Ast. Anti Ribalt. Sx Pd	PD	Left fixing device PD	izquierdo PD	<b>0US366</b>
33	Spirale Prot.Compl. Pd-	Spirale de protection	Additional protection coil	Espiral de protección	
		complémentaire PD-CRT-LEI	PD-CRT-LEI	complementaria PD-CRT-LEI	<b>0SI005</b>
34	C-1-1:- C: D-1	Callana and follows DD	Hannan animin a CDT Lai	Callanda Caranian DD	<b>0SI006</b>
		Cablage supérieur PD	Upper wiring CRT-Lei	Cableado Superior PD	031000
	Rondella D.6 Pd-Crt-Lei-	Rondelle d.6 PD-CRT-LEI-	Washer d.6 PD-CRT-LEI-	Arandela d.6 PD-CRT-LEI-	<b>0SI173</b>
	Тро	TPO	TPO	TPO	031173
		Anneau De Maintien Interne		Anillo De Sujeción Interno	OTICATA
		PD	Inside Support Ring Pd	PD	0US476
		Anneau De Maintien Externe		Anillo De Sujeción Externo	OTIC 455
	Pd	PD		PD	0US477
38	Morsettiera		Terminal block	Placa de bornes	0710204
	Pd/Crt/Lei/Tpo	Bornier PD/CRT/LEI/TPO	PD/CRT/LEI/TPO	PD/CRT/LEI/TPO	0US381
40		Câblage inférieur	Additional lower wiring	Cableado inferior	0.07=1.00
	Cabl. Inf. Compl. Pd/Tpo	complémentaire PD/TPO	PD/TPO	complementario PD/TPO	<b>0SI189</b>
41	Cavo Alimentazione		Power supply cable	Cable de alimentación	
	Pd/Tpo	Câble d'alimentation PD/TPO		PD/TPO	<b>0SI375</b>
42	Canada Dinata	Danaga maya mlagyas	Daniel for DL ATEC	Camilla mana DI A C A S	0US358
	Spazzola Piastre	Brosse pour plaques	Brush for PLATES	Cepillo para PLACAS	000000
43	Pressacavo Pg13,5	Butée De Câble PG13,5	Cable Stop PG13,5	Prensaestopas PG13,5	<b>0SI190</b>
51		Plaquette De Garniture PGD		Placa Delantera Pgd	
		Electrolux	Trim Plate Pgd Electrolux		<b>0SI359</b>

