
You are here: IoT Gateway User Guide > Projects and triggers > Defining a trigger > Trigger event type

Topic updated on September 21, 2023

Trigger event type

The trigger event type identifies when the trigger is executed. For every trigger's definition, the **Event** tab provides a **Trigger Event Type** drop down-list with options that determine the trigger event type. Once a specific trigger event type is selected, the event tab becomes active with parameters that accommodate that specific event type.



The event types available in the **Trigger Event Type** list depends on the type of product installed on the node (for example Enterprise Gateway or Asset Gateway), as well as the packages and extensions installed on the node (for example the device drivers).

The trigger event types are documented in the Trigger event type reference.

About Telit | Contact Us | Legal Notices | Terms of Service | Privacy Policy

Copyright © 2025, Telit IoT Solutions Holding Ltd.. All rights reserved.