




4-6-0 CASTLE CLASS LOCOMOTIVE AND TENDER 2-RAIL

No. 2220 ORIGINAL TYPE WITH 1" MOTOR - No. 2221 MODIFIED TYPE WITH 1" MOTOR



[4]	Screw	20690 20699	Insulating Bush Wheel without Flange—Insulated	Wheel without Flange (with Insulating Bush) Assembly Job No. 17968	14443	Screw	
2548	Screw				14445	Front Plate	
7511	Screw				21022	Chassis	
7715	Axle				21400	Coupling	
	(8.2)	20733	Wire Collector		21414	Rivet	
7737	Screw				21528	Drawbar	
7741	Coupling Rod Pin	20734	Base for Collector				
11560	Axle Front Bogie Assembly	20735	Cover for Collector		FOR I MOTOR—ITEMS AS STATED, EXCEPT FOR:—		
17665	Bogie & Bracket Assembly Job. No.	20759	Coupling Rod				
20189	Wheel 12377	21472	Motor Assembly		14407	Chassis (For Motor Job No. 20716)	
	***		7/2/20 00 00 00 00 00 00 00 00 00 00 00 00 0		14442	Drawbar	
12832	Screw	21525	Worm Wheel		20110	Worm Wheel	
14407	Chassis (For motor job No. 21472)				20716	Motor Assembly	
14408	Wheel with Flange				20728	Washer	
14409	Wheel without Flange	TENDER			20729	Insulating Bush	
14411	Grub Screw				20746	Screw	
14413	Cylinder Assembly	27	Screw		20747	Washer	
14420	Connecting Rod Pin	7630	Rivet				
20689	Coupling Rod Pin (Insulated Wheels)	11560	Axle	e Underframe		ASSEMBLIES	
20690	Insulating Bush Wheel with Flange	14433	Underframe	Assembly	14392	Housing Assembly	
20698	(with insulating	20187	Wheel with Flange	Job No. 17833	18666	Chassis Assembly (without motor)	
A64319	Wheel with Flange Bush) Assembly —Insulated Job No. 17966	20168	Wheel Without Flange		21023	Chassis Assembly (with motor)	