Bed Leveling Optimization & Printer Upgrades 🎇

1 Bed Adjustment

Once **Screw Tilt** and **Bed Leveling** are completed, print a test with **small squares positioned above the bed screws** to fine-tune the settings.

- First layer: Print this initial layer slowly.
- Live adjustment: During printing, adjust the bed height by turning the corresponding leveling screws.
- Do not relevel after: Once the optimal setting is achieved, avoid redoing the Bed Leveling to maintain accuracy.
- Tutorial video on Bed Leveling and Screw Tilt Calculate:
- https://youtu.be/tKLLveLwOtk?si=8Lm94dnieESqAA 8

This should **improve adhesion and bed flatness**, resulting in better prints.

2 Stabilizing Bed Leveling

To ensure long-term stability of the bed leveling, **replace the springs and spacers** with **silicone tubes**. This helps **reduce vibrations** and prevents the bed from **losing its calibration over time**.

- **Link to order silicone tubes:**
- A https://a.aliexpress.com/ EwjsNp6

Tip for Neptune 4 Plus and Max: The spacers under the bed can also be replaced with these silicone tubes, further enhancing stability and precision.

3 Upgrade with OpenNeptune

If you want to **significantly enhance** your printer, switching to **OpenNeptune** is a great upgrade.

This firmware improves performance and optimizes printer management.

■ Tutorial video on OpenNeptune:

https://voutu.be/J-H4aQfmzbY?si=mtNvxhRc2sa66Bli