Mes chers camarades bien le bonjour!

Voici un tuto afin d'ajouter le wifi a la neptune 4 / 4 Pro!

Pour moi il est toujours préférable de passer par la connexion filaire (plus stable, plus rapide) mais si vous n'avez pas la possibilité voici donc une solution.

Tout mes test on été effectuer avec une clé wifi usb TP-Link Archer T3U : https://amzn.to/3EQv9Qi Brancher la clé usb wifi sur le port usb de l'imprimante.


Tout d'abord il vous faudra connecter votre imprimante à votre réseau local via le câble ethernet de l'imprimante à votre box internet.

Une fois connecté rendez vous dans le menu about machine



Un fois dans le menu vous aurez une adresse IP

Utiliser une application afin d'accéder à votre imprimante en ssh comme l'application **putty** https://www.chiark.greenend.org.uk/~sgtatham/putty/latest.html indiquer l'adresse ip dans comme si dessous et appuyez sur **open**



Tapez comme login : **mks** password : **makerbase**

Une fois connecté tapez : sudo apt install network-manager

tapez le password : makerbase

Tapez Y si on vous demande une confirmation


afin d'être sûr que la clé fonctionne bien tapez la commande : nmcli dev wifi

vous devriez voir vos réseaux wifi dans la liste.


```
root@mkspi:~# nmcli dev wifi
IN-USE SSID
                              MODE
                                     CHAN RATE
                                                       SIGNAL
                                                               BARS
                                                                      SECURITY
                                           65 Mbit/s
                                           130 Mbit/s
        CuisineHub.A6EE.u,
                              Infra
                                     11
                                           65 Mbit/s
                                                       64
        Salle de Jeux.o,
                              Infra
                                     11
                                           65 Mbit/s
        Milight3.0-4B03D0
                                     11
                                           65 Mbit/s
                                                                      WPA2
                              Infra
root@mkspi:~#
```

Si c'est le cas alors tapez la commande : nmtui

allez dans Activate a connection



Sélectionnez votre réseau wifi dans la liste et appuyez sur enter. Entrer le mot de passe de votre wifi et valider.



Normalement aucun message n'apparaît et un petit * apparaît à côté du réseau.

faite back puis quit

Une fois revenu en ligne de commande nous allons vérifier que le wifi est bien connecté et récupérer l'adresse ip de la clé wifi.

taper pour cela les commande :

cd /sbin ./ifconfig

Dans la partie wlan0 vous trouverez votre adresse ip wifi et ainsi vous connecter à l'interface de l'imprimante sans câble ;-)

Après un redémarrage de l'imprimante, le wifi ne se reconnecte pas automatiquement donc voici comment faire pour que l'imprimante se connecte à chaque démarrage.


Connectez vous en SSH (voir plus haut via putty) taper la commande :

sudo nano /etc/network/interfaces

Entrée le mot de passe : makerbase

Allez à la fin du fichier et ajouter c'est ligne :

auto wlan0
iface wlan0 inet dhcp
wpa-essid NOM_DE_VOTRE_WIFI
wpa-psk MOT_DE_PASSE_WIFI



Ensuite appuyez sur ctrl+x

tapez Y puis touche enter

Votre configuration sera enregistrée après un reboot de la machine ;-)

Si après un redémarrage vous n'avez plus de wifi lorsque vous faites la commande : nmcli dev wifi

Alors faites cette modification:

toujours en ssh taper la commande : **sudo nano /etc/NetworkManager/NetworkManager.conf** modifier la ligne :

Managed=false en Managed=true

une fois fait faites les touche CTRL+X

Appuyer sur Y puis ENTER (si vous êtes toujours dans le fichier refaire CTRL+X

ensuite tapez la commande : sudo service network-manager restart

et enfin pour tester refaite : **nmcli dev wifi** Les réseaux wifi devraient apparaître ;-)

N'hésitez pas si vous avez des inputs.

Longue vie et prospérité, que la force du print soit avec vous !

Credit:

Julien Mairy

https://www.youtube.com/@printernbeer

https://www.facebook.com/Smarthome42

https://www.facebook.com/groups/impressions3dfr

Hello, my dear friends!

Here is a tutorial on how to add wifi to the Neptune 4 / 4 Pro!

For me it is always preferable to use the wired connection (more stable, faster) but if you do not have the option here is a solution.

All my tests were carried out with a TP-Link Archer T3U usb wifi key: https://amzn.to/3EQv9Qi Plug the wifi usb key into the printer's usb port.


First of all you will need to connect your printer to your local network via the Ethernet cable from the printer to your internet box.

Once connected, go to the about machine menu



Once in the menu you will have an IP address

Use an application to access your printer via ssh such as the **putty** application https://www.chiark.greenend.org.uk/~sgtatham/putty/latest.html indicate the ip address in as if below and press **open**



Type as login: **mks** password: **makerbase**

Once connected type: sudo apt install network-manager

type password: makerbase

Type Y if you are asked for confirmation


to be sure that the key works correctly, type the command: nmcli dev wifi

you should see your wifi networks in the list.


```
root@mkspi:~# nmcli dev wifi
IN-USE SSID
                             MODE
                                    CHAN RATE
                                                                    SECURITY
                                                              BARS
                                          65 Mbit/s
       CuisineHub.A6EE.u,
                             Infra 11
                                          65 Mbit/s
                                                      64
                             Infra 11
       Salle de Jeux.o,
                                          65 Mbit/s
       Milight3.0-4B03D0
                             Infra 11
                                                                    WPA2
                                          65 Mbit/s
root@mkspi:~#
```

If so then type the command: nmtui

Go to Activate a connection



Select your wifi network from the list and press enter. Enter your wifi password and confirm.



Normally no message appears and a small * appears next to the network.

back then quit

Once back on the command line we will check that the wifi is properly connected and retrieve the IP address of the wifi key.

To do this, type the commands:

cd /sbin ./ifconfig

```
flags=4163<UP, BROADCAST, RUNNING, MULTICAST>
          inet 192.168.0.108 netmask 255.255.255.0 broadcast 192.168.0.255 inet6_f-00..-207.-06.000 prefixlen 64 scopeid 0x20<link>
          RX packets 828659 bytes 145058183 (138.3 MiB)
          RX errors 0 dropped 25441 overruns 0 frame 0
TX packets 426837 bytes 238524175 (227.4 MiB)
          TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
          device interrupt 48
lo: flags=73<UP,LOOPBACK,RUNNING> mtu 65536
    inet 127.0.0.1 netmask 255.0.0.0
          inet6 ::1 prefixlen 128 scopeid 0x10<host>
loop txqueuelen 1000 (Local Loopback)
          RX packets 1552895 bytes 504124300 (480.7 MiB)
          RX errors 0 dropped 0 overruns 0 frame 0
TX packets 1552895 bytes 504124300 (480.7 MiB)
          TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
wlan0: flags=4163<UP,BROADCAST,RUNNING,MULTICAST> mtu 1500
inet 192.168.0.205 netmask 255.255.255.0 broadcast 192.168.0.255
          inet6 a98 prefixlen 64 scopeid 0x20<link>
ether ueuelen 1000 (Ethernet)
RX packets 7702 bytes 941112631 (897.5 MiB)
          RX errors 0 dropped 332467 overruns 0 frame 0
TX packets 24 bytes 1614254 (1.5 MiB)
           TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
 :oot@mkspi:/sbin#
```

In the wlan0 part you will find your wifi IP address and thus connect to the printer interface without cable :-)

After restarting the printer, the wifi does not reconnect automatically so here is how to get the printer to connect each time it is started.

Connect via SSH (see above via putty) type the command:

sudo nano /etc/network/interfaces

Enter password: makerbase

Go to the end of the file and add this line:

auto wlan0
iface wlan0 inet dhcp
wpa-essid NAME_OF_YOUR_WIFI
wpa-psk WIFI_PASSWORD

```
source /etc/network/interfaces.d/*

# Network is managed by Network manager

auto lo

iface lo inet loopback
iface eth0 inet dhcp

auto wlan0
iface wlan0 inet dhcp

wpa-essid SmartHome42
wpa-psk
```

Then press ctrl+x

type Y then press enter

Your configuration will be saved after rebooting the machine ;-)

If after a reboot you no longer have wifi when you order: nmcli dev wifi

So make this modification:

still in ssh type the command: **sudo nano /etc/NetworkManager/NetworkManager.conf** modify the line:

Managed=false to Managed=true

once done press CTRL+X

Press Y then ENTER (if you are still in the file redo CTRL+X then type the command: sudo service network-manager restart and finally to test redone: nmcli dev wifi
WiFi networks should appear ;-)

Don't hesitate if you have any input.

Long life and prosperity, may the power of print be with you!

Credit:

Julien Mairy

https://www.youtube.com/@printernbeer https://www.facebook.com/Smarthome42 https://www.facebook.com/groups/impressions3dfr