## Changelog 30 Oct 23

Changement fais après update 1.2.2.43 Neptune 4 Plus:

- Mise en page totalement refaite avec un index pour retrouver facilement les sections.
- Dans la section [virtual sdcard]
  - Suppression de 8 M300 (personnellement il y en avait trop)
- Ajout de la section Température pour afficher celle de l'host et du mcu à l'interface web
- pour les section tmc2209 stepper x et Y
  - o changement du run\_current de 1.2 à 0.8
  - désactivation du hold\_current
  - o interpalte mis à false plutôt que true (conseille de la doc klipper)
  - o stealthchop\_threshold : 999999 au lieu de 0 pour éviter les sifflement moteur
- ajout de la section firmware rectraction
- changement des valeur min et max température du bed et extruder (voir printer.cfg)
- ajout de l'option [screw\_tilt\_adjust] (option pour le bed leveling, faire un home avant)
- ajout de l'option [bed\_screws] (option pour le bed leveling avec feuilles de papier, faire un home avant)
- une version du M600 différent
- Ajout des macros Load/Unload Filament
- Ajout des macro pour PID Extruder / BED

## Changelog 30 Oct 23

Change made after update 1.2.2.43 Neptune 4 Plus:

- Completely redesigned layout with an index to easily find the sections.
- In the [virtual sdcard] section
  - Removal of 8 M300s (personally there were too many)
- Added Temperature section to display that of the host and mcu to the web interface
- for the tmc2209 stepper\_x and Y sections
  - o change of run current from 1.2 to 0.8
  - deactivation of hold\_current
  - o interpalte set to false rather than true (recommends from the klipper doc)
  - o stealthchop threshold: 999999 instead of 0 to avoid engine whistling
- added firmware\_rectraction section
- change of min and max temperature values of the bed and extruder (see printer.cfg)
- addition of the option [screw\_tilt\_adjust] (option for bed leveling, do a home before)

- addition of the [bed\_screws] option (option for bed leveling with sheets of paper, make a home first)
- a version of the different M600
- Added Load/Unload Filament macros
- Added macros for PID Extruder / BED