Motor direction

Overview

The code is used to rotate the motor in anticlockwise and clockwise direction.

Requirements

- 1. Arduino uno
- 2. Proteus simulator
- 3. Motor