
Camera Adapters for the Logitech Adaptive Gaming Kit USER QUICK GUIDE



Introduction

The Camera Mount Adapters for the Logitech Adaptive Gaming Kit provides a way to attach the various buttons from the Logitech Adaptive Gaming Kit to standard ¼"-20-inch camera mounting systems.

Features



Sizing

There are for different adapters to suit the different sizes of buttons from the Logitech adaptive gaming kit:

Size	Button	Camera Mount Adapter
Large		AGK-L
Small		

Camera Adapters for the Logitech Adaptive Gaming Kit USER OUICK GUIDE





Installation

To attach the adapter to the Logitech Switches, place two M3 x 8 mm machine screws into the adapter. Line up the screw with the holes in the appropriate button and tighten the screws.



To use with a camera mount, simply screw the camera mount threads into the adapter and adjust camera mount to the desired location.



Cleaning

Wipe with sterilizing cloth or spray.

© 2022 by Neil Squire / Makers Making Change