
Interact Switch TOPPER GUIDE



Overview

The Interact Switch is available with several different Switch Tops. Using different colors and textures can help a user distinguish between switches by sight or feel. The plain, 'default' button topper can be seen below, and the other options included in the Interact Switch Repository are listed in the table on the next page.



Generally, it is also possible and easy to print toppers in different colors. It is also possible to print a topper in multiple colors based on the height. This is illustrated below with a Smile Topper that has the main portion printed in orange and the raised portion printed in black.



Interact Switch TOPPER GUIDE



Arrow	Circle	Dome
Dots Circles	Dots Wide	Lines
Lines Very Wide	Lines Wide	Octagon
Rings	Rings Wide	Smile