
# Ivy Nunchuck Joystick Adapter USER GUIDE



#### Introduction

The Ivy Nunchuck Joystick Adapter enables a Nunchuck controller to be used as a USB HID Mouse or USB HID Gamepad. The Nunchuck Controller has a thumb joystick and two buttons. A light on the enclosure of the Ivy Nunchuck Joystick Adapter indicates which operating mode the device is in.

### **Features**



## Setup

- 1. Plug the Nunchuck Controller into the Ivy Nunchuck Joystick Adapter.
- 2. Plug the USB-C end of the USB Cable into the Ivy Nunchuck Joystick Adapter.
- 3. Connected the other end of the USB cable to the Host Device (use a suitable adapter if necessary).

### Swapping between Mouse and Gamepad Mode

- 1. Reset the Adapter. Before the red light turns off, press and hold the two buttons on the Nunchuck until the light turns green, then release the two buttons.
- 2. Press the C button to toggle between modes. The light on the Adapter will indicate the current mode: USB HID Mouse Yellow, USB HID Gamepad Blue.
- 3. Press and release the Z button to set the mode. The light will blink.
- 4. Cycle the power by pressing the reset button or disconnecting and reconnecting USB cable.

# **Ivy Nunchuck Joystick Adapter USER GUIDE**



## **Usage**

Mouse Mode	Gamepad Mode	
Status Light: Yellow	Status Light: Blue	
<ul> <li>Move the joystick to control the cursor.</li> <li>Press the C button to left click.</li> <li>Press the Z button to right click.</li> <li>Hold the Z button for 2 seconds to enter scroll mode. LED will turn purple. Move joystick to scroll. Press Z button again to exit scroll mode.</li> </ul>	<ul> <li>Move the joystick to control the joystick.</li> <li>Press the C button to activate Button 1.</li> <li>Press the Z button to activate Button 2.</li> </ul>	

## Mapping

Nunchuck	Mouse	Joystick		
Nunchuck		PC	XAC (Left USB)	XAC (Right USB)
Joystick	Cursor movement	Joystick	Left Thumbstick	Right
	(Scroll movement if in scroll	movement		Thumbstick
	mode (purple LED))			
С	Left click	Button 1	X1 (Left Stick Up)	View
Z	Right click	Button 2	X2 (Left Stick Down)	Menu
	(Long press -> enter scroll mode)			

## **Host Device Compatibility**

- USB HID Mouse: PC, Mac, Android Smartphone, Apple Smartphone (iOS 13+)
- USB HID Gamepad: PC, Xbox Adaptive Controller

# **Specifications**

Nunchuck Joystick Range of Motion	±30°
Nunchuck Joystick Range of Motion	± 15 mm
Nunchuck Joystick Activation Force	100 grams
Nunchuck Weight	68 grams
Enclosure Height	25 mm
Enclosure Width	45 mm
Enclosure Length	51 mm
Enclosure Weight	21 grams

# **Cleaning**

The outside of the enclosure can be cleaned with a damp cloth. Do not use hot water. Do not submerge.