

Switch Adapted Bump 'N' Go Bubble Dino

ASSEMBLY GUIDE

Required Components

	Materials
	1. Play day Bump 'N' Go Bubble Dino 2. 1x Mono jack 3. Wire

Required Tools

- Phillip screwdriver
- Wire strippers
- Flush cutters
- Soldering iron and solder

Required Personal Protective Equipment (PPE)

- Safety glasses

Assembly Instructions

1. Carefully remove dinosaur from packaging.
2. Remove all screws holding together the two halves of the dinosaur. **The screws in the arms legs do not need to be removed.**
3. Separate the two halves of the dinosaur. Do not remove any screws on the inside.
4. Cut two wires, 15 cm each, and strip the insulation off of 0.5 cm on each side. Put the wires through the first two legs of the mono jack as shown in the photo, and solder them on.
5. Find the sliding switch, and solder to two of the contacts on the back of the PCB.
6. **Test the toy with an assistive switch**, make sure it turns on when the switch is pressed and turns off when the switch is not pressed.
7. Drill a hole in the dino, with a ¼ inch drill bit, behind the leg as shown in the photo.
8. Put the mono jack through the drilled hole, and screw the ring onto the jack to keep it in place.
9. Reassemble and repackage the dino.

