V1.0 | December 2022

Button Toppers for Joy-Con SUMMARY



Title

Button Toppers for Joy-Con

Subtitle

Button extenders that make the buttons on a Joy-Con bigger and further apart.

Device Details

Overview

The Button Toppers for Joy-Con are a set of toppers that attach to the buttons on the Nintendo Joy-Con controller of a Nintendo Switch. They make the buttons larger and further apart to make them easier to use.

Usage

To use the button toppers, they need to be glued onto the existing buttons on the Joy-Con. This is permanent, and risks damaging the Joy-Con buttons if the toppers are removed.

Once they are attached, the buttons can be used as normal.

Cost

<\$1

Build Instructions

To use the button toppers, they need to be glued onto the buttons on the Joy-Con. This is permanent, and risks damaging the Joy-Con buttons if the toppers are removed.

Skills Required

• 3D printing

Time Required

3D Printing: 24 minutes Assembly: 5 minutes

Tools

- 3D printer
- Hobby knife
- Safety goggles

Components

- 1X Switch button topper A
- 1X Switch button topper B
- 1X Switch button topper − X

Button Toppers for Joy-Con SUMMARY



- 1X Switch button topper Y OR 1X Switch button topper Y smaller
- 1X Switch button topper

Attribution

- Design by RehabEng SCCR HorizonHealth on printables.com
- Documentation by Neil Squire Society/Makers Making Change