# Foot Pedal Switch USER QUICK GUIDE



## Introduction

This device is a foot pedal switch that functions like a standard 3.5mm mono jack switch but can be operated with a foot.

#### **Features**



# Usage

To use, connect the jack to a matching 3.5 mm mono plug. The pedal can then be placed on the ground and pressed with the user's foot to activate.

# Compatibility

The foot pedal is compatible with any device that uses a standard 3.5 mm mono jack switch. The pedal was originally designed for use with the Xbox Accessible Controller (XAC).

#### Alternate Models

There is a version of the switch with a metal body that has the cable on the same side as the hinge. The metal version is listed as an alternate in the Bill of Materials and the Maker Guide.

## **Specifications**

The pedal has dimensions of 80 x 80 x 35 mm, and weighs 200 g. It has an activation force of 1.5 pounds.

### Cleaning

The device can be wiped clean with a damp cloth.