Foot Pedal Switch USER QUICK GUIDE



Introduction

This device is a foot pedal switch that functions like a standard 3.5mm mono jack switch but can be operated with a foot.

Features



Usage

To use, connect the jack to a matching 3.5 mm mono plug. The pedal can then be placed on the ground and pressed with the user's foot to activate.

Compatibility

The foot pedal is compatible with any device that uses a standard 3.5 mm mono jack switch. The pedal was originally designed for use with the Xbox Accessible Controller (XAC).

Specifications

The pedal has dimensions of 80 x 80 x 35 mm, and weighs 200 g. It has an activation force of 1.5 pounds.

Cleaning

The device can be wiped clean with a damp cloth.