

Overview

This document contains the necessary information to build the Horizontal Paintbrush Stand.




Figure 1: Horizontal Paintbrush Stands. Variant A on the left, Variant B on the right. Show mounted with a magic arm, a C-Clamp, and a C-Clamp Adapter.



Contents

Overview	
Maker Checklist	
Maker To Do List	
Items to Give to User	
Customization Guide	
3D Printing Guide	6
3D Printing Summary	6
3D Printing Settings – Variant A	6
3D Printing Settings – Variant B	6
Post-Processing	6
Assembly Guide – Variant A	
Required Components	
Required Personal Protective Equipment (PPE)	
Assembly Instructions – Variant A	8
Step A.1	8
Step A.2	
Assembly Guide – Variant B	10
Required Components	10
Required Personal Protective Equipment (PPE)	10
Assembly Instructions – Variant B	11
Step B.1	11
Step B.2	11
Step B.3	12
Step B.4	13
Quality Check	14
Mounting Options	15
Magic Arm + C-Clamp	15
Materials Required	15
Instructions	15

V1.0 | JUNE 2022



Loc-Line + C	Clamp	16
Materials	Required	16
Instructio	ς	17



Maker Checklist

This list provides an overview of the steps required to build and deliver the device to a user.

Maker	To Do List							
	lead through the Maker Guide to become familiar with required components, tools, supplie							
	nd safety gear and overall assembly steps.							
	alk to User about customization options							
	o Variant A or B							
	o Color							
	 Number of brush slots 							
	 Brush slot spacing 							
	 Mounting Options 							
	Jpdate Design if necessary							
	Provide requestor with estimated cost of material and shipping.							
	Order hardware components							
	3D Print components							
	Gather tools, supplies, and safety equipment.							
	Assemble the device							
	Quality check the device							
	Print "User Guide"							
Items t	Give to User							
	Assembled, tested brush stand							
	User Guide"							

V1.0 | JUNE 2022

Horizontal Paintbrush Stand MAKER GUIDE



Customization Guide



3D Printing Guide

3D Printing Summary

Metrics	Variant A	Variant B
Total Print Time (min)	3h14m	9h45m
Total Number of Components	2	12
Typical Total Mass (g)	42	85
Typical Number of Print Setups	1	1

3D Printing Settings – Variant A

Print File Name	Qty	Total Print Time (hr:min)	Mass (g)	Infill (%)	Support(Y/N)	Layer Height/ Nozzle Diameter(mm)	Notes (orientation, special settings, etc.)
_A_Base.stl	1	3h12m	42	20	N	0.2/0.4	
_A_Cap.st	1	0h3m	1	20	N	0.2/0.4	

3D Printing Settings – Variant B

Print File Name	Qty	Total Print Time (hr:min)	Mass (g)	Infill (%)	Support(Y/N)	Layer Height/ Nozzle Diameter(mm)	Notes (orientation, special settings, etc.)
_B_Base1.stl	2	4h25m	39	20	N	0.2/0.4	
_B_Base2.stl	2	4h25m	39	20	N	0.2/0.4	
_B_Nut_Insert.stl	1	0h35m	6	20	N	0.2/0.4	
_B_Cap.stl	1	0h9m	2	20	N	0.2/0.4	
_B_Pin.stl	6	0h9m	2	20	N	0.2/0.4	Better to print separate


Post-Processing

- Remove any burrs. May be painted if desired.



Assembly Guide - Variant A

Required Components




Required Personal Protective Equipment (PPE)

• n/a




Assembly Instructions – Variant A

Step A.1 Insert the Tee Nut into the top of the Base. Use a $\frac{1}{2}$ "-20 Washer and bolt to tighten and secure the Tee Nut into the Base. Nut Holder.






Step A.2
Add the Cap to cover the Tee Nut.





Assembly Guide – Variant B

Required Components



Required Personal Protective Equipment (PPE)


- Eye protection (Superglue)
- Protective Gloves (Superglue)

5. 6X Pins6. 1X Tee Nut7. Superglue




Assembly Instructions – Variant B


Step B.1
Using 4 pins for alignment, use superglue to attach the sides of the bases together.




Step B.2 Insert and glue the 2 remaining pins with the nut insert to secure the two halves.








Step B.3 Insert the Tee Nut from the top. Use a $\frac{1}{4}$ "-20 Washer and bolt to tighten and secure the Tee Nut into the Nut Holder.





Step B.4
Add the Cap to cover the Tee Nut.



V1.0 | JUNE 2022

Horizontal Paintbrush Stand MAKER GUIDE



Quality Check

- 1. Ensure the Tee Nut is installed correctly.
- 2. Check to make sure there are no sharp edges on the stand.



Mounting Options

There Horizontal Brush Stand has a $\frac{1}{2}$ "-20 UNC female thread on the bottom, so it is compatible with a variety of commercial and DIY mounting options.

Magic Arm + C-Clamp

The Magic Arm / Articulating Arm provides a convenient way to adjust the position and orientation of the stand and can be locked in place with a single knob. Using the C-Clamp and C-Clamp Adapter is a cost-effect way of providing a sturdy, non-permanent connection to a table or other work surface. The size of the C-clamp can be chosen to accommodate different table thicknesses.

Materials Required

Magic Arm

https://www.amazon.ca/Koolehaoda-Adjustable-Articulating-Compatible-Microphones/dp/808PC21P2D

C-Clamp

- https://www.homedepot.ca/product/bessey-2-1-2-inch-drop-forged-c-clamp-with-1-3-8-inch-throat-depth/1000816966
- •

C-Clamp Adapter

https://makersmakingchange.com/project/c-clamp-threaded-adapter/

Instructions

- 1. Remove any unneeded hardware from the Magic Arm until just the male thread is left on both side.
- 2. Connect one side of the Magic Arm to the Paintbrush Stand. A locking washer or thread locker can be used to form a more reliable connection.
- 3. Connect the other end of the Magic Arm to the C-Clamp Adapter. A locking washer or thread locker can be used to form a more reliable connection.
- 4. Position the C-Clamp Adapter in an appropriate place on the work surface and use the C-clamp to clamp it in place. To provide better grip or protect the surface, a thin piece of rubber or DYCEM non-slip mat can be used.



Loc-Line + C-Clamp

Materials Required

1/2" Loc-Line Modular Hose (Enough segments to achieve desired length)

- https://www.bulkreefsupply.com/loc-line-modular-hose-segments.html (CAN)
- https://www.amazon.ca/Loc-Line-Coolant-Component-Copolymer-Segment/dp/B006R9ORIY
 (CAN)
- https://www.modularhose.com/ (USA)

1/2" Loc-Line Double Socket (SKU 90614)

- https://www.bulkreefsupply.com/loc-line-double-socket.html, SKU 202755 (CAN)
- https://www.modularhose.com/Loc-Line-90614 (USA)

1/2" Loc-Line Flat Surface/Fixed Mount

- https://www.amazon.ca/Loc-Line-Coolant-Component-Acetal-Copolymer/dp/B006T5JOV6 (CAN)
- https://www.modularhose.com/Loc-Line-51895?quantity=1&custcol_item_colors=8, SKU 51895-Blk (USA)

½" Loc-Line Modular Hose Assembly Pliers (Optional)

- https://www.modularhose.com/Loc-Line-60533?quantity=1&custcol_item_colors=8 (USA)1/2"
 Loc-Line Hose Assembly Pliers (Optional)
- https://www.amazon.ca/Loc-Line-78004-Hose-Assembly-Pliers/dp/B0025PUF1M (CAN)

1/4"-20 UNC SHCS x

C-Clamp

• https://www.homedepot.ca/product/bessey-2-1-2-inch-drop-forged-c-clamp-with-1-3-8-inch-throat-depth/1000816966

C-Clamp Camera Mount Adapter



• https://makersmakingchange.com/project/c-clamp-threaded-adapter/

Instructions

- 1. Attach the ½" Loc-Line Flat Surface/Fixed Mount to the bottom of the Horizontal Brush Stand using a ½"-20 UNC screw and a ½" lock washer.
- 2. Attach the ½" Loc-Line Double Socket to the ½" Loc-Line Flat Surface / Fixed Mount.
- 3. Attach the other $\frac{1}{2}$ " Loc-Line Flat Surface/Fixed Mount to a C-Clamp Camera Mount Adapter using a $\frac{1}{2}$ "-20 UNC screw and a $\frac{1}{2}$ " lock washer.
- 4. Determine how many ½"