

### **Overview**

This document contains the necessary information to switch-adapt a whale bubble blower.

### **Contents**

Overview	1
Maker Checklist	2
Maker To Do List	2
Items to Give to User	2
Tool List	2
Assembly Guide	3
Required Components	3
Required Tools	3
Required Personal Protective Equipment (PPE)	3
Assembly Instructions	4
Step 1	4
Step 2	4
Step 3	5
Step 4	e
Step 5	7
Step 6	7
Step 7	8
Step 8	8
Step 9	g
Step 10	g
Step 11	10
Testing	10



### **Maker Checklist**


This list provides an overview of the steps required to build and deliver the device.

Maker	To Do List
	Read through the Maker Guide to become familiar with required components, tools, supplies,
	and safety gear and overall assembly steps.
	Order hardware components
	Gather tools, supplies, and safety equipment.
	Assemble the device
	Test device
	Print "User Quick Guide"
Items	to Give to User
	Assembled, tested device
	"User Quick Guide"
Tool List	
	Drill and ¼" drill bit
	Soldering iron
	Solder
	Phillips screwdriver (included with the bubble blower)
	Wire cutters
	Wire strippers
	Ruler



### **Assembly Guide**

### **Required Components**



#### **BOM**

- Whale bubble blower
- 2. 3.5 mm mono jack
- 3. 22 AWG wire

### **Required Tools**

- Drill and ¼" drill bit
- Soldering iron
- Solder
- Phillips screwdriver (included with the bubble blower)
- Wire cutters
- Wire strippers
- Ruler

### Required Personal Protective Equipment (PPE)

Safety glasses




### **Assembly Instructions**

Step 1
Cut two 8 cm lengths of wire.



Step 2
Strip 0.5 cm of the insulation off each end of the wires.





Step 3

Unscrew the 6 screws in the whale and separate the top and bottom halves. The location of the 6 screws are circled in the picture. Note that the 2 screws in the tail are shorter than the other 4 in the body.






Step 4
Drill a ¼" hole in the side of the top half of whale.




Step 5
Cut the white wire that is connected to original switch, located on one of the whale's fins, and strip off 1 cm of insulation off the ends of the wire. Be careful when stripping the insulation as the wire inside is quite thin.






Step 6
Twist the two ends of the white wire back together, and twist one end of one of the 8 cm long wires around the exposed section of white wire.



Step 7
Solder the twisted together wires, then wrap the connection in electrical tape.




© 2022 by Neil Squire.



Step 8

Solder the second 8 cm long wire to the tab on the battery power connection as shown. The original red wire from the toy may disconnect from the tab. If that happens, simply solder it back in place.



Step 9
Solder one of the 8 cm long wires to the first leg of the mono jack, then solder the second wire to the second leg of the mono jack.





### Step 10

Test the switch adapt and original switch to make sure everything works properly before reassembling the whale. Add batteries into the whale (4 AA batteries), then plug an assistive switch into the mono jack. Make sure all wires are away from the spinning wands and fan. Press the original button to make sure it still works. The bubble wands should rotate and air should be blown through them when the button is pressed, then stop when it is pressed again. Plug a switch into the mono jack and press and hold the switch. The bubble wands should rotate and air should be blown through them while the switch is held and stop when it is released. Take the batteries out of the whale after testing.

#### Step 11


Remove the nut from the mono jack and push the mono jack through the hole from the inside. Reinstall the nut and tighten to secure the mono jack.



Step 12

Reassemble the whale and screw it back together with the 6 screws. The two shortest screws go into the tail. Make sure the wires do not touch the bubble wands or fan at the back of the whale.





Step 13
Put the whale and the provided screwdriver back into the original packaging.



### **Testing**

Put batteries into the whale. Press the original button to make sure it still works. The bubble wands should rotate and air should be blown through them when the button is pressed, then stop when it is pressed again. Plug a switch into the mono jack and press and hold the switch. The bubble wands should rotate and air should be blown through them while the switch is held and stop when it is released. Take the batteries out of the whale after testing so it does not turn on during shipping.