



































Schrittmotor	Wicklung	Farbe	Buchse 4P	Stecker 9P		Sensor Notaus	
A (A+)	1	SW	1	6			
C (A-)	ı	gn	2	7			
B (B+)	2	rt	3	8			
D (B-)	۷	bl	4	9			
							old
GND (Sig-)				1	Sensor	1	1
Signal +	Endsrtop XYZ			3	Selisoi	3	6
Signal -				4			
(+V) [12V]				5			
12V →					NotAus	4	4
12V ←					NOLAUS	5	5
GND						7	-
SSR -					Absaugung	8	-
SSR auto						9	-