

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO0A0	IOMUX	RTC_32K_OUT	0x201B0000	[0,3]	1	io -4 0x201B0000 0x000F0001
		CLK_32K	0x201B0000	[0,3]	2	io -4 0x201B0000 0x000F0002
		CLK_24M_OUT	0x201B0000	[0,3]	3	io -4 0x201B0000 0x000F0003
		FSPI1_CLK	0x201B0000	[0,3]	4	io -4 0x201B0000 0x000F0004
		GPIO0_A0	0x201B0000	[0,3]	0	io -4 0x201B0000 0x000F0000
	Pull	z	0x201B0200	[0,1]	0	io -4 0x201B0200 0x00030000
		up	0x201B0200	[0,1]	1	io -4 0x201B0200 0x00030001
		down	0x201B0200	[0,1]	2	io -4 0x201B0200 0x00030002
	I/O Mode	input	0x20520008	[0,0]	0	io -4 0x20520008 0x00010000
		output	0x20520008	[0,0]	1	io -4 0x20520008 0x00010001
	Output	low	0x20520000	[0,0]	0	io -4 0x20520000 0x00010000
		high	0x20520000	[0,0]	1	io -4 0x20520000 0x00010001
	Input Ctrl	disable	0x201B0300	[0,0]	0	io -4 0x201B0300 0x00010000
		enable	0x201B0300	[0,0]	1	io -4 0x201B0300 0x00010001
	Schmitt	disable	0x201B0400	[0,0]	0	io -4 0x201B0400 0x00010000
		enable	0x201B0400	[0,0]	1	io -4 0x201B0400 0x00010001
	Drive Strength	level0	0x201B0100	[0,5]	1	io -4 0x201B0100 0x003F0001
		level1	0x201B0100	[0,5]	3	io -4 0x201B0100 0x003F0003
		level2	0x201B0100	[0,5]	7	io -4 0x201B0100 0x003F0007
		level3	0x201B0100	[0,5]	15	io -4 0x201B0100 0x003F000F
		level4	0x201B0100	[0,5]	31	io -4 0x201B0100 0x003F001F
		level5	0x201B0100	[0,5]	63	io -4 0x201B0100 0x003F003F
	ExtPort	read gpio data in input mode	0x20520070	[0,0]		io -4 0x20520070
GPIO0A1	IOMUX	PWM0_CH0_M0	0x201B0000	[4,7]	1	io -4 0x201B0000 0x00F00010
		CPU_AVS	0x201B0000	[4,7]	2	io -4 0x201B0000 0x00F00020
		FSPI1_D1	0x201B0000	[4,7]	4	io -4 0x201B0000 0x00F00040
		GPIO0_A1	0x201B0000	[4,7]	0	io -4 0x201B0000 0x00F00000
		z	0x201B0200	[2,3]	0	io -4 0x201B0200 0x000C0000
	Pull	up	0x201B0200	[2,3]	1	io -4 0x201B0200 0x000C0004
		down	0x201B0200	[2,3]	2	io -4 0x201B0200 0x000C0008
	I/O Mode	input	0x20520008	[1,1]	0	io -4 0x20520008 0x00020000
		output	0x20520008	[1,1]	1	io -4 0x20520008 0x00020002
	Output	low	0x20520000	[1,1]	0	io -4 0x20520000 0x00020000
		high	0x20520000	[1,1]	1	io -4 0x20520000 0x00020002
	Input Ctrl	disable	0x201B0300	[1,1]	0	io -4 0x201B0300 0x00020000
		enable	0x201B0300	[1,1]	1	io -4 0x201B0300 0x00020002
	Schmitt	disable	0x201B0400	[1,1]	0	io -4 0x201B0400 0x00020000
		enable	0x201B0400	[1,1]	1	io -4 0x201B0400 0x00020002
	Drive Strength	level0	0x201B0100	[8,13]	1	io -4 0x201B0100 0x3F000100
		level1	0x201B0100	[8,13]	3	io -4 0x201B0100 0x3F000300
		level2	0x201B0100	[8,13]	7	io -4 0x201B0100 0x3F000700
		level3	0x201B0100	[8,13]	15	io -4 0x201B0100 0x3F000F00
		level4	0x201B0100	[8,13]	31	io -4 0x201B0100 0x3F001F00
		level5	0x201B0100	[8,13]	63	io -4 0x201B0100 0x3F003F00
	ExtPort	read gpio data in input mode	0x20520070	[1,1]		io -4 0x20520070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO0A2	IOMUX	PWM0_CH3_M0	0x201B0000	[8,11]	1	io -4 0x201B0000 0x0F000100
		FSPI1_D0	0x201B0000	[8,11]	4	io -4 0x201B0000 0x0F000400
		GPIO0_A2	0x201B0000	[8,11]	0	io -4 0x201B0000 0x0F000000
	Pull	z	0x201B0200	[4,5]	0	io -4 0x201B0200 0x00300000
		up	0x201B0200	[4,5]	1	io -4 0x201B0200 0x00300010
		down	0x201B0200	[4,5]	2	io -4 0x201B0200 0x00300020
	I/O Mode	input	0x20520008	[2,2]	0	io -4 0x20520008 0x00040000
		output	0x20520008	[2,2]	1	io -4 0x20520008 0x00040004
	Output	low	0x20520000	[2,2]	0	io -4 0x20520000 0x00040000
		high	0x20520000	[2,2]	1	io -4 0x20520000 0x00040004
	Input Ctrl	disable	0x201B0300	[2,2]	0	io -4 0x201B0300 0x00040000
		enable	0x201B0300	[2,2]	1	io -4 0x201B0300 0x00040004
	Schmitt	disable	0x201B0400	[2,2]	0	io -4 0x201B0400 0x00040000
		enable	0x201B0400	[2,2]	1	io -4 0x201B0400 0x00040004
	Drive Strength	level0	0x201B0104	[0,5]	1	io -4 0x201B0104 0x003F0001
		level1	0x201B0104	[0,5]	3	io -4 0x201B0104 0x003F0003
		level2	0x201B0104	[0,5]	7	io -4 0x201B0104 0x003F0007
		level3	0x201B0104	[0,5]	15	io -4 0x201B0104 0x003F000F
		level4	0x201B0104	[0,5]	31	io -4 0x201B0104 0x003F001F
		level5	0x201B0104	[0,5]	63	io -4 0x201B0104 0x003F003F
	ExtPort	read gpio data in input mode	0x20520070	[2,2]		io -4 0x20520070
GPIO0A3	IOMUX	PWR_CTRL0	0x201B0000	[12,15]	1	io -4 0x201B0000 0xF0001000
		GPIO0_A3	0x201B0000	[12,15]	0	io -4 0x201B0000 0xF0000000
	Pull	z	0x201B0200	[6,7]	0	io -4 0x201B0200 0x00C00000
		up	0x201B0200	[6,7]	1	io -4 0x201B0200 0x00C00040
		down	0x201B0200	[6,7]	2	io -4 0x201B0200 0x00C00080
	I/O Mode	input	0x20520008	[3,3]	0	io -4 0x20520008 0x00080000
		output	0x20520008	[3,3]	1	io -4 0x20520008 0x00080008
	Output	low	0x20520000	[3,3]	0	io -4 0x20520000 0x00080000
		high	0x20520000	[3,3]	1	io -4 0x20520000 0x00080008
	Input Ctrl	disable	0x201B0300	[3,3]	0	io -4 0x201B0300 0x00080000
		enable	0x201B0300	[3,3]	1	io -4 0x201B0300 0x00080008
	Schmitt	disable	0x201B0400	[3,3]	0	io -4 0x201B0400 0x00080000
		enable	0x201B0400	[3,3]	1	io -4 0x201B0400 0x00080008
	Drive Strength	level0	0x201B0104	[8,13]	1	io -4 0x201B0104 0x3F000100
		level1	0x201B0104	[8,13]	3	io -4 0x201B0104 0x3F000300
		level2	0x201B0104	[8,13]	7	io -4 0x201B0104 0x3F000700
		level3	0x201B0104	[8,13]	15	io -4 0x201B0104 0x3F000F00
		level4	0x201B0104	[8,13]	31	io -4 0x201B0104 0x3F001F00
		level5	0x201B0104	[8,13]	63	io -4 0x201B0104 0x3F003F00
	ExtPort	read gpio data in input mode	0x20520070	[3,3]		io -4 0x20520070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO0A4	IOMUX	PWR_CTRL1	0x201B0004	[0,3]	1	io -4 0x201B0004 0x000F0001
		FSPI1_CSN	0x201B0004	[0,3]	4	io -4 0x201B0004 0x000F0004
		GPIO0_A4	0x201B0004	[0,3]	0	io -4 0x201B0004 0x000F0000
	Pull	z	0x201B0200	[8,9]	0	io -4 0x201B0200 0x03000000
		up	0x201B0200	[8,9]	1	io -4 0x201B0200 0x03000100
		down	0x201B0200	[8,9]	2	io -4 0x201B0200 0x03000200
	I/O Mode	input	0x20520008	[4,4]	0	io -4 0x20520008 0x00100000
		output	0x20520008	[4,4]	1	io -4 0x20520008 0x00100010
	Output	low	0x20520000	[4,4]	0	io -4 0x20520000 0x00100000
		high	0x20520000	[4,4]	1	io -4 0x20520000 0x00100010
	Input Ctrl	disable	0x201B0300	[4,4]	0	io -4 0x201B0300 0x00100000
		enable	0x201B0300	[4,4]	1	io -4 0x201B0300 0x00100010
	Schmitt	disable	0x201B0400	[4,4]	0	io -4 0x201B0400 0x00100000
		enable	0x201B0400	[4,4]	1	io -4 0x201B0400 0x00100010
	Drive Strength	level0	0x201B0108	[0,5]	1	io -4 0x201B0108 0x003F0001
		level1	0x201B0108	[0,5]	3	io -4 0x201B0108 0x003F0003
		level2	0x201B0108	[0,5]	7	io -4 0x201B0108 0x003F0007
		level3	0x201B0108	[0,5]	15	io -4 0x201B0108 0x003F000F
		level4	0x201B0108	[0,5]	31	io -4 0x201B0108 0x003F001F
		level5	0x201B0108	[0,5]	63	io -4 0x201B0108 0x003F003F
	ExtPort	read gpio data in input mode	0x20520070	[4,4]		io -4 0x20520070
GPIO0A5	IOMUX	UART0_TX_M0	0x201B0004	[4,7]	1	io -4 0x201B0004 0x00F00010
		PWM0_CH1_M0	0x201B0004	[4,7]	2	io -4 0x201B0004 0x00F00020
		I2C0_SCL_M0	0x201B0004	[4,7]	3	io -4 0x201B0004 0x00F00030
		FSPI1_D2	0x201B0004	[4,7]	4	io -4 0x201B0004 0x00F00040
		JTAG_TCK_M0	0x201B0004	[4,7]	5	io -4 0x201B0004 0x00F00050
		GPIO0_A5	0x201B0004	[4,7]	0	io -4 0x201B0004 0x00F00000
	Pull	z	0x201B0200	[10,11]	0	io -4 0x201B0200 0x0C000000
		up	0x201B0200	[10,11]	1	io -4 0x201B0200 0x0C000400
		down	0x201B0200	[10,11]	2	io -4 0x201B0200 0x0C000800
	I/O Mode	input	0x20520008	[5,5]	0	io -4 0x20520008 0x00200000
		output	0x20520008	[5,5]	1	io -4 0x20520008 0x00200020
	Output	low	0x20520000	[5,5]	0	io -4 0x20520000 0x00200000
		high	0x20520000	[5,5]	1	io -4 0x20520000 0x00200020
	Input Ctrl	disable	0x201B0300	[5,5]	0	io -4 0x201B0300 0x00200000
		enable	0x201B0300	[5,5]	1	io -4 0x201B0300 0x00200020
	Schmitt	disable	0x201B0400	[5,5]	0	io -4 0x201B0400 0x00200000
		enable	0x201B0400	[5,5]	1	io -4 0x201B0400 0x00200020
	Drive Strength	level0	0x201B0108	[8,13]	1	io -4 0x201B0108 0x3F000100
		level1	0x201B0108	[8,13]	3	io -4 0x201B0108 0x3F000300
		level2	0x201B0108	[8,13]	7	io -4 0x201B0108 0x3F000700
		level3	0x201B0108	[8,13]	15	io -4 0x201B0108 0x3F000F00
		level4	0x201B0108	[8,13]	31	io -4 0x201B0108 0x3F001F00
		level5	0x201B0108	[8,13]	63	io -4 0x201B0108 0x3F003F00
	ExtPort	read gpio data in input mode	0x20520070	[5,5]		io -4 0x20520070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO0A6	IOMUX	UART0_RX_M0	0x201B0004	[8,11]	1	io -4 0x201B0004 0x0F000100
		PWM0_CH2_M0	0x201B0004	[8,11]	2	io -4 0x201B0004 0x0F000200
		I2C0_SDA_M0	0x201B0004	[8,11]	3	io -4 0x201B0004 0x0F000300
		FSPI1_D3	0x201B0004	[8,11]	4	io -4 0x201B0004 0x0F000400
		JTAG_TMS_M0	0x201B0004	[8,11]	5	io -4 0x201B0004 0x0F000500
		GPIO0_A6	0x201B0004	[8,11]	0	io -4 0x201B0004 0x0F000000
	Pull	z	0x201B0200	[12,13]	0	io -4 0x201B0200 0x30000000
		up	0x201B0200	[12,13]	1	io -4 0x201B0200 0x30001000
		down	0x201B0200	[12,13]	2	io -4 0x201B0200 0x30002000
	I/O Mode	input	0x20520008	[6,6]	0	io -4 0x20520008 0x00400000
		output	0x20520008	[6,6]	1	io -4 0x20520008 0x00400040
	Output	low	0x20520000	[6,6]	0	io -4 0x20520000 0x00400000
		high	0x20520000	[6,6]	1	io -4 0x20520000 0x00400040
	Input Ctrl	disable	0x201B0300	[6,6]	0	io -4 0x201B0300 0x00400000
		enable	0x201B0300	[6,6]	1	io -4 0x201B0300 0x00400040
	Schmitt	disable	0x201B0400	[6,6]	0	io -4 0x201B0400 0x00400000
		enable	0x201B0400	[6,6]	1	io -4 0x201B0400 0x00400040
	Drive Strength	level0	0x201B010C	[0,5]	1	io -4 0x201B010C 0x003F0001
		level1	0x201B010C	[0,5]	3	io -4 0x201B010C 0x003F0003
		level2	0x201B010C	[0,5]	7	io -4 0x201B010C 0x003F0007
		level3	0x201B010C	[0,5]	15	io -4 0x201B010C 0x003F000F
		level4	0x201B010C	[0,5]	31	io -4 0x201B010C 0x003F001F
		level5	0x201B010C	[0,5]	63	io -4 0x201B010C 0x003F003F
	ExtPort	read gpio data in input mode	0x20520070	[6,6]		io -4 0x20520070
GPIO1A0	IOMUX	EMMC_D3	0x20170020	[0,3]	1	io -4 0x20170020 0x000F0001
		FSPI0_D3	0x20170020	[0,3]	2	io -4 0x20170020 0x000F0002
		GPIO1_A0	0x20170020	[0,3]	0	io -4 0x20170020 0x000F0000
	Pull	z	0x20170210	[0,1]	0	io -4 0x20170210 0x00030000
		up	0x20170210	[0,1]	1	io -4 0x20170210 0x00030001
		down	0x20170210	[0,1]	2	io -4 0x20170210 0x00030002
	I/O Mode	input	0x20D80008	[0,0]	0	io -4 0x20D80008 0x00010000
		output	0x20D80008	[0,0]	1	io -4 0x20D80008 0x00010001
	Output	low	0x20D80000	[0,0]	0	io -4 0x20D80000 0x00010000
		high	0x20D80000	[0,0]	1	io -4 0x20D80000 0x00010001
	Input Ctrl	disable	0x20170310	[0,0]	0	io -4 0x20170310 0x00010000
		enable	0x20170310	[0,0]	1	io -4 0x20170310 0x00010001
	Schmitt	disable	0x20170410	[0,0]	0	io -4 0x20170410 0x00010000
		enable	0x20170410	[0,0]	1	io -4 0x20170410 0x00010001
	Drive Strength	level0	0x20170140	[0,5]	1	io -4 0x20170140 0x003F0001
		level1	0x20170140	[0,5]	3	io -4 0x20170140 0x003F0003
		level2	0x20170140	[0,5]	7	io -4 0x20170140 0x003F0007
		level3	0x20170140	[0,5]	15	io -4 0x20170140 0x003F000F
		level4	0x20170140	[0,5]	31	io -4 0x20170140 0x003F001F
		level5	0x20170140	[0,5]	63	io -4 0x20170140 0x003F003F
	ExtPort	read gpio data in input mode	0x20D80070	[0,0]		io -4 0x20D80070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO1A1	IOMUX	EMMC D0	0x20170020	[4, 7]	1	io -4 0x20170020 0x00F00010
		FSPI0 D0	0x20170020	[4, 7]	2	io -4 0x20170020 0x00F00020
		GPIO1 A1	0x20170020	[4, 7]	0	io -4 0x20170020 0x00F00000
	Pull	z	0x20170210	[2, 3]	0	io -4 0x20170210 0x000C0000
		up	0x20170210	[2, 3]	1	io -4 0x20170210 0x000C0004
		down	0x20170210	[2, 3]	2	io -4 0x20170210 0x000C0008
	I/O Mode	input	0x20D80008	[1, 1]	0	io -4 0x20D80008 0x00020000
		output	0x20D80008	[1, 1]	1	io -4 0x20D80008 0x00020002
	Output	low	0x20D80000	[1, 1]	0	io -4 0x20D80000 0x00020000
		high	0x20D80000	[1, 1]	1	io -4 0x20D80000 0x00020002
	Input Ctrl	disable	0x20170310	[1, 1]	0	io -4 0x20170310 0x00020000
		enable	0x20170310	[1, 1]	1	io -4 0x20170310 0x00020002
	Schmitt	disable	0x20170410	[1, 1]	0	io -4 0x20170410 0x00020000
		enable	0x20170410	[1, 1]	1	io -4 0x20170410 0x00020002
	Drive Strength	level0	0x20170140	[8, 13]	1	io -4 0x20170140 0x3F000100
		level1	0x20170140	[8, 13]	3	io -4 0x20170140 0x3F000300
		level2	0x20170140	[8, 13]	7	io -4 0x20170140 0x3F000700
		level3	0x20170140	[8, 13]	15	io -4 0x20170140 0x3F000F00
		level4	0x20170140	[8, 13]	31	io -4 0x20170140 0x3F001F00
		level5	0x20170140	[8, 13]	63	io -4 0x20170140 0x3F003F00
	ExtPort	read gpio data in input mode	0x20D80070	[1, 1]		io -4 0x20D80070
GPIO1A2	IOMUX	EMMC D1	0x20170020	[8, 11]	1	io -4 0x20170020 0x0F000100
		FSPI0 D1	0x20170020	[8, 11]	2	io -4 0x20170020 0x0F000200
		GPIO1 A2	0x20170020	[8, 11]	0	io -4 0x20170020 0x0F000000
	Pull	z	0x20170210	[4, 5]	0	io -4 0x20170210 0x00300000
		up	0x20170210	[4, 5]	1	io -4 0x20170210 0x00300010
		down	0x20170210	[4, 5]	2	io -4 0x20170210 0x00300020
	I/O Mode	input	0x20D80008	[2, 2]	0	io -4 0x20D80008 0x00040000
		output	0x20D80008	[2, 2]	1	io -4 0x20D80008 0x00040004
	Output	low	0x20D80000	[2, 2]	0	io -4 0x20D80000 0x00040000
		high	0x20D80000	[2, 2]	1	io -4 0x20D80000 0x00040004
	Input Ctrl	disable	0x20170310	[2, 2]	0	io -4 0x20170310 0x00040000
		enable	0x20170310	[2, 2]	1	io -4 0x20170310 0x00040004
	Schmitt	disable	0x20170410	[2, 2]	0	io -4 0x20170410 0x00040000
		enable	0x20170410	[2, 2]	1	io -4 0x20170410 0x00040004
	Drive Strength	level0	0x20170144	[0, 5]	1	io -4 0x20170144 0x003F0001
		level1	0x20170144	[0, 5]	3	io -4 0x20170144 0x003F0003
		level2	0x20170144	[0, 5]	7	io -4 0x20170144 0x003F0007
		level3	0x20170144	[0, 5]	15	io -4 0x20170144 0x003F000F
		level4	0x20170144	[0, 5]	31	io -4 0x20170144 0x003F001F
		level5	0x20170144	[0, 5]	63	io -4 0x20170144 0x003F003F
	ExtPort	read gpio data in input mode	0x20D80070	[2, 2]		io -4 0x20D80070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO1A3	IOMUX	EMMC D2	0x20170020	[12, 15]	1	io -4 0x20170020 0xF0001000
		FSPI0 D2	0x20170020	[12, 15]	2	io -4 0x20170020 0xF0002000
		GPIO1 A3	0x20170020	[12, 15]	0	io -4 0x20170020 0xF0000000
	Pull	z	0x20170210	[6, 6]	0	io -4 0x20170210 0x00400000
		up	0x20170210	[6, 6]	1	io -4 0x20170210 0x00400040
		down	0x20170210	[6, 6]	0	io -4 0x20170210 0x00400080
	I/O Mode	input	0x20D80008	[3, 3]	0	io -4 0x20D80008 0x00080000
		output	0x20D80008	[3, 3]	1	io -4 0x20D80008 0x00080008
	Output	low	0x20D80000	[3, 3]	0	io -4 0x20D80000 0x00080000
		high	0x20D80000	[3, 3]	1	io -4 0x20D80000 0x00080008
	Input Ctrl	disable	0x20170310	[3, 3]	0	io -4 0x20170310 0x00080000
		enable	0x20170310	[3, 3]	1	io -4 0x20170310 0x00080008
	Schmitt	disable	0x20170410	[3, 3]	0	io -4 0x20170410 0x00080000
		enable	0x20170410	[3, 3]	1	io -4 0x20170410 0x00080008
	Drive Strength	level0	0x20170144	[8, 13]	1	io -4 0x20170144 0x3F000100
		level1	0x20170144	[8, 13]	3	io -4 0x20170144 0x3F000300
		level2	0x20170144	[8, 13]	7	io -4 0x20170144 0x3F000700
		level3	0x20170144	[8, 13]	15	io -4 0x20170144 0x3F000F00
		level4	0x20170144	[8, 13]	31	io -4 0x20170144 0x3F001F00
		level5	0x20170144	[8, 13]	63	io -4 0x20170144 0x3F003F00
	ExtPort	read gpio data in input mode	0x20D80070	[3, 3]		io -4 0x20D80070
GPIO1A4	IOMUX	EMMC CLK	0x20170024	[0, 3]	1	io -4 0x20170024 0x000F0001
		FSPI0 CLK	0x20170024	[0, 3]	2	io -4 0x20170024 0x000F0002
		GPIO1 A4	0x20170024	[0, 3]	0	io -4 0x20170024 0x000F0000
	Pull	z	0x20170210	[8, 9]	0	io -4 0x20170210 0x03000000
		up	0x20170210	[8, 9]	1	io -4 0x20170210 0x03000100
		down	0x20170210	[8, 9]	2	io -4 0x20170210 0x03000200
	I/O Mode	input	0x20D80008	[4, 4]	0	io -4 0x20D80008 0x00100000
		output	0x20D80008	[4, 4]	1	io -4 0x20D80008 0x00100010
	Output	low	0x20D80000	[4, 4]	0	io -4 0x20D80000 0x00100000
		high	0x20D80000	[4, 4]	1	io -4 0x20D80000 0x00100010
	Input Ctrl	disable	0x20170310	[4, 4]	0	io -4 0x20170310 0x00100000
		enable	0x20170310	[4, 4]	1	io -4 0x20170310 0x00100010
	Schmitt	disable	0x20170410	[4, 4]	0	io -4 0x20170410 0x00100000
		enable	0x20170410	[4, 4]	1	io -4 0x20170410 0x00100010
	Drive Strength	level0	0x20170148	[0, 5]	1	io -4 0x20170148 0x003F0001
		level1	0x20170148	[0, 5]	3	io -4 0x20170148 0x003F0003
		level2	0x20170148	[0, 5]	7	io -4 0x20170148 0x003F0007
		level3	0x20170148	[0, 5]	15	io -4 0x20170148 0x003F000F
		level4	0x20170148	[0, 5]	31	io -4 0x20170148 0x003F001F
		level5	0x20170148	[0, 5]	63	io -4 0x20170148 0x003F003F
	ExtPort	read gpio data in input mode	0x20D80070	[4, 4]		io -4 0x20D80070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO1A5	IOMUX	EMMC_CMD	0x20170024	[4, 7]	1	io -4 0x20170024 0x00F00010
		FSPI0_CSN	0x20170024	[4, 7]	2	io -4 0x20170024 0x00F00020
		GPIO1_A5	0x20170024	[4, 7]	0	io -4 0x20170024 0x00F00000
	Pull	z	0x20170210	[10, 11]	0	io -4 0x20170210 0x0C000000
		up	0x20170210	[10, 11]	1	io -4 0x20170210 0x0C000400
		down	0x20170210	[10, 11]	2	io -4 0x20170210 0x0C000800
	I/O Mode	input	0x20D80008	[5, 5]	0	io -4 0x20D80008 0x00200000
		output	0x20D80008	[5, 5]	1	io -4 0x20D80008 0x00200020
	Output	low	0x20D80000	[5, 5]	0	io -4 0x20D80000 0x00200000
		high	0x20D80000	[5, 5]	1	io -4 0x20D80000 0x00200020
	Input Ctrl	disable	0x20170310	[5, 5]	0	io -4 0x20170310 0x00200000
		enable	0x20170310	[5, 5]	1	io -4 0x20170310 0x00200020
	Schmitt	disable	0x20170410	[5, 5]	0	io -4 0x20170410 0x00200000
		enable	0x20170410	[5, 5]	1	io -4 0x20170410 0x00200020
	Drive Strength	level0	0x20170148	[8, 13]	1	io -4 0x20170148 0x3F000100
		level1	0x20170148	[8, 13]	3	io -4 0x20170148 0x3F000300
		level2	0x20170148	[8, 13]	7	io -4 0x20170148 0x3F000700
		level3	0x20170148	[8, 13]	15	io -4 0x20170148 0x3F000F00
		level4	0x20170148	[8, 13]	31	io -4 0x20170148 0x3F001F00
		level5	0x20170148	[8, 13]	63	io -4 0x20170148 0x3F003F00
	ExtPort	read gpio data in input mode	0x20D80070	[5, 5]		io -4 0x20D80070
GPIO1A6	IOMUX	GPIO1_A6	0x20180024	[8, 11]	0	io -4 0x20180024 0x0F000000
	Pull	z	0x20180210	[12, 13]	0	io -4 0x20180210 0x30000000
		up	0x20180210	[12, 13]	1	io -4 0x20180210 0x30001000
		down	0x20180210	[12, 13]	2	io -4 0x20180210 0x30002000
	I/O Mode	input	0x20D80008	[6, 6]	0	io -4 0x20D80008 0x00400000
		output	0x20D80008	[6, 6]	1	io -4 0x20D80008 0x00400040
	Output	low	0x20D80000	[6, 6]	0	io -4 0x20D80000 0x00400000
		high	0x20D80000	[6, 6]	1	io -4 0x20D80000 0x00400040
	Input Ctrl	disable	0x20180310	[6, 6]	0	io -4 0x20180310 0x00400000
		enable	0x20180310	[6, 6]	1	io -4 0x20180310 0x00400040
	Schmitt	disable	0x20180410	[6, 6]	0	io -4 0x20180410 0x00400000
		enable	0x20180410	[6, 6]	1	io -4 0x20180410 0x00400040
	Drive Strength	level0	0x2018014C	[0, 5]	1	io -4 0x2018014C 0x003F0001
		level1	0x2018014C	[0, 5]	3	io -4 0x2018014C 0x003F0003
		level2	0x2018014C	[0, 5]	7	io -4 0x2018014C 0x003F0007
		level3	0x2018014C	[0, 5]	15	io -4 0x2018014C 0x003F000F
		level4	0x2018014C	[0, 5]	31	io -4 0x2018014C 0x003F001F
		level5	0x2018014C	[0, 5]	63	io -4 0x2018014C 0x003F003F
	ExtPort	read gpio data in input mode	0x20D80070	[6, 6]		io -4 0x20D80070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO1A7	IOMUX	SDMMCO D1	0x20180024	[12, 15]	1	io -4 0x20180024 0xF0001000
		UART1_RX M1	0x20180024	[12, 15]	2	io -4 0x20180024 0xF0002000
		PWM2_CH1 M0	0x20180024	[12, 15]	4	io -4 0x20180024 0xF0004000
		GPIO1_A7	0x20180024	[12, 15]	0	io -4 0x20180024 0xF0000000
	Pull	z	0x20180210	[14, 15]	0	io -4 0x20180210 0xC0000000
		up	0x20180210	[14, 15]	1	io -4 0x20180210 0xC0004000
		down	0x20180210	[14, 15]	2	io -4 0x20180210 0xC0008000
	I/O Mode	input	0x20D80008	[7, 7]	0	io -4 0x20D80008 0x00800000
		output	0x20D80008	[7, 7]	1	io -4 0x20D80008 0x00800080
	Output	low	0x20D80000	[7, 7]	0	io -4 0x20D80000 0x00800000
		high	0x20D80000	[7, 7]	1	io -4 0x20D80000 0x00800080
	Input Ctrl	disable	0x20180310	[7, 7]	0	io -4 0x20180310 0x00800000
		enable	0x20180310	[7, 7]	1	io -4 0x20180310 0x00800080
	Schmitt	disable	0x20180410	[7, 7]	0	io -4 0x20180410 0x00800000
		enable	0x20180410	[7, 7]	1	io -4 0x20180410 0x00800080
	Drive Strength	level0	0x2018014C	[8, 13]	1	io -4 0x2018014C 0x3F000100
		level1	0x2018014C	[8, 13]	3	io -4 0x2018014C 0x3F000300
		level2	0x2018014C	[8, 13]	7	io -4 0x2018014C 0x3F000700
		level3	0x2018014C	[8, 13]	15	io -4 0x2018014C 0x3F000F00
		level4	0x2018014C	[8, 13]	31	io -4 0x2018014C 0x3F001F00
		level5	0x2018014C	[8, 13]	63	io -4 0x2018014C 0x3F003F00
	ExtPort	read gpio data in input mode	0x20D80070	[7, 7]		io -4 0x20D80070
GPIO1B0	IOMUX	SDMMCO D0	0x20180028	[0, 3]	1	io -4 0x20180028 0x000F0001
		UART1_TX M1	0x20180028	[0, 3]	2	io -4 0x20180028 0x000F0002
		PWM2_CH0 M0	0x20180028	[0, 3]	4	io -4 0x20180028 0x000F0004
		GPIO1_B0	0x20180028	[0, 3]	0	io -4 0x20180028 0x000F0000
	Pull	z	0x20180214	[0, 1]	0	io -4 0x20180214 0x00030000
		up	0x20180214	[0, 1]	1	io -4 0x20180214 0x00030001
		down	0x20180214	[0, 1]	2	io -4 0x20180214 0x00030002
	I/O Mode	input	0x20D80008	[8, 8]	0	io -4 0x20D80008 0x01000000
		output	0x20D80008	[8, 8]	1	io -4 0x20D80008 0x01000100
	Output	low	0x20D80000	[8, 8]	0	io -4 0x20D80000 0x01000000
		high	0x20D80000	[8, 8]	1	io -4 0x20D80000 0x01000100
	Input Ctrl	disable	0x20180314	[0, 0]	0	io -4 0x20180314 0x00010000
		enable	0x20180314	[0, 0]	1	io -4 0x20180314 0x00010001
	Schmitt	disable	0x20180414	[0, 0]	0	io -4 0x20180414 0x00010000
		enable	0x20180414	[0, 0]	1	io -4 0x20180414 0x00010001
	Drive Strength	level0	0x20180150	[0, 5]	1	io -4 0x20180150 0x003F0001
		level1	0x20180150	[0, 5]	3	io -4 0x20180150 0x003F0003
		level2	0x20180150	[0, 5]	7	io -4 0x20180150 0x003F0007
		level3	0x20180150	[0, 5]	15	io -4 0x20180150 0x003F000F
		level4	0x20180150	[0, 5]	31	io -4 0x20180150 0x003F001F
		level5	0x20180150	[0, 5]	63	io -4 0x20180150 0x003F003F
	ExtPort	read gpio data in input mode	0x20D80070	[8, 8]		io -4 0x20D80070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO1B1	IOMUX	SDMMC0_CLK	0x20180028	[4, 7]	1	io -4 0x20180028 0x00F00010
		UART1_RTSN_M1	0x20180028	[4, 7]	2	io -4 0x20180028 0x00F00020
		GPIO1_B1	0x20180028	[4, 7]	0	io -4 0x20180028 0x00F00000
	Pull	z	0x20180214	[2, 3]	0	io -4 0x20180214 0x000C0000
		up	0x20180214	[2, 3]	1	io -4 0x20180214 0x000C0004
		down	0x20180214	[2, 3]	2	io -4 0x20180214 0x000C0008
	I/O Mode	input	0x20D80008	[9, 9]	0	io -4 0x20D80008 0x02000000
		output	0x20D80008	[9, 9]	1	io -4 0x20D80008 0x02000200
	Output	low	0x20D80000	[9, 9]	0	io -4 0x20D80000 0x02000000
		high	0x20D80000	[9, 9]	1	io -4 0x20D80000 0x02000200
	Input Ctrl	disable	0x20180314	[1, 1]	0	io -4 0x20180314 0x00020000
		enable	0x20180314	[1, 1]	1	io -4 0x20180314 0x00020002
	Schmitt	disable	0x20180414	[1, 1]	0	io -4 0x20180414 0x00020000
		enable	0x20180414	[1, 1]	1	io -4 0x20180414 0x00020002
	Drive Strength	level0	0x20180150	[8, 13]	1	io -4 0x20180150 0x3F000100
		level1	0x20180150	[8, 13]	3	io -4 0x20180150 0x3F000300
		level2	0x20180150	[8, 13]	7	io -4 0x20180150 0x3F000700
		level3	0x20180150	[8, 13]	15	io -4 0x20180150 0x3F000F00
		level4	0x20180150	[8, 13]	31	io -4 0x20180150 0x3F001F00
		level5	0x20180150	[8, 13]	63	io -4 0x20180150 0x3F003F00
	ExtPort	read gpio data in input mode	0x20D80070	[9, 9]		io -4 0x20D80070
GPIO1B2	IOMUX	SDMMC0_CMD	0x20180028	[8, 11]	1	io -4 0x20180028 0x0F000100
		UART1_CTSN_M1	0x20180028	[8, 11]	2	io -4 0x20180028 0x0F000200
		GPIO1_B2	0x20180028	[8, 11]	0	io -4 0x20180028 0x0F000000
	Pull	z	0x20180214	[4, 5]	0	io -4 0x20180214 0x00300000
		up	0x20180214	[4, 5]	1	io -4 0x20180214 0x00300010
		down	0x20180214	[4, 5]	2	io -4 0x20180214 0x00300020
	I/O Mode	input	0x20D80008	[10, 10]	0	io -4 0x20D80008 0x04000000
		output	0x20D80008	[10, 10]	1	io -4 0x20D80008 0x04000400
	Output	low	0x20D80000	[10, 10]	0	io -4 0x20D80000 0x04000000
		high	0x20D80000	[10, 10]	1	io -4 0x20D80000 0x04000400
	Input Ctrl	disable	0x20180314	[2, 2]	0	io -4 0x20180314 0x00040000
		enable	0x20180314	[2, 2]	1	io -4 0x20180314 0x00040004
	Schmitt	disable	0x20180414	[2, 2]	0	io -4 0x20180414 0x00040000
		enable	0x20180414	[2, 2]	1	io -4 0x20180414 0x00040004
	Drive Strength	level0	0x20180154	[0, 5]	1	io -4 0x20180154 0x003F0001
		level1	0x20180154	[0, 5]	3	io -4 0x20180154 0x003F0003
		level2	0x20180154	[0, 5]	7	io -4 0x20180154 0x003F0007
		level3	0x20180154	[0, 5]	15	io -4 0x20180154 0x003F000F
		level4	0x20180154	[0, 5]	31	io -4 0x20180154 0x003F001F
		level5	0x20180154	[0, 5]	63	io -4 0x20180154 0x003F003F
	ExtPort	read gpio data in input mode	0x20D80070	[10, 10]		io -4 0x20D80070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO1B3	IOMUX	SDMMCO D3	0x20180028	[12, 15]	1	io -4 0x20180028 0xF0001000
		UART0 RX M2	0x20180028	[12, 15]	2	io -4 0x20180028 0xF0002000
		JTAG TMS M2	0x20180028	[12, 15]	3	io -4 0x20180028 0xF0003000
		PWM2 CH3 M0	0x20180028	[12, 15]	4	io -4 0x20180028 0xF0004000
		I2CO SDA M1	0x20180028	[12, 15]	5	io -4 0x20180028 0xF0005000
	Pull	GPI01 B3	0x20180028	[12, 15]	0	io -4 0x20180028 0xF0000000
		z	0x20180214	[6, 7]	0	io -4 0x20180214 0x00C00000
		up	0x20180214	[6, 7]	1	io -4 0x20180214 0x00C00040
	I/O Mode	down	0x20180214	[6, 7]	2	io -4 0x20180214 0x00C00080
		input	0x20D80008	[11, 11]	0	io -4 0x20D80008 0x08000000
	Output	output	0x20D80008	[11, 11]	1	io -4 0x20D80008 0x08000800
		low	0x20D80000	[11, 11]	0	io -4 0x20D80000 0x08000000
	Input Ctrl	high	0x20D80000	[11, 11]	1	io -4 0x20D80000 0x08000800
		disable	0x20180314	[3, 3]	0	io -4 0x20180314 0x00080000
	Schmitt	enable	0x20180314	[3, 3]	1	io -4 0x20180314 0x00080008
		disable	0x20180414	[3, 3]	0	io -4 0x20180414 0x00080000
	Drive Strength	enable	0x20180414	[3, 3]	1	io -4 0x20180414 0x00080008
		level0	0x20180154	[8, 13]	1	io -4 0x20180154 0x3F000100
		level1	0x20180154	[8, 13]	3	io -4 0x20180154 0x3F000300
		level2	0x20180154	[8, 13]	7	io -4 0x20180154 0x3F000700
		level3	0x20180154	[8, 13]	15	io -4 0x20180154 0x3F000F00
		level4	0x20180154	[8, 13]	31	io -4 0x20180154 0x3F001F00
	ExtPort	level5	0x20180154	[8, 13]	63	io -4 0x20180154 0x3F003F00
		read gpio data in input mode	0x20D80070	[11, 11]		io -4 0x20D80070
GPIO1B4	IOMUX	SDMMCO D2	0x2018002C	[0, 3]	1	io -4 0x2018002C 0x000F0001
		UART0 TX M2	0x2018002C	[0, 3]	2	io -4 0x2018002C 0x000F0002
		JTAG TCK M2	0x2018002C	[0, 3]	3	io -4 0x2018002C 0x000F0003
		PWM2 CH2 M0	0x2018002C	[0, 3]	4	io -4 0x2018002C 0x000F0004
		I2CO SCL M1	0x2018002C	[0, 3]	5	io -4 0x2018002C 0x000F0005
		GPI01 B4	0x2018002C	[0, 3]	0	io -4 0x2018002C 0x000F0000
	Pull	z	0x20180214	[8, 9]	0	io -4 0x20180214 0x03000000
		up	0x20180214	[8, 9]	1	io -4 0x20180214 0x03000100
		down	0x20180214	[8, 9]	2	io -4 0x20180214 0x03000200
	I/O Mode	input	0x20D80008	[12, 12]	0	io -4 0x20D80008 0x10000000
		output	0x20D80008	[12, 12]	1	io -4 0x20D80008 0x10001000
	Output	low	0x20D80000	[12, 12]	0	io -4 0x20D80000 0x10000000
		high	0x20D80000	[12, 12]	1	io -4 0x20D80000 0x10001000
	Input Ctrl	disable	0x20180314	[4, 4]	0	io -4 0x20180314 0x00100000
		enable	0x20180314	[4, 4]	1	io -4 0x20180314 0x00100010
	Schmitt	disable	0x20180414	[4, 4]	0	io -4 0x20180414 0x00100000
		enable	0x20180414	[4, 4]	1	io -4 0x20180414 0x00100010
	Drive Strength	level0	0x20180158	[0, 5]	1	io -4 0x20180158 0x003F0001
		level1	0x20180158	[0, 5]	3	io -4 0x20180158 0x003F0003
		level2	0x20180158	[0, 5]	7	io -4 0x20180158 0x003F0007
		level3	0x20180158	[0, 5]	15	io -4 0x20180158 0x003F000F
		level4	0x20180158	[0, 5]	31	io -4 0x20180158 0x003F001F
	ExtPort	level5	0x20180158	[0, 5]	63	io -4 0x20180158 0x003F003F
		read gpio data in input mode	0x20D80070	[12, 12]		io -4 0x20D80070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO1B5	IOMUX	CAM_CLK0_OUT	0x2018002C	[4, 7]	1	io -4 0x2018002C 0x00F00010
		I2C0_SCL_M2	0x2018002C	[4, 7]	2	io -4 0x2018002C 0x00F00020
		UART2_TX_M2	0x2018002C	[4, 7]	3	io -4 0x2018002C 0x00F00030
		GPIO1_B5	0x2018002C	[4, 7]	0	io -4 0x2018002C 0x00F00000
	Pull	z	0x20180214	[10, 11]	0	io -4 0x20180214 0x0C000000
		up	0x20180214	[10, 11]	1	io -4 0x20180214 0x0C000400
		down	0x20180214	[10, 11]	2	io -4 0x20180214 0x0C000800
	I/O Mode	input	0x20D80008	[13, 13]	0	io -4 0x20D80008 0x20000000
		output	0x20D80008	[13, 13]	1	io -4 0x20D80008 0x20002000
	Output	low	0x20D80000	[13, 13]	0	io -4 0x20D80000 0x20000000
		high	0x20D80000	[13, 13]	1	io -4 0x20D80000 0x20002000
	Input Ctrl	disable	0x20180314	[5, 5]	0	io -4 0x20180314 0x00200000
		enable	0x20180314	[5, 5]	1	io -4 0x20180314 0x00200020
	Schmitt	disable	0x20180414	[5, 5]	0	io -4 0x20180414 0x00200000
		enable	0x20180414	[5, 5]	1	io -4 0x20180414 0x00200020
	Drive Strength	level0	0x20180158	[8, 13]	1	io -4 0x20180158 0x3F000100
		level1	0x20180158	[8, 13]	3	io -4 0x20180158 0x3F000300
		level2	0x20180158	[8, 13]	7	io -4 0x20180158 0x3F000700
		level3	0x20180158	[8, 13]	15	io -4 0x20180158 0x3F000F00
		level4	0x20180158	[8, 13]	31	io -4 0x20180158 0x3F001F00
		level5	0x20180158	[8, 13]	63	io -4 0x20180158 0x3F003F00
	ExtPort	read gpio data in input mode	0x20D80070	[13, 13]		io -4 0x20D80070
GPIO1B6	IOMUX	CAM_CLK1_OUT	0x2018002C	[8, 11]	1	io -4 0x2018002C 0x0F000100
		I2C0_SDA_M2	0x2018002C	[8, 11]	2	io -4 0x2018002C 0x0F000200
		UART2_RX_M2	0x2018002C	[8, 11]	3	io -4 0x2018002C 0x0F000300
		GPIO1_B6	0x2018002C	[8, 11]	0	io -4 0x2018002C 0x0F000000
	Pull	z	0x20180214	[12, 13]	0	io -4 0x20180214 0x30000000
		up	0x20180214	[12, 13]	1	io -4 0x20180214 0x30001000
		down	0x20180214	[12, 13]	2	io -4 0x20180214 0x30002000
	I/O Mode	input	0x20D80008	[14, 14]	0	io -4 0x20D80008 0x40000000
		output	0x20D80008	[14, 14]	1	io -4 0x20D80008 0x40004000
	Output	low	0x20D80000	[14, 14]	0	io -4 0x20D80000 0x40000000
		high	0x20D80000	[14, 14]	1	io -4 0x20D80000 0x40004000
	Input Ctrl	disable	0x20180314	[6, 6]	0	io -4 0x20180314 0x00400000
		enable	0x20180314	[6, 6]	1	io -4 0x20180314 0x00400040
	Schmitt	disable	0x20180414	[6, 6]	0	io -4 0x20180414 0x00400000
		enable	0x20180414	[6, 6]	1	io -4 0x20180414 0x00400040
	Drive Strength	level0	0x2018015C	[0, 5]	1	io -4 0x2018015C 0x003F0001
		level1	0x2018015C	[0, 5]	3	io -4 0x2018015C 0x003F0003
		level2	0x2018015C	[0, 5]	7	io -4 0x2018015C 0x003F0007
		level3	0x2018015C	[0, 5]	15	io -4 0x2018015C 0x003F000F
		level4	0x2018015C	[0, 5]	31	io -4 0x2018015C 0x003F001F
		level5	0x2018015C	[0, 5]	63	io -4 0x2018015C 0x003F003F
	ExtPort	read gpio data in input mode	0x20D80070	[14, 14]		io -4 0x20D80070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO1B7	IOMUX	PWM0_CH1_M2	0x2018002C	[12, 15]	1	io -4 0x2018002C 0xF0001000
		I2C4_SCL_M1	0x2018002C	[12, 15]	2	io -4 0x2018002C 0xF0002000
		UART2_RTSN_M2	0x2018002C	[12, 15]	3	io -4 0x2018002C 0xF0003000
		GPIO1_B7	0x2018002C	[12, 15]	0	io -4 0x2018002C 0xF0000000
	Pull	z	0x20180214	[14, 15]	0	io -4 0x20180214 0xC0000000
		up	0x20180214	[14, 15]	1	io -4 0x20180214 0xC0004000
		down	0x20180214	[14, 15]	2	io -4 0x20180214 0xC0008000
	I/O Mode	input	0x20D80008	[15, 15]	0	io -4 0x20D80008 0x80000000
		output	0x20D80008	[15, 15]	1	io -4 0x20D80008 0x80008000
	Output	low	0x20D80000	[15, 15]	0	io -4 0x20D80000 0x80000000
		high	0x20D80000	[15, 15]	1	io -4 0x20D80000 0x80008000
	Input Ctrl	disable	0x20180314	[7, 7]	0	io -4 0x20180314 0x00800000
		enable	0x20180314	[7, 7]	1	io -4 0x20180314 0x00800080
	Schmitt	disable	0x20180414	[7, 7]	0	io -4 0x20180414 0x00800000
		enable	0x20180414	[7, 7]	1	io -4 0x20180414 0x00800080
	Drive Strength	level0	0x2018015C	[8, 13]	1	io -4 0x2018015C 0x3F000100
		level1	0x2018015C	[8, 13]	3	io -4 0x2018015C 0x3F000300
		level2	0x2018015C	[8, 13]	7	io -4 0x2018015C 0x3F000700
		level3	0x2018015C	[8, 13]	15	io -4 0x2018015C 0x3F000F00
		level4	0x2018015C	[8, 13]	31	io -4 0x2018015C 0x3F001F00
		level5	0x2018015C	[8, 13]	63	io -4 0x2018015C 0x3F003F00
	ExtPort	read gpio data in input mode	0x20D80070	[15, 15]		io -4 0x20D80070
GPIO1C0	IOMUX	PWM0_CH2_M2	0x20180030	[0, 3]	1	io -4 0x20180030 0x000F0001
		I2C4_SDA_M1	0x20180030	[0, 3]	2	io -4 0x20180030 0x000F0002
		UART2_CTSN_M2	0x20180030	[0, 3]	3	io -4 0x20180030 0x000F0003
		GPIO1_C0	0x20180030	[0, 3]	0	io -4 0x20180030 0x000F0000
	Pull	z	0x20180218	[0, 1]	0	io -4 0x20180218 0x00030000
		up	0x20180218	[0, 1]	1	io -4 0x20180218 0x00030001
		down	0x20180218	[0, 1]	2	io -4 0x20180218 0x00030002
	I/O Mode	input	0x20D8000C	[0, 0]	0	io -4 0x20D8000C 0x00010000
		output	0x20D8000C	[0, 0]	1	io -4 0x20D8000C 0x00010001
	Output	low	0x20D80004	[0, 0]	0	io -4 0x20D80004 0x00010000
		high	0x20D80004	[0, 0]	1	io -4 0x20D80004 0x00010001
	Input Ctrl	disable	0x20180318	[0, 0]	0	io -4 0x20180318 0x00010000
		enable	0x20180318	[0, 0]	1	io -4 0x20180318 0x00010001
	Schmitt	disable	0x20180418	[0, 0]	0	io -4 0x20180418 0x00010000
		enable	0x20180418	[0, 0]	1	io -4 0x20180418 0x00010001
	Drive Strength	level0	0x20180160	[0, 5]	1	io -4 0x20180160 0x003F0001
		level1	0x20180160	[0, 5]	3	io -4 0x20180160 0x003F0003
		level2	0x20180160	[0, 5]	7	io -4 0x20180160 0x003F0007
		level3	0x20180160	[0, 5]	15	io -4 0x20180160 0x003F000F
		level4	0x20180160	[0, 5]	31	io -4 0x20180160 0x003F001F
		level5	0x20180160	[0, 5]	63	io -4 0x20180160 0x003F003F
	ExtPort	read gpio data in input mode	0x20D80070	[16, 16]		io -4 0x20D80070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO1C1	IOMUX	MIPICSI_D3N	0x20180030	[4, 7]	1	io -4 0x20180030 0x00F00010
		GPIO1_C1	0x20180030	[4, 7]	0	io -4 0x20180030 0x00F00000 io -4 0x20030808 0x00040000 io -4 0x20DB0000 0x0000007D io -4 0x20DB044C 0x00000001
	Pull					
	I/O Mode	input	0x20D8000C	[1, 1]	0	io -4 0x20D8000C 0x00020000
	Output					
	Input Ctrl					
	Schmitt					
	Drive Strength					
	ExtPort	read gpio data in input mode	0x20D80070	[17, 17]		io -4 0x20D80070
GPIO1C2	IOMUX	MIPICSI_D3P	0x20180030	[8, 11]	1	io -4 0x20180030 0x0F000100
		GPIO1_C2	0x20180030	[8, 11]	0	io -4 0x20180030 0x0F000000 io -4 0x20030808 0x00040000 io -4 0x20DB0000 0x0000007D io -4 0x20DB044C 0x00000001
	Pull					
	I/O Mode	input	0x20D8000C	[2, 2]	0	io -4 0x20D8000C 0x00040000
	Output					
	Input Ctrl					
	Schmitt					
	Drive Strength					
	ExtPort	read gpio data in input mode	0x20D80070	[18, 18]		io -4 0x20D80070
GPIO1C3	IOMUX	MIPICSI_CK1N	0x20180030	[12, 15]	1	io -4 0x20180030 0xF0001000
		GPIO1_C3	0x20180030	[12, 15]	0	io -4 0x20180030 0xF0000000 io -4 0x20030808 0x00040000 io -4 0x20DB0000 0x0000007D io -4 0x20DB044C 0x00000001
	Pull					
	I/O Mode	input	0x20D8000C	[3, 3]	0	io -4 0x20D8000C 0x00080000
	Output					
	Input Ctrl					
	Schmitt					
	Drive Strength					
	ExtPort	read gpio data in input mode	0x20D80070	[19, 19]		io -4 0x20D80070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO1C4	IOMUX	MIPICSI_CK1P	0x20180034	[0, 3]	1	io -4 0x20180034 0x000F0001
		GPIO1_C4	0x20180034	[0, 3]	0	io -4 0x20180034 0x000F0000 io -4 0x20030808 0x00040000 io -4 0x20DB0000 0x0000007D io -4 0x20DB044C 0x00000001
	Pull					
	I/O Mode	input	0x20D8000C	[4, 4]	0	io -4 0x20D8000C 0x00100000
	Output					
	Input Ctrl					
	Schmitt					
	Drive Strength					
	ExtPort	read gpio data in input mode	0x20D80070	[20, 20]		io -4 0x20D80070
GPIO1C5	IOMUX	MIPICSI_D2N	0x20180034	[4, 7]	1	io -4 0x20180034 0x00F00010
		GPIO1_C5	0x20180034	[4, 7]	0	io -4 0x20180034 0x00F00000 io -4 0x20030808 0x00040000 io -4 0x20DB0000 0x0000007D io -4 0x20DB044C 0x00000001
	Pull					
	I/O Mode	input	0x20D8000C	[5, 5]	0	io -4 0x20D8000C 0x00200000
	Output					
	Input Ctrl					
	Schmitt					
	Drive Strength					
	ExtPort	read gpio data in input mode	0x20D80070	[21, 21]		io -4 0x20D80070
GPIO1C6	IOMUX	MIPICSI_D2P	0x20180034	[8, 11]	1	io -4 0x20180034 0x0F000100
		GPIO1_C6	0x20180034	[8, 11]	0	io -4 0x20180034 0x0F000000 io -4 0x20030808 0x00040000 io -4 0x20DB0000 0x0000007D io -4 0x20DB044C 0x00000001
	Pull					
	I/O Mode	input	0x20D8000C	[6, 6]	0	io -4 0x20D8000C 0x00400000
	Output					
	Input Ctrl					
	Schmitt					
	Drive Strength					
	ExtPort	read gpio data in input mode	0x20D80070	[22, 22]		io -4 0x20D80070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO1D0	IOMUX	MIPICSI_DIN	0x20180038	[0, 3]	1	io -4 0x20180038 0x000F0001
		GPIO1_D0	0x20180038	[0, 3]	0	io -4 0x20180038 0x000F0000 io -4 0x20030808 0x00040000 io -4 0x20DB0000 0x0000007D io -4 0x20DB044C 0x00000001
	Pull					
	I/O Mode	input	0x20D8000C	[8, 8]	0	io -4 0x20D8000C 0x01000000
	Output					
	Input Ctrl					
	Schmitt					
	Drive Strength					
	ExtPort	read gpio data in input mode	0x20D80070	[24, 24]		io -4 0x20D80070
GPIO1D1	IOMUX	MIPICSI_D1P	0x20180038	[4, 7]	1	io -4 0x20180038 0x00F00010
		GPIO1_D1	0x20180038	[4, 7]	0	io -4 0x20180038 0x00F00000 io -4 0x20030808 0x00040000 io -4 0x20DB0000 0x0000007D io -4 0x20DB044C 0x00000001
	Pull					
	I/O Mode	input	0x20D8000C	[9, 9]	0	io -4 0x20D8000C 0x02000000
	Output					
	Input Ctrl					
	Schmitt					
	Drive Strength					
	ExtPort	read gpio data in input mode	0x20D80070	[25, 25]		io -4 0x20D80070
GPIO1D2	IOMUX	MIPICSI_CKON	0x20180038	[8, 11]	1	io -4 0x20180038 0x0F000100
		GPIO1_D2	0x20180038	[8, 11]	0	io -4 0x20180038 0x0F000000 io -4 0x20030808 0x00040000 io -4 0x20DB0000 0x0000007D io -4 0x20DB044C 0x00000001
	Pull					
	I/O Mode	input	0x20D8000C	[10, 10]	0	io -4 0x20D8000C 0x04000000
	Output					
	Input Ctrl					
	Schmitt					
	Drive Strength					
	ExtPort	read gpio data in input mode	0x20D80070	[26, 26]		io -4 0x20D80070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO1D3	IOMUX	MIPICSI_CKOP	0x20180038	[12, 15]	1	io -4 0x20180038 0xF0001000
		GPIO1_D3	0x20180038	[12, 15]	0	io -4 0x20180038 0xF0000000 io -4 0x20030808 0x00040000 io -4 0x20DB0000 0x0000007D io -4 0x20DB044C 0x00000001
	Pull					
	I/O Mode	input	0x20D8000C	[11, 11]	0	io -4 0x20D8000C 0x08000000
	Output					
	Input Ctrl					
	Schmitt					
	Drive Strength					
	ExtPort	read gpio data in input mode	0x20D80070	[27, 27]		io -4 0x20D80070
GPIO1D4	IOMUX	MIPICSI_DON	0x2018003C	[0, 3]	1	io -4 0x2018003C 0x000F0001
		GPIO1_D4	0x2018003C	[0, 3]	0	io -4 0x2018003C 0x000F0000 io -4 0x20030808 0x00040000 io -4 0x20DB0000 0x0000007D io -4 0x20DB044C 0x00000001
	Pull					
	I/O Mode	input	0x20D8000C	[12, 12]	0	io -4 0x20D8000C 0x10000000
	Output					
	Input Ctrl					
	Schmitt					
	Drive Strength					
	ExtPort	read gpio data in input mode	0x20D80070	[28, 28]		io -4 0x20D80070
GPIO1D5	IOMUX	MIPICSI_DOP	0x2018003C	[4, 7]	1	io -4 0x2018003C 0x00F00010
		GPIO1_D5	0x2018003C	[4, 7]	0	io -4 0x2018003C 0x00F00000 io -4 0x20030808 0x00040000 io -4 0x20DB0000 0x0000007D io -4 0x20DB044C 0x00000001
	Pull					
	I/O Mode	input	0x20D8000C	[13, 13]	0	io -4 0x20D8000C 0x20000000
	Output					
	Input Ctrl					
	Schmitt					
	Drive Strength					
	ExtPort	read gpio data in input mode	0x20D80070	[29, 29]		io -4 0x20D80070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO2A0	IOMUX	SDMMC1_D1	0x201A0040	[0, 3]	1	io -4 0x201A0040 0x000F0001
		UART1_RTSN_M3	0x201A0040	[0, 3]	2	io -4 0x201A0040 0x000F0002
		PWMO_CH0_M1	0x201A0040	[0, 3]	3	io -4 0x201A0040 0x000F0003
		SPIO_CS1N_M1	0x201A0040	[0, 3]	5	io -4 0x201A0040 0x000F0005
		GPIO2_A0	0x201A0040	[0, 3]	0	io -4 0x201A0040 0x000F0000
	Pull	z	0x201A0220	[0, 1]	0	io -4 0x201A0220 0x00030000
		up	0x201A0220	[0, 1]	1	io -4 0x201A0220 0x00030001
		down	0x201A0220	[0, 1]	2	io -4 0x201A0220 0x00030002
	I/O Mode	input	0x20840008	[0, 0]	0	io -4 0x20840008 0x00010000
		output	0x20840008	[0, 0]	1	io -4 0x20840008 0x00010001
	Output	low	0x20840000	[0, 0]	0	io -4 0x20840000 0x00010000
		high	0x20840000	[0, 0]	1	io -4 0x20840000 0x00010001
	Input Ctrl	disable	0x201A0320	[0, 0]	0	io -4 0x201A0320 0x00010000
		enable	0x201A0320	[0, 0]	1	io -4 0x201A0320 0x00010001
	Schmitt	disable	0x201A0420	[0, 0]	0	io -4 0x201A0420 0x00010000
		enable	0x201A0420	[0, 0]	1	io -4 0x201A0420 0x00010001
	Drive Strength	level0	0x201A0180	[0, 5]	1	io -4 0x201A0180 0x003F0001
		level1	0x201A0180	[0, 5]	3	io -4 0x201A0180 0x003F0003
		level2	0x201A0180	[0, 5]	7	io -4 0x201A0180 0x003F0007
		level3	0x201A0180	[0, 5]	15	io -4 0x201A0180 0x003F000F
		level4	0x201A0180	[0, 5]	31	io -4 0x201A0180 0x003F001F
		level5	0x201A0180	[0, 5]	63	io -4 0x201A0180 0x003F003F
	ExtPort	read gpio data in input mode	0x20840070	[0, 0]		io -4 0x20840070
GPIO2A1	IOMUX	SDMMC1_D0	0x201A0040	[4, 7]	1	io -4 0x201A0040 0x00F00010
		UART1_CTSN_M3	0x201A0040	[4, 7]	2	io -4 0x201A0040 0x00F00020
		PWMO_CH1_M1	0x201A0040	[4, 7]	3	io -4 0x201A0040 0x00F00030
		SPIO_MOSI_M1	0x201A0040	[4, 7]	5	io -4 0x201A0040 0x00F00050
		GPIO2_A1	0x201A0040	[4, 7]	0	io -4 0x201A0040 0x00F00000
	Pull	z	0x201A0220	[2, 3]	0	io -4 0x201A0220 0x000C0000
		up	0x201A0220	[2, 3]	1	io -4 0x201A0220 0x000C0004
		down	0x201A0220	[2, 3]	2	io -4 0x201A0220 0x000C0008
	I/O Mode	input	0x20840008	[1, 1]	0	io -4 0x20840008 0x00020000
		output	0x20840008	[1, 1]	1	io -4 0x20840008 0x00020002
	Output	low	0x20840000	[1, 1]	0	io -4 0x20840000 0x00020000
		high	0x20840000	[1, 1]	1	io -4 0x20840000 0x00020002
	Input Ctrl	disable	0x201A0320	[1, 1]	0	io -4 0x201A0320 0x00020000
		enable	0x201A0320	[1, 1]	1	io -4 0x201A0320 0x00020002
	Schmitt	disable	0x201A0420	[1, 1]	0	io -4 0x201A0420 0x00020000
		enable	0x201A0420	[1, 1]	1	io -4 0x201A0420 0x00020002
	Drive Strength	level0	0x201A0180	[8, 13]	1	io -4 0x201A0180 0x3F000100
		level1	0x201A0180	[8, 13]	3	io -4 0x201A0180 0x3F000300
		level2	0x201A0180	[8, 13]	7	io -4 0x201A0180 0x3F000700
		level3	0x201A0180	[8, 13]	15	io -4 0x201A0180 0x3F000F00
		level4	0x201A0180	[8, 13]	31	io -4 0x201A0180 0x3F001F00
		level5	0x201A0180	[8, 13]	63	io -4 0x201A0180 0x3F003F00
	ExtPort	read gpio data in input mode	0x20840070	[1, 1]		io -4 0x20840070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO2A2	IOMUX	SDMMC1_CLK	0x201A0040	[8, 11]	1	io -4 0x201A0040 0x0F000100
		UART1_TX_M3	0x201A0040	[8, 11]	2	io -4 0x201A0040 0x0F000200
		PWM0_CH2_M1	0x201A0040	[8, 11]	3	io -4 0x201A0040 0x0F000300
		SPI0_CLK_M1	0x201A0040	[8, 11]	5	io -4 0x201A0040 0x0F000500
		GPIO2_A2	0x201A0040	[8, 11]	0	io -4 0x201A0040 0x0F000000
	Pull	z	0x201A0220	[4, 5]	0	io -4 0x201A0220 0x00300000
		up	0x201A0220	[4, 5]	1	io -4 0x201A0220 0x00300010
		down	0x201A0220	[4, 5]	2	io -4 0x201A0220 0x00300020
	I/O Mode	input	0x20840008	[2, 2]	0	io -4 0x20840008 0x00040000
		output	0x20840008	[2, 2]	1	io -4 0x20840008 0x00040004
	Output	low	0x20840000	[2, 2]	0	io -4 0x20840000 0x00040000
		high	0x20840000	[2, 2]	1	io -4 0x20840000 0x00040004
	Input Ctrl	disable	0x201A0320	[2, 2]	0	io -4 0x201A0320 0x00040000
		enable	0x201A0320	[2, 2]	1	io -4 0x201A0320 0x00040004
	Schmitt	disable	0x201A0420	[2, 2]	0	io -4 0x201A0420 0x00040000
		enable	0x201A0420	[2, 2]	1	io -4 0x201A0420 0x00040004
	Drive Strength	level0	0x201A0184	[0, 5]	1	io -4 0x201A0184 0x003F0001
		level1	0x201A0184	[0, 5]	3	io -4 0x201A0184 0x003F0003
		level2	0x201A0184	[0, 5]	7	io -4 0x201A0184 0x003F0007
		level3	0x201A0184	[0, 5]	15	io -4 0x201A0184 0x003F000F
		level4	0x201A0184	[0, 5]	31	io -4 0x201A0184 0x003F001F
		level5	0x201A0184	[0, 5]	63	io -4 0x201A0184 0x003F003F
	ExtPort	read gpio data in input mode	0x20840070	[2, 2]		io -4 0x20840070
GPIO2A3	IOMUX	SDMMC1_CMD	0x201A0040	[12, 15]	1	io -4 0x201A0040 0xF0001000
		UART1_RX_M3	0x201A0040	[12, 15]	2	io -4 0x201A0040 0xF0002000
		PWM1_CHO_M1	0x201A0040	[12, 15]	3	io -4 0x201A0040 0xF0003000
		SPI0_CSON_M1	0x201A0040	[12, 15]	5	io -4 0x201A0040 0xF0005000
		GPIO2_A3	0x201A0040	[12, 15]	0	io -4 0x201A0040 0xF0000000
	Pull	z	0x201A0220	[6, 7]	0	io -4 0x201A0220 0x00C00000
		up	0x201A0220	[6, 7]	1	io -4 0x201A0220 0x00C00040
		down	0x201A0220	[6, 7]	2	io -4 0x201A0220 0x00C00080
	I/O Mode	input	0x20840008	[3, 3]	0	io -4 0x20840008 0x00080000
		output	0x20840008	[3, 3]	1	io -4 0x20840008 0x00080008
	Output	low	0x20840000	[3, 3]	0	io -4 0x20840000 0x00080000
		high	0x20840000	[3, 3]	1	io -4 0x20840000 0x00080008
	Input Ctrl	disable	0x201A0320	[3, 3]	0	io -4 0x201A0320 0x00080000
		enable	0x201A0320	[3, 3]	1	io -4 0x201A0320 0x00080008
	Schmitt	disable	0x201A0420	[3, 3]	0	io -4 0x201A0420 0x00080000
		enable	0x201A0420	[3, 3]	1	io -4 0x201A0420 0x00080008
	Drive Strength	level0	0x201A0184	[8, 13]	1	io -4 0x201A0184 0x3F000100
		level1	0x201A0184	[8, 13]	3	io -4 0x201A0184 0x3F000300
		level2	0x201A0184	[8, 13]	7	io -4 0x201A0184 0x3F000700
		level3	0x201A0184	[8, 13]	15	io -4 0x201A0184 0x3F000F00
		level4	0x201A0184	[8, 13]	31	io -4 0x201A0184 0x3F001F00
		level5	0x201A0184	[8, 13]	63	io -4 0x201A0184 0x3F003F00
	ExtPort	read gpio data in input mode	0x20840070	[3, 3]		io -4 0x20840070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO2A4	IOMUX	SDMMC1_D3	0x201A0044	[0, 3]	1	io -4 0x201A0044 0x000F0001
		UART1_RTSN_M2	0x201A0044	[0, 3]	2	io -4 0x201A0044 0x000F0002
		PWM1_CH1_M1	0x201A0044	[0, 3]	3	io -4 0x201A0044 0x000F0003
		I2C1_SCL_M1	0x201A0044	[0, 3]	4	io -4 0x201A0044 0x000F0004
		SPIO_MISO_M1	0x201A0044	[0, 3]	5	io -4 0x201A0044 0x000F0005
		ETH_LED_DPX	0x201A0044	[0, 3]	6	io -4 0x201A0044 0x000F0006
	Pull	GPIO2_A4	0x201A0044	[0, 3]	0	io -4 0x201A0044 0x000F0000
		z	0x201A0220	[8, 9]	0	io -4 0x201A0220 0x03000000
		up	0x201A0220	[8, 9]	1	io -4 0x201A0220 0x03000100
	I/O Mode	down	0x201A0220	[8, 9]	2	io -4 0x201A0220 0x03000200
		input	0x20840008	[4, 4]	0	io -4 0x20840008 0x00100000
		output	0x20840008	[4, 4]	1	io -4 0x20840008 0x00100010
	Output	low	0x20840000	[4, 4]	0	io -4 0x20840000 0x00100000
		high	0x20840000	[4, 4]	1	io -4 0x20840000 0x00100010
	Input Ctrl	disable	0x201A0320	[4, 4]	0	io -4 0x201A0320 0x00100000
		enable	0x201A0320	[4, 4]	1	io -4 0x201A0320 0x00100010
	Schmitt	disable	0x201A0420	[4, 4]	0	io -4 0x201A0420 0x00100000
		enable	0x201A0420	[4, 4]	1	io -4 0x201A0420 0x00100010
	Drive Strength	level0	0x201A0188	[0, 5]	1	io -4 0x201A0188 0x003F0001
		level1	0x201A0188	[0, 5]	3	io -4 0x201A0188 0x003F0003
		level2	0x201A0188	[0, 5]	7	io -4 0x201A0188 0x003F0007
		level3	0x201A0188	[0, 5]	15	io -4 0x201A0188 0x003F000F
		level4	0x201A0188	[0, 5]	31	io -4 0x201A0188 0x003F001F
		level5	0x201A0188	[0, 5]	63	io -4 0x201A0188 0x003F003F
	ExtPort	read gpio data in input mode	0x20840070	[4, 4]		io -4 0x20840070
GPIO2A5	IOMUX	SDMMC1_D2	0x201A0044	[4, 7]	1	io -4 0x201A0044 0x00F00010
		UART1_CTSN_M2	0x201A0044	[4, 7]	2	io -4 0x201A0044 0x00F00020
		PWM1_CH2_M1	0x201A0044	[4, 7]	3	io -4 0x201A0044 0x00F00030
		I2C1_SDA_M1	0x201A0044	[4, 7]	4	io -4 0x201A0044 0x00F00040
		GPIO2_A5	0x201A0044	[4, 7]	0	io -4 0x201A0044 0x00F00000
	Pull	z	0x201A0220	[10, 11]	0	io -4 0x201A0220 0x0C000000
		up	0x201A0220	[10, 11]	1	io -4 0x201A0220 0x0C000400
		down	0x201A0220	[10, 11]	2	io -4 0x201A0220 0x0C000800
	I/O Mode	input	0x20840008	[5, 5]	0	io -4 0x20840008 0x00200000
		output	0x20840008	[5, 5]	1	io -4 0x20840008 0x00200020
	Output	low	0x20840000	[5, 5]	0	io -4 0x20840000 0x00200000
		high	0x20840000	[5, 5]	1	io -4 0x20840000 0x00200020
	Input Ctrl	disable	0x201A0320	[5, 5]	0	io -4 0x201A0320 0x00200000
		enable	0x201A0320	[5, 5]	1	io -4 0x201A0320 0x00200020
	Schmitt	disable	0x201A0420	[5, 5]	0	io -4 0x201A0420 0x00200000
		enable	0x201A0420	[5, 5]	1	io -4 0x201A0420 0x00200020
	Drive Strength	level0	0x201A0188	[8, 13]	1	io -4 0x201A0188 0x3F000100
		level1	0x201A0188	[8, 13]	3	io -4 0x201A0188 0x3F000300
		level2	0x201A0188	[8, 13]	7	io -4 0x201A0188 0x3F000700
		level3	0x201A0188	[8, 13]	15	io -4 0x201A0188 0x3F000F00
		level4	0x201A0188	[8, 13]	31	io -4 0x201A0188 0x3F001F00
		level5	0x201A0188	[8, 13]	63	io -4 0x201A0188 0x3F003F00
	ExtPort	read gpio data in input mode	0x20840070	[5, 5]		io -4 0x20840070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO2A6	IOMUX	UART1_TX_M2	0x201A0044	[8, 11]	1	io -4 0x201A0044 0x0F000100
		PWM2_CH0_M1	0x201A0044	[8, 11]	3	io -4 0x201A0044 0x0F000300
		I2C2_SCL_M1	0x201A0044	[8, 11]	4	io -4 0x201A0044 0x0F000400
		SAI_SDI	0x201A0044	[8, 11]	5	io -4 0x201A0044 0x0F000500
		ETH_LED_LINK	0x201A0044	[8, 11]	6	io -4 0x201A0044 0x0F000600
		GPIO2_A6	0x201A0044	[8, 11]	0	io -4 0x201A0044 0x0F000000
	Pull	z	0x201A0220	[12, 13]	0	io -4 0x201A0220 0x30000000
		up	0x201A0220	[12, 13]	1	io -4 0x201A0220 0x30001000
		down	0x201A0220	[12, 13]	2	io -4 0x201A0220 0x30002000
	I/O Mode	input	0x20840008	[6, 6]	0	io -4 0x20840008 0x00400000
		output	0x20840008	[6, 6]	1	io -4 0x20840008 0x00400040
	Output	low	0x20840000	[6, 6]	0	io -4 0x20840000 0x00400000
		high	0x20840000	[6, 6]	1	io -4 0x20840000 0x00400040
	Input Ctrl	disable	0x201A0320	[6, 6]	0	io -4 0x201A0320 0x00400000
		enable	0x201A0320	[6, 6]	1	io -4 0x201A0320 0x00400040
	Schmitt	disable	0x201A0420	[6, 6]	0	io -4 0x201A0420 0x00400000
		enable	0x201A0420	[6, 6]	1	io -4 0x201A0420 0x00400040
	Drive Strength	level0	0x201A018C	[0, 5]	1	io -4 0x201A018C 0x003F0001
		level1	0x201A018C	[0, 5]	3	io -4 0x201A018C 0x003F0003
		level2	0x201A018C	[0, 5]	7	io -4 0x201A018C 0x003F0007
		level3	0x201A018C	[0, 5]	15	io -4 0x201A018C 0x003F000F
		level4	0x201A018C	[0, 5]	31	io -4 0x201A018C 0x003F001F
		level5	0x201A018C	[0, 5]	63	io -4 0x201A018C 0x003F003F
	ExtPort	read gpio data in input mode	0x20840070	[6, 6]		io -4 0x20840070
GPIO2A7	IOMUX	UART1_RX_M2	0x201A0044	[12, 15]	1	io -4 0x201A0044 0xF0001000
		SPIO_CS1N_M0	0x201A0044	[12, 15]	2	io -4 0x201A0044 0xF0002000
		PWM2_CH1_M1	0x201A0044	[12, 15]	3	io -4 0x201A0044 0xF0003000
		I2C2_SDA_M1	0x201A0044	[12, 15]	4	io -4 0x201A0044 0xF0004000
		SAI_SCLK	0x201A0044	[12, 15]	5	io -4 0x201A0044 0xF0005000
		ETH_LED_SPD	0x201A0044	[12, 15]	6	io -4 0x201A0044 0xF0006000
		GPIO2_A7	0x201A0044	[12, 15]	0	io -4 0x201A0044 0xF0000000
	Pull	z	0x201A0220	[14, 15]	0	io -4 0x201A0220 0xC0000000
		up	0x201A0220	[14, 15]	1	io -4 0x201A0220 0xC0004000
		down	0x201A0220	[14, 15]	2	io -4 0x201A0220 0xC0008000
	I/O Mode	input	0x20840008	[7, 7]	0	io -4 0x20840008 0x00800000
		output	0x20840008	[7, 7]	1	io -4 0x20840008 0x00800080
	Output	low	0x20840000	[7, 7]	0	io -4 0x20840000 0x00800000
		high	0x20840000	[7, 7]	1	io -4 0x20840000 0x00800080
	Input Ctrl	disable	0x201A0320	[7, 7]	0	io -4 0x201A0320 0x00800000
		enable	0x201A0320	[7, 7]	1	io -4 0x201A0320 0x00800080
	Schmitt	disable	0x201A0420	[7, 7]	0	io -4 0x201A0420 0x00800000
		enable	0x201A0420	[7, 7]	1	io -4 0x201A0420 0x00800080
	Drive Strength	level0	0x201A018C	[8, 13]	1	io -4 0x201A018C 0x3F000100
		level1	0x201A018C	[8, 13]	3	io -4 0x201A018C 0x3F000300
		level2	0x201A018C	[8, 13]	7	io -4 0x201A018C 0x3F000700
		level3	0x201A018C	[8, 13]	15	io -4 0x201A018C 0x3F000F00
		level4	0x201A018C	[8, 13]	31	io -4 0x201A018C 0x3F001F00
		level5	0x201A018C	[8, 13]	63	io -4 0x201A018C 0x3F003F00
	ExtPort	read gpio data in input mode	0x20840070	[7, 7]		io -4 0x20840070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO2B0	IOMUX	UART2_TX_M1	0x201A0048	[0,3]	1	io -4 0x201A0048 0x000F0001
		SPI0_CLK_M0	0x201A0048	[0,3]	2	io -4 0x201A0048 0x000F0002
		PWM0_CH3_M1	0x201A0048	[0,3]	3	io -4 0x201A0048 0x000F0003
		I2C4_SCL_M0	0x201A0048	[0,3]	4	io -4 0x201A0048 0x000F0004
		SAI_MCLK	0x201A0048	[0,3]	5	io -4 0x201A0048 0x000F0005
		FLASH_TRIG_OUT	0x201A0048	[0,3]	6	io -4 0x201A0048 0x000F0006
	Pull	GPIO2_B0	0x201A0048	[0,3]	0	io -4 0x201A0048 0x000F0000
		z	0x201A0224	[0,1]	0	io -4 0x201A0224 0x00030000
		up	0x201A0224	[0,1]	1	io -4 0x201A0224 0x00030001
	I/O Mode	down	0x201A0224	[0,1]	2	io -4 0x201A0224 0x00030002
		input	0x20840008	[8,8]	0	io -4 0x20840008 0x01000000
		output	0x20840008	[8,8]	1	io -4 0x20840008 0x000F0000
	Output	low	0x20840000	[8,8]	0	io -4 0x20840000 0x01000000
		high	0x20840000	[8,8]	1	io -4 0x20840000 0x01000100
	Input Ctrl	disable	0x201A0324	[0,0]	0	io -4 0x201A0324 0x00010000
		enable	0x201A0324	[0,0]	1	io -4 0x201A0324 0x00010001
	Schmitt	disable	0x201A0424	[0,0]	0	io -4 0x201A0424 0x00010000
		enable	0x201A0424	[0,0]	1	io -4 0x201A0424 0x00010001
	Drive Strength	level0	0x201A0190	[0,5]	1	io -4 0x201A0190 0x003F0001
		level1	0x201A0190	[0,5]	3	io -4 0x201A0190 0x003F0003
		level2	0x201A0190	[0,5]	7	io -4 0x201A0190 0x003F0007
		level3	0x201A0190	[0,5]	15	io -4 0x201A0190 0x003F000F
		level4	0x201A0190	[0,5]	31	io -4 0x201A0190 0x003F001F
		level5	0x201A0190	[0,5]	63	io -4 0x201A0190 0x003F003F
	ExtPort	read gpio data in input mode	0x20840070	[8,8]		io -4 0x20840070
GPIO2B1	IOMUX	UART2_RX_M1	0x201A0048	[4,7]	1	io -4 0x201A0048 0x000F00010
		SPI0_MOSI_M0	0x201A0048	[4,7]	2	io -4 0x201A0048 0x000F00020
		PWM1_CH3_M1	0x201A0048	[4,7]	3	io -4 0x201A0048 0x000F00030
		I2C4_SDA_M0	0x201A0048	[4,7]	4	io -4 0x201A0048 0x000F00040
		SAI_LRCK	0x201A0048	[4,7]	5	io -4 0x201A0048 0x000F00050
		PRELIGHT_TRIG_OUT	0x201A0048	[4,7]	6	io -4 0x201A0048 0x000F00060
	Pull	GPIO2_B1	0x201A0048	[4,7]	0	io -4 0x201A0048 0x000F00000
		z	0x201A0224	[2,3]	0	io -4 0x201A0224 0x000C0000
		up	0x201A0224	[2,3]	1	io -4 0x201A0224 0x000C0004
	I/O Mode	down	0x201A0224	[2,3]	2	io -4 0x201A0224 0x000C0008
		input	0x20840008	[9,9]	0	io -4 0x20840008 0x02000000
		output	0x20840008	[9,9]	1	io -4 0x20840008 0x02000200
	Output	low	0x20840000	[9,9]	0	io -4 0x20840000 0x02000000
		high	0x20840000	[9,9]	1	io -4 0x20840000 0x02000200
	Input Ctrl	disable	0x201A0324	[1,1]	0	io -4 0x201A0324 0x00020000
		enable	0x201A0324	[1,1]	1	io -4 0x201A0324 0x00020002
	Schmitt	disable	0x201A0424	[1,1]	0	io -4 0x201A0424 0x00020000
		enable	0x201A0424	[1,1]	1	io -4 0x201A0424 0x00020002
	Drive Strength	level0	0x201A0190	[8,13]	1	io -4 0x201A0190 0x3F000100
		level1	0x201A0190	[8,13]	3	io -4 0x201A0190 0x3F000300
		level2	0x201A0190	[8,13]	7	io -4 0x201A0190 0x3F000700
		level3	0x201A0190	[8,13]	15	io -4 0x201A0190 0x3F000F00
		level4	0x201A0190	[8,13]	31	io -4 0x201A0190 0x3F001F00
		level5	0x201A0190	[8,13]	63	io -4 0x201A0190 0x3F003F00
	ExtPort	read gpio data in input mode	0x20840070	[9,9]		io -4 0x20840070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO2B2	IOMUX	UART2 RTSN M1	0x201A0048	[8, 11]	1	io -4 0x201A0048 0x0F000100
		SPI0 CSON M0	0x201A0048	[8, 11]	2	io -4 0x201A0048 0x0F000200
		PWM2 CH2 M1	0x201A0048	[8, 11]	3	io -4 0x201A0048 0x0F000300
		I2C3 SDA M1	0x201A0048	[8, 11]	4	io -4 0x201A0048 0x0F000400
		SAI SDO	0x201A0048	[8, 11]	5	io -4 0x201A0048 0x0F000500
		GPIO2 B2	0x201A0048	[8, 11]	0	io -4 0x201A0048 0x0F000000
	Pull	z	0x201A0224	[4, 5]	0	io -4 0x201A0224 0x00300000
		up	0x201A0224	[4, 5]	1	io -4 0x201A0224 0x00300010
		down	0x201A0224	[4, 5]	2	io -4 0x201A0224 0x00300020
	I/O Mode	input	0x20840008	[10, 10]	0	io -4 0x20840008 0x04000000
		output	0x20840008	[10, 10]	1	io -4 0x20840008 0x04000400
	Output	low	0x20840000	[10, 10]	0	io -4 0x20840000 0x04000000
		high	0x20840000	[10, 10]	1	io -4 0x20840000 0x04000400
	Input Ctrl	disable	0x201A0324	[2, 2]	0	io -4 0x201A0324 0x00040000
		enable	0x201A0324	[2, 2]	1	io -4 0x201A0324 0x00040004
	Schmitt	disable	0x201A0424	[2, 2]	0	io -4 0x201A0424 0x00040000
		enable	0x201A0424	[2, 2]	1	io -4 0x201A0424 0x00040004
	Drive Strength	level0	0x201A0194	[0, 5]	1	io -4 0x201A0194 0x003F0001
		level1	0x201A0194	[0, 5]	3	io -4 0x201A0194 0x003F0003
		level2	0x201A0194	[0, 5]	7	io -4 0x201A0194 0x003F0007
		level3	0x201A0194	[0, 5]	15	io -4 0x201A0194 0x003F000F
		level4	0x201A0194	[0, 5]	31	io -4 0x201A0194 0x003F001F
		level5	0x201A0194	[0, 5]	63	io -4 0x201A0194 0x003F003F
	ExtPort	read gpio data in input mode	0x20840070	[10, 10]		io -4 0x20840070
GPIO2B3	IOMUX	UART2 CTSN M1	0x201A0048	[12, 15]	1	io -4 0x201A0048 0xF0001000
		SPI0 MISO M0	0x201A0048	[12, 15]	2	io -4 0x201A0048 0xF0002000
		PWM2 CH3 M1	0x201A0048	[12, 15]	3	io -4 0x201A0048 0xF0003000
		I2C3 SCL M1	0x201A0048	[12, 15]	4	io -4 0x201A0048 0xF0004000
		GPIO2 B3	0x201A0048	[12, 15]	0	io -4 0x201A0048 0xF0000000
		z	0x201A0224	[6, 7]	0	io -4 0x201A0224 0x00C00000
	Pull	up	0x201A0224	[6, 7]	1	io -4 0x201A0224 0x00C00040
		down	0x201A0224	[6, 7]	2	io -4 0x201A0224 0x00C00080
	I/O Mode	input	0x20840008	[11, 11]	0	io -4 0x20840008 0x08000000
		output	0x20840008	[11, 11]	1	io -4 0x20840008 0x08000800
	Output	low	0x20840000	[11, 11]	0	io -4 0x20840000 0x08000000
		high	0x20840000	[11, 11]	1	io -4 0x20840000 0x08000800
	Input Ctrl	disable	0x201A0324	[3, 3]	0	io -4 0x201A0324 0x00080000
		enable	0x201A0324	[3, 3]	1	io -4 0x201A0324 0x00080008
	Schmitt	disable	0x201A0424	[3, 3]	0	io -4 0x201A0424 0x00080000
		enable	0x201A0424	[3, 3]	1	io -4 0x201A0424 0x00080008
	Drive Strength	level0	0x201A0194	[8, 13]	1	io -4 0x201A0194 0x3F000100
		level1	0x201A0194	[8, 13]	3	io -4 0x201A0194 0x3F000300
		level2	0x201A0194	[8, 13]	7	io -4 0x201A0194 0x3F000700
		level3	0x201A0194	[8, 13]	15	io -4 0x201A0194 0x3F000F00
		level4	0x201A0194	[8, 13]	31	io -4 0x201A0194 0x3F001F00
		level5	0x201A0194	[8, 13]	63	io -4 0x201A0194 0x3F003F00
	ExtPort	read gpio data in input mode	0x20840070	[11, 11]		io -4 0x20840070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO2B4	Pull	z	0x201A080C	[13, 14]	0	io -4 0x201A080C 0x60000000
		up	0x201A080C	[13, 14]	3	io -4 0x201A080C 0x60006000
		down	0x201A080C	[13, 14]	1	io -4 0x201A080C 0x60002000
	I/O Mode	input	0x20840008	[12, 12]	0	io -4 0x20840008 0x10000000
		output	0x20840008	[12, 12]	1	io -4 0x20840008 0x10001000
	Output	low	0x20840000	[12, 12]	0	io -4 0x20840000 0x10000000
		high	0x20840000	[12, 12]	1	io -4 0x20840000 0x10001000
	Input Ctrl	disable	0x201A080C	[4, 4]	0	io -4 0x201A080C 0x00100000
		enable	0x201A080C	[4, 4]	1	io -4 0x201A080C 0x00100010
	Schmitt	disable	0x201A080C	[8, 9]	0	io -4 0x201A080C 0x03000000
		enable	0x201A080C	[8, 9]	3	io -4 0x201A080C 0x03000300
	Drive Strength	level0	0x201A080C	[10, 11]	0	io -4 0x201A080C 0x0c000000
		level1	0x201A080C	[10, 11]	1	io -4 0x201A080C 0x0c000100
		level2	0x201A080C	[10, 11]	2	io -4 0x201A080C 0x0c000200
		level3	0x201A080C	[10, 11]	3	io -4 0x201A080C 0x0c000300
	ExtPort	read gpio data in input mode	0x20840070	[12, 12]		io -4 0x20840070
GPIO2B5	Pull	z	0x201A080C	[13, 14]	0	io -4 0x201A080C 0x60000000
		up	0x201A080C	[13, 14]	3	io -4 0x201A080C 0x60006000
		down	0x201A080C	[13, 14]	1	io -4 0x201A080C 0x60002000
	I/O Mode	input	0x20840008	[13, 13]	0	io -4 0x20840008 0x20000000
		output	0x20840008	[13, 13]	1	io -4 0x20840008 0x20002000
	Output	low	0x20840000	[13, 13]	0	io -4 0x20840000 0x20000000
		high	0x20840000	[13, 13]	1	io -4 0x20840000 0x20002000
	Input Ctrl	disable	0x201A080C	[5, 5]	0	io -4 0x201A080C 0x00200000
		enable	0x201A080C	[5, 5]	1	io -4 0x201A080C 0x00200020
	Schmitt	disable	0x201A080C	[8, 9]	0	io -4 0x201A080C 0x03000000
		enable	0x201A080C	[8, 9]	3	io -4 0x201A080C 0x03000300
	Drive Strength	level0	0x201A080C	[10, 11]	0	io -4 0x201A080C 0x0c000000
		level1	0x201A080C	[10, 11]	1	io -4 0x201A080C 0x0c000100
		level2	0x201A080C	[10, 11]	2	io -4 0x201A080C 0x0c000200
		level3	0x201A080C	[10, 11]	3	io -4 0x201A080C 0x0c000300
	ExtPort	read gpio data in input mode	0x20840070	[13, 13]		io -4 0x20840070
GPIO2B6	Pull	z	0x201A080C	[13, 14]	0	io -4 0x201A080C 0x60000000
		up	0x201A080C	[13, 14]	3	io -4 0x201A080C 0x60006000
		down	0x201A080C	[13, 14]	1	io -4 0x201A080C 0x60002000
	I/O Mode	input	0x20840008	[14, 14]	0	io -4 0x20840008 0x40000000
		output	0x20840008	[14, 14]	1	io -4 0x20840008 0x40004000
	Output	low	0x20840000	[14, 14]	0	io -4 0x20840000 0x40000000
		high	0x20840000	[14, 14]	1	io -4 0x20840000 0x40004000
	Input Ctrl	disable	0x201A080C	[6, 6]	0	io -4 0x201A080C 0x00400000
		enable	0x201A080C	[6, 6]	1	io -4 0x201A080C 0x00400010
	Schmitt	disable	0x201A080C	[8, 9]	0	io -4 0x201A080C 0x03000000
		enable	0x201A080C	[8, 9]	3	io -4 0x201A080C 0x03000300
	Drive Strength	level0	0x201A080C	[10, 11]	0	io -4 0x201A080C 0x0c000000
		level1	0x201A080C	[10, 11]	1	io -4 0x201A080C 0x0c000100
		level2	0x201A080C	[10, 11]	2	io -4 0x201A080C 0x0c000200
		level3	0x201A080C	[10, 11]	3	io -4 0x201A080C 0x0c000300
	ExtPort	read gpio data in input mode	0x20840070	[14, 14]		io -4 0x20840070

RV1103B

Name	Config	Description	Register	Position	Value	IO Command
GPIO2B7	Pull	z	0x201A080C	[13, 14]	0	io -4 0x201A080C 0x60000000
		up	0x201A080C	[13, 14]	3	io -4 0x201A080C 0x60006000
		down	0x201A080C	[13, 14]	1	io -4 0x201A080C 0x60002000
	I/O Mode	input	0x20840008	[15, 15]	0	io -4 0x20840008 0x80000000
		output	0x20840008	[15, 15]	1	io -4 0x20840008 0x80008000
	Output	low	0x20840000	[15, 15]	0	io -4 0x20840000 0x80000000
		high	0x20840000	[15, 15]	1	io -4 0x20840000 0x80008000
	Input Ctrl	disable	0x201A080C	[7, 7]	0	io -4 0x201A080C 0x00800000
		enable	0x201A080C	[7, 7]	1	io -4 0x201A080C 0x00800080
	Schmitt	disable	0x201A080C	[8, 9]	0	io -4 0x201A080C 0x03000000
		enable	0x201A080C	[8, 9]	3	io -4 0x201A080C 0x03000300
	Drive Strength	level0	0x201A080C	[10, 11]	0	io -4 0x201A080C 0x0c000000
		level1	0x201A080C	[10, 11]	1	io -4 0x201A080C 0x0c000100
		level2	0x201A080C	[10, 11]	2	io -4 0x201A080C 0x0c000200
		level3	0x201A080C	[10, 11]	3	io -4 0x201A080C 0x0c000300
	ExtPort	read gpio data in input mode	0x20840070	[15, 15]		io -4 0x20840070