

GENERAL USE

- How to stack food case on top of one another?
 - Place one covered food case on top of another covered food case and press together so the bottom of one food case attaches to the lid of the other.

.........



.



- Hand-washing is preferred for both lid and food case.
- Do not use steel or abrasive sponges in order to avoid scratching the surface of the food case.
- Top rack dishwasher safe only.

CAUTION

- Do not heat longer than 2 minutes in the microwave. (Not more than 100°C)
- · Not for oven use.





