<u>Base</u>	SIMD&FP	<u>SVE</u>	<u>SME</u>	Index by
<u>Instructions</u>	<u>Instructions</u>	<u>Instructions</u>	<u>Instructions</u>	Encoding

Pseu

SSHLL, SSHLL2

Signed Shift Left Long (immediate). This instruction reads each vector element from the source SIMD&FP register, left shifts each vector element by the specified shift amount, places the result into a vector, and writes the vector to the destination SIMD&FP register. The destination vector elements are twice as long as the source vector elements. All the values in this instruction are signed integer values.

The SSHLL instruction extracts vector elements from the lower half of the source register. The SSHLL2 instruction extracts vector elements from the upper half of the source register.

Depending on the settings in the *CPACR_EL1*, *CPTR_EL2*, and *CPTR_EL3* registers, and the current Security state and Exception level, an attempt to execute the instruction might be trapped.

This instruction is used by the alias **SXTL**, **SXTL2**.

```
31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

0 Q 0 0 1 1 1 1 0 != 0000 | immb | 1 0 1 0 0 1 | Rn | Rd

U | immh
```

```
SSHLL{2} <Vd>.<Ta>, <Vn>.<Tb>, #<shift>
```

```
integer d = UInt(Rd);
integer n = UInt(Rn);

if immh == '0000' then SEE(asimdimm);
if immh<3> == '1' then UNDEFINED;
constant integer esize = 8 << HighestSetBit(immh);
constant integer datasize = 64;
integer part = UInt(Q);
integer elements = datasize DIV esize;

integer shift = UInt(immh:immb) - esize;
boolean unsigned = (U == '1');</pre>
```

Assembler Symbols

2

Is the second and upper half specifier. If present it causes the operation to be performed on the upper 64 bits of the registers holding the narrower elements, and is encoded in "Q":

Q	2
0	[absent]
1	[present]

<Vd>

Is the name of the SIMD&FP destination register, encoded in the "Rd" field.

<Ta>

Is an arrangement specifier, encoded in "immh":

immh	<ta></ta>
0000	SEE Advanced SIMD modified immediate
0001	8Н
001x	4S
01xx	2D
1xxx	RESERVED

<Vn>

Is the name of the SIMD&FP source register, encoded in the "Rn" field.

<Tb>

Is an arrangement specifier, encoded in "immh:Q":

immh	Q	<tb></tb>
0000	Х	SEE Advanced SIMD modified
		<u>immediate</u>
0001	0	8B
0001	1	16B
001x	0	4H
001x	1	8H
01xx	0	2S
01xx	1	4S
1xxx	X	RESERVED

<shift>

Is the left shift amount, in the range 0 to the source element width in bits minus 1, encoded in "immh:immb":

immh	<shift></shift>
0000	SEE Advanced SIMD modified immediate
0001	(UInt(immh:immb)-8)
001x	(UInt(immh:immb)-16)
01xx	(UInt(immh:immb)-32)
1xxx	RESERVED

Alias Conditions

Alias	Is preferred when		
SXTL, SXTL2	immb == '000' && <u>BitCount</u> (immh) == 1		

Operation

```
CheckFPAdvSIMDEnabled64();
bits(datasize) operand = Vpart[n, part, datasize];
bits(datasize*2) result;
integer element;
for e = 0 to elements-1
```

```
element = Int(Elem[operand, e, esize], unsigned) << shift;
    Elem[result, e, 2*esize] = element<2*esize-1:0>;

V[d, datasize*2] = result;
```

Operational information

If PSTATE.DIT is 1:

- The execution time of this instruction is independent of:
 - The values of the data supplied in any of its registers.
 - The values of the NZCV flags.
- The response of this instruction to asynchronous exceptions does not vary based on:
 - The values of the data supplied in any of its registers.
 - The values of the NZCV flags.

<u>Base</u>	SIMD&FP	<u>SVE</u>	<u>SME</u>	Index by
<u>Instructions</u>	<u>Instructions</u>	<u>Instructions</u>	<u>Instructions</u>	Encoding

 $Internal\ version\ only: is a\ v33.64,\ AdvSIMD\ v29.12,\ pseudocode\ no_diffs_2023_09_RC2,\ sve\ v2023-06_rel\ ;\ Build\ timestamp:\ 2023-09-18T17:56$

Copyright © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.

Sh Pseu