Base

FADDP (vector)

Floating-point Add Pairwise (vector). This instruction creates a vector by concatenating the vector elements of the first source SIMD&FP register after the vector elements of the second source SIMD&FP register, reads each pair of adjacent vector elements from the concatenated vector, adds each pair of values together, places the result into a vector, and writes the vector to the destination SIMD&FP register. All the values in this instruction are floating-point values.

This instruction can generate a floating-point exception. Depending on the settings in *FPCR*, the exception results in either a flag being set in *FPSR* or a synchronous exception being generated. For more information, see Floating-point exception traps.

Depending on the settings in the CPACR EL1, CPTR EL2, and CPTR EL3 registers, and the current Security state and Exception level, an attempt to execute the instruction might be trapped.

It has encodings from 2 classes: Half-precision and Single-precision and double-precision

Half-precision (FEAT_FP16)

```
31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
                                        0 0 0 1 0 1
|0|Q|1|0 1 1 1 0|0|1 0|
                               Rm
     U
```

```
FADDP <Vd>.<T>, <Vn>.<T>, <Vm>.<T>
```

```
if !IsFeatureImplemented(FEAT_FP16) then UNDEFINED;
integer d = UInt(Rd);
integer n = UInt(Rn);
integer m = UInt(Rm);
constant integer esize = 16;
constant integer datasize = 64 << UInt(Q);
integer elements = datasize DIV esize;
boolean pair = (U == '1');
```

Single-precision and double-precision

```
31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
0|Q|1|0 1 1 1 0|0|sz|1
                               Rm
                                      1 1 0 1 0 1
                                                          Rn
```

```
FADDP <Vd>.<T>, <Vn>.<T>, <Vm>.<T>
integer d = <u>UInt</u>(Rd);
integer n = UInt(Rn);
integer m = UInt(Rm);
```

```
if sz:Q == '10' then UNDEFINED;
constant integer esize = 32 << UInt(sz);
constant integer datasize = 64 << UInt(Q);
integer elements = datasize DIV esize;

boolean pair = (U == '1');</pre>
```

Assembler Symbols

<Vd>

Is the name of the SIMD&FP destination register, encoded in the "Rd" field.

<T>

For the half-precision variant: is an arrangement specifier, encoded in "Q":

Q	<t></t>
0	4 H
1	8H

For the single-precision and double-precision variant: is an arrangement specifier, encoded in "sz:Q":

SZ	Q	<t></t>
0	0	2S
0	1	4 S
1	0	RESERVED
1	1	2D

<Vn>

Is the name of the first SIMD&FP source register, encoded in the "Rn" field.

<Vm>

Is the name of the second SIMD&FP source register, encoded in the "Rm" field.

Operation

```
CheckFPAdvSIMDEnabled64();
bits(datasize) operand1 = V[n, datasize];
bits(datasize) operand2 = \underline{\underline{V}}[m, datasize];
bits(datasize) result;
bits(2*datasize) concat = operand2:operand1;
bits(esize) element1;
bits(esize) element2;
for e = 0 to elements-1
    if pair then
        element1 = Elem[concat, 2*e, esize];
        element2 = Elem[concat, (2*e)+1, esize];
    else
        element1 = Elem[operand1, e, esize];
        element2 = Elem[operand2, e, esize];
    Elem[result, e, esize] = FPAdd(element1, element2, FPCR[]);
V[d, datasize] = result;
```

BaseSIMD&FPSVESMEIndex byInstructionsInstructionsInstructionsInstructions

 $Internal\ version\ only: is a\ v33.64,\ AdvSIMD\ v29.12,\ pseudocode\ no_diffs_2023_09_RC2,\ sve\ v2023-06_rel\ ;\ Build\ timestamp:\ 2023-09-18T17:56$

Copyright © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.

Sh Pseu