ADDS (immediate)

Add (immediate), setting flags, adds a register value and an optionally-shifted immediate value, and writes the result to the destination register. It updates the condition flags based on the result.

This instruction is used by the alias [CMN (immediate)](#).

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
sf	0	1	1	0	0	0	1	0	sh				imm12										Rn					Rd			
	op	S																													

32-bit (sf == 0)

```
ADDS <Wd>, <Wn|WSP>, #<imm>{, <shift>}
```

64-bit (sf == 1)

```
ADDS <Xd>, <Xn|SP>, #<imm>{, <shift>}
```

```
integer d = UInt(Rd);
integer n = UInt(Rn);
constant integer datasize = 32 << UInt(sf);
bits(datasize) imm;

case sh of
    when '0' imm = ZeroExtend(imm12, datasize);
    when '1' imm = ZeroExtend(imm12:Zeros(12), datasize);
```

Assembler Symbols

<Wd>	Is the 32-bit name of the general-purpose destination register, encoded in the "Rd" field.
<Wn|WSP>	Is the 32-bit name of the source general-purpose register or stack pointer, encoded in the "Rn" field.
<Xd>	Is the 64-bit name of the general-purpose destination register, encoded in the "Rd" field.
<Xn|SP>	Is the 64-bit name of the source general-purpose register or stack pointer, encoded in the "Rn" field.
<imm>	Is an unsigned immediate, in the range 0 to 4095, encoded in the "imm12" field.

<shift>
> Is the optional left shift to apply to the immediate,
> defaulting to LSL #0 and encoded in "sh":

sh	<shift>
0	LSL #0
1	LSL #12

Alias Conditions

Alias	Is preferred when
[CMN (immediate)](#)	`Rd == '11111'`

Operation

```
bits(datasize) result;
bits(datasize) operand1 = if n == 31 then SP[]<datasize-1:0> else X[n,
bits(4) nzcv;

(result, nzcv) = AddWithCarry(operand1, imm, '0');

PSTATE.<N,Z,C,V> = nzcv;

X[d, datasize] = result;
```

Operational information

If PSTATE.DIT is 1:

- The execution time of this instruction is independent of:
    - The values of the data supplied in any of its registers.
    - The values of the NZCV flags.
- The response of this instruction to asynchronous exceptions does not vary based on:
    - The values of the data supplied in any of its registers.
    - The values of the NZCV flags.