FMULX

Floating-point Multiply extended. This instruction multiplies corresponding floating-point values in the vectors of the two source SIMD&FP registers, places the resulting floating-point values in a vector, and writes the vector to the destination SIMD&FP register.

If one value is zero and the other value is infinite, the result is 2.0. In this case, the result is negative if only one of the values is negative, otherwise the result is positive.

This instruction can generate a floating-point exception. Depending on the settings in *FPCR*, the exception results in either a flag being set in *FPSR*, or a synchronous exception being generated. For more information, see *Floating-point exception traps*.

Depending on the settings in the *CPACR_EL1*, *CPTR_EL2*, and *CPTR_EL3* registers, and the current Security state and Exception level, an attempt to execute the instruction might be trapped.

It has encodings from 4 classes: <u>Scalar half precision</u>, <u>Scalar single-precision</u> and <u>double-precision</u>, <u>Vector half precision</u> and <u>Vector single-precision</u> and <u>double-precision</u>

Scalar half precision (FEAT FP16)

```
31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0 0 1 0 1 1 1 1 1 0 0 1 0 Rm 0 0 0 1 1 1 Rn Rd
```

```
FMULX <Hd>, <Hn>, <Hm>
```

```
if !IsFeatureImplemented(FEAT_FP16) then UNDEFINED;
integer d = UInt(Rd);
integer n = UInt(Rn);
integer m = UInt(Rm);
constant integer esize = 16;
constant integer datasize = esize;
integer elements = 1;
```

Scalar single-precision and double-precision

```
31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0 0 1 0 1 1 1 1 0 0 sz 1 Rm 1 1 0 1 1 1 Rn Rd
```

```
FMULX <V><d>, <V><n>, <V><m>
```

```
integer d = UInt(Rd);
integer n = UInt(Rn);
integer m = UInt(Rm);
constant integer esize = 32 << UInt(sz);
constant integer datasize = esize;
integer elements = 1;</pre>
```

Vector half precision (FEAT FP16)

31 30 29	28 27 26 2	5 24 23 22 21	20 19 18 17 16	15 14 1	3 12 11 10	9 8 7 6 5	4 3 2 1 0
0 Q 0	0 1 1 1	0010	Rm	0 0	0 1 1 1	Rn	Rd

FMULX <Vd>.<T>, <Vn>.<T>, <Vm>.<T>

```
if !IsFeatureImplemented(FEAT_FP16) then UNDEFINED;
integer d = UInt(Rd);
integer n = UInt(Rn);
integer m = UInt(Rm);
constant integer esize = 16;
constant integer datasize = 64 << UInt(Q);
integer elements = datasize DIV esize;</pre>
```

Vector single-precision and double-precision

31 30 29 28 27 26 25 24	23 22 21 20 19 18 17 16	15 14 13 12 11 10 9 8 7 6 5	4 3 2 1 0
0 Q 0 0 1 1 1 0	0 sz 1 Rm	1 1 0 1 1 1 Rn	Rd

FMULX <Vd>.<T>, <Vn>.<T>, <Vm>.<T>

```
integer d = UInt(Rd);
integer n = UInt(Rn);
integer m = UInt(Rm);
if sz:Q == '10' then UNDEFINED;
constant integer esize = 32 << UInt(sz);
constant integer datasize = 64 << UInt(Q);
integer elements = datasize DIV esize;</pre>
```

Assembler Symbols

<Hd> Is the 16-bit name of the SIMD&FP destination register,

encoded in the "Rd" field.

<Hn> Is the 16-bit name of the first SIMD&FP source register,

encoded in the "Rn" field.

<Hm> Is the 16-bit name of the second SIMD&FP source register,

encoded in the "Rm" field.

<V> Is a width specifier, encoded in "sz":

SZ	<v></v>
0	S
1	D

<d>Is the number of the SIMD&FP destination register, in the

"Rd" field.

<n> Is the number of the first SIMD&FP source register,

encoded in the "Rn" field.

<m> Is the number of the second SIMD&FP source register, encoded in the "Rm" field.

Is the name of the SIMD&FP destination register, encoded in the "Rd" field.

For the half-precision variant: is an arrangement specifier, encoded in "Q":

Q	<t></t>
0	4 H
1	8H

For the single-precision and double-precision variant: is an arrangement specifier, encoded in "sz:Q":

SZ	Q	<t></t>
0	0	2S
0	1	4S
1	0	RESERVED
1	1	2D

<Vn> Is the name of the first SIMD&FP source register, encoded in the "Rn" field.

Is the name of the second SIMD&FP source register, encoded in the "Rm" field.

Operation

<Vm>

<Vd>

<T>

```
if elements == 1 then
    CheckFPEnabled64();
else
    CheckFPAdvSIMDEnabled64();
bits(datasize) operand1 = \underline{V}[n, datasize];
bits(datasize) operand2 = V[m, datasize];
bits(esize) element1;
bits(esize) element2;
FPCRType fpcr = FPCR[];
boolean merge = elements == 1 && <u>IsMerging(fpcr);</u>
bits (128) result = if merge then V[n, 128] else Zeros(128);
for e = 0 to elements-1
    element1 = Elem[operand1, e, esize];
    element2 = Elem[operand2, e, esize];
    Elem[result, e, esize] = FPMulX(element1, element2, fpcr);
V[d, 128] = result;
```

Base Instructions SIMD&FP Instructions

<u>SVE</u> Instructions SME Instructions Index by Encoding Internal version only: isa v33.64, AdvSIMD v29.12, pseudocode no_diffs_2023_09_RC2, sve v2023-06_rel ; Build timestamp: 2023-09-18T17:56 Copyright \hat{A} © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.