AMAIR_EL2, Auxiliary Memory Attribute Indirection Register (EL2)

The AMAIR EL2 characteristics are:

Purpose

Provides implementation defined memory attributes for the memory regions specified by MAIR_EL2.

Configuration

AArch64 System register AMAIR_EL2 bits [31:0] are architecturally mapped to AArch32 System register HAMAIR0[31:0].

AArch64 System register AMAIR_EL2 bits [63:32] are architecturally mapped to AArch32 System register HAMAIR1[31:0].

If EL2 is not implemented, this register is res0 from EL3.

This register has no effect if EL2 is not enabled in the current Security state.

Attributes

AMAIR EL2 is a 64-bit register.

Field descriptions

63 62 61 60 59 58 57 56 55 54 53 52 51 50 49 48 47 46 45 44 43 42 41 40 39 38 37 36 35 34 33 32

IMPLEMENTATION DEFINED

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

AMAIR EL2 is permitted to be cached in a TLB.

IMPLEMENTATION DEFINED, bits [63:0]

implementation defined.

The reset behavior of this field is:

• On a Warm reset, this field resets to an architecturally unknown value.

Accessing AMAIR_EL2

When <u>HCR_EL2</u>.E2H is 1, without explicit synchronization, access from EL2 using the mnemonic AMAIR_EL2 or AMAIR_EL1 are not guaranteed to be ordered with respect to accesses using the other mnemonic.

Accesses to this register use the following encodings in the System register encoding space:

MRS <Xt>, AMAIR_EL2

op0	op1	CRn	CRm	op2
0b11	0b100	0b1010	0b0011	0b000

```
if PSTATE.EL == EL0 then
    UNDEFINED;
elsif PSTATE.EL == EL1 then
    if EL2Enabled() && HCR_EL2.NV == '1' then
        Aarch64.SystemAccessTrap(EL2, 0x18);
    else
        UNDEFINED;
elsif PSTATE.EL == EL2 then
        X[t, 64] = AMAIR_EL2;
elsif PSTATE.EL == EL3 then
        X[t, 64] = AMAIR_EL2;
```

MSR AMAIR EL2, <Xt>

op0	op1	CRn	CRm	op2
0b11	0b100	0b1010	0b0011	0b000

```
if PSTATE.EL == EL0 then
    UNDEFINED;
elsif PSTATE.EL == EL1 then
    if EL2Enabled() && HCR_EL2.NV == '1' then
        AArch64.SystemAccessTrap(EL2, 0x18);
    else
        UNDEFINED;
elsif PSTATE.EL == EL2 then
    AMAIR_EL2 = X[t, 64];
elsif PSTATE.EL == EL3 then
    AMAIR_EL2 = X[t, 64];
```

When FEAT_VHE is implemented MRS <Xt>, AMAIR EL1

op0	op1	CRn	CRm	op2
0b11	0b000	0b1010	0b0011	0b000

```
if PSTATE.EL == ELO then
   UNDEFINED;
elsif PSTATE.EL == EL1 then
   if EL2Enabled() && HCR EL2.TRVM == '1' then
        AArch64.SystemAccessTrap(EL2, 0x18);
   elsif EL2Enabled() &&
IsFeatureImplemented(FEAT_FGT) && (!HaveEL(EL3) |
SCR_EL3.FGTEn == '1') && HFGRTR_EL2.AMAIR_EL1 == '1'
        AArch64.SystemAccessTrap(EL2, 0x18);
   elsif EL2Enabled() && HCR_EL2.<NV2,NV1,NV> ==
'111' then
        X[t, 64] = NVMem[0x148];
    else
        X[t, 64] = AMAIR\_EL1;
elsif PSTATE.EL == EL2 then
    if HCR_EL2.E2H == '1' then
       X[t, 64] = AMAIR\_EL2;
    else
        X[t, 64] = AMAIR\_EL1;
elsif PSTATE.EL == EL3 then
   X[t, 64] = AMAIR\_EL1;
```

When FEAT_VHE is implemented MSR AMAIR_EL1, <Xt>

op0	op1	CRn	CRm	op2
0b11	0b000	0b1010	0b0011	0b000

```
if PSTATE.EL == EL0 then
    UNDEFINED;
elsif PSTATE.EL == EL1 then
    if EL2Enabled() && HCR_EL2.TVM == '1' then
        AArch64.SystemAccessTrap(EL2, 0x18);
    elsif EL2Enabled() &&
IsFeatureImplemented(FEAT_FGT) && (!HaveEL(EL3) ||
SCR_EL3.FGTEn == '1') && HFGWTR_EL2.AMAIR_EL1 == '1'
then
        AArch64.SystemAccessTrap(EL2, 0x18);
    elsif EL2Enabled() && HCR_EL2.<NV2,NV1,NV> ==
'111' then
        NVMem[0x148] = X[t, 64];
```

```
else
         AMAIR_EL1 = X[t, 64];
elsif PSTATE.EL == EL2 then
    if HCR_EL2.E2H == '1' then
         AMAIR_EL2 = X[t, 64];
else
         AMAIR_EL1 = X[t, 64];
elsif PSTATE.EL == EL3 then
         AMAIR_EL1 = X[t, 64];
```

AArch32 Registers AArch64 Registers

AArch32 Instructions AArch64 Instructions Index by Encoding

External Registers

28/03/2023 16:02; 72747e43966d6b97dcbd230a1b3f0421d1ea3d94

Copyright © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.