Index by

Encoding

Base SIMD&FP Instructions Instructions

SVE Instructions SME Instructions

INCP (vector)

Increment vector by count of true predicate elements

Counts the number of true elements in the source predicate and then uses the result to increment all destination vector elements.

The predicate size specifier may be omitted in assembler source code, but this is deprecated and will be prohibited in a future release of the architecture.

```
31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0 0 0 1 0 0 1 0 1 size 1 0 1 1 0 0 1 0 0 0 0 0 0 0 Pm Zdn
```

```
INCP <Zdn>.<T>, <Pm>.<T>

if !HaveSVE() && !HaveSME() then UNDEFINED;
if size == '00' then UNDEFINED;
constant integer esize = 8 << UInt(size);
integer m = UInt(Pm);
integer dn = UInt(Zdn);</pre>
```

Assembler Symbols

<7.dn>

Is the name of the source and destination scalable vector register, encoded in the "Zdn" field.

<T>

Is the size specifier, encoded in "size":

size	<t></t>		
0.0	RESERVED		
01	Н		
10	S		
11	D		

<Pm>

Is the name of the source scalable predicate register, encoded in the "Pm" field.

Operation

```
CheckSVEEnabled();
constant integer VL = CurrentVL;
constant integer PL = VL DIV 8;
constant integer elements = VL DIV esize;
bits(VL) operand1 = Z[dn, VL];
bits(PL) operand2 = P[m, PL];
bits(VL) result;
integer count = 0;
```

```
for e = 0 to elements-1
   if ActivePredicateElement (operand2, e, esize) then
        count = count + 1;

for e = 0 to elements-1
        Elem[result, e, esize] = Elem[operand1, e, esize] + count;

Z[dn, VL] = result;
```

Operational information

This instruction might be immediately preceded in program order by a MOVPRFX instruction. The MOVPRFX instruction must conform to all of the following requirements, otherwise the behavior of the MOVPRFX and this instruction is unpredictable:

- The MOVPRFX instruction must be unpredicated.
- The MOVPRFX instruction must specify the same destination register as this instruction.
- The destination register must not refer to architectural register state referenced by any other source operand register of this instruction.

<u>Base</u>	SIMD&FP	<u>SVE</u>	<u>SME</u>	<u>Index by</u>
<u>Instructions</u>	<u>Instructions</u>	<u>Instructions</u>	<u>Instructions</u>	Encoding

Internal version only: is a v33.64, AdvSIMD v29.12, pseudocode no_diffs_2023_09_RC2, sve v2023-06_rel ; Build timestamp: 2023-09-18T17:56

Copyright © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.

Sh Pseu