dex by	Sh
ncoding	Pseud

BaseSIMD&FPSVESMEIndex byInstructionsInstructionsInstructionsInstructionsEncoding

INSR (scalar)

Insert general-purpose register in shifted vector

Shift the destination vector left by one element, and then place a copy of the least-significant bits of the general-purpose register in element 0 of the destination vector. This instruction is unpredicated.

3	31	30	29	28	27	26	25	24	23 22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Γ	0	0	0	0	0	1	0	1	size	1	0	0	1	0	0	0	0	1	1	1	0			Rm	1				Zdr	- ا	

```
INSR <Zdn>.<T>, <R><m>
```

```
if !HaveSVE() && !HaveSME() then UNDEFINED;
constant integer esize = 8 << UInt(size);
integer dn = UInt(Zdn);
integer m = UInt(Rm);</pre>
```

Assembler Symbols

<Zdn>

Is the name of the source and destination scalable vector register, encoded in the "Zdn" field.

<T>

Is the size specifier, encoded in "size":

size	<t></t>
0.0	В
01	Н
10	S
11	D

<R>

Is a width specifier, encoded in "size":

size	<r></r>
01	W
x0	W
11	X

<m>

Is the number [0-30] of the source general-purpose register or the name ZR (31), encoded in the "Rm" field.

Operation

```
CheckSVEEnabled();
constant integer VL = CurrentVL;
constant integer PL = VL DIV 8;
bits(VL) dest = Z[dn, VL];
bits(esize) src = X[m, esize];
Z[dn, VL] = dest<(VL-esize)-1:0> : src;
```

Operational information

If FEAT_SVE2 is implemented or FEAT_SME is implemented, then if PSTATE.DIT is 1:

- The execution time of this instruction is independent of:
 - The values of the data supplied in any of its registers.
 - The values of the NZCV flags.
- The response of this instruction to asynchronous exceptions does not vary based on:
 - The values of the data supplied in any of its registers.
 - The values of the NZCV flags.

This instruction might be immediately preceded in program order by a MOVPRFX instruction. The MOVPRFX instruction must conform to all of the following requirements, otherwise the behavior of the MOVPRFX and this instruction is unpredictable:

- The MOVPRFX instruction must be unpredicated.
- The MOVPRFX instruction must specify the same destination register as this instruction.
- The destination register must not refer to architectural register state referenced by any other source operand register of this instruction.

<u>Base</u>	SIMD&FP	<u>SVE</u>	<u>SME</u>	<u>Index by</u>
<u>Instructions</u>	<u>Instructions</u>	<u>Instructions</u>	<u>Instructions</u>	Encoding

Internal version only: isa v33.64, AdvSIMD v29.12, pseudocode no_diffs_2023_09_RC2, sve v2023-06_rel; Build timestamp: 2023-09-18T17:56

Copyright © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.

Sh Pseu