Base Instructions	SIMD&FP Instructions	<u>SVE</u> <u>Instructions</u>	SME Instructions	Index by Encoding
SEVL			_	
Send Event Local is a hint instruction that causes an event to be signaled locally without requiring the event to be signaled to other PEs in the multiprocessor system. It can prime a wait-loop which starts with a WFE instruction. $\frac{313029282726252423222120191817161514131211109876543210}{11010101000001111111$				
SEVL				
// Empty.				
Operation				
<u>SendEventLo</u>	<u>cal</u> ();			
<u>Base</u> <u>Instructions</u>	SIMD&FP Instructions	SVE Instructions	SME Instructions	Index by Encoding
Internal version only: isa v33.64, AdvSIMD v29.12, pseudocode no_diffs_2023_09_RC2, sve v2023-06_rel ; Build timestamp: 2023-09-18T17:56				
Copyright \hat{A} © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.				

Sh Pseu

Sh Pseu